

EN

**Notices Spéciaux
01/2025**

65105018/A



MANUAL

01/2025



TABLE OF CONTENTS

INSTALLER'S MANUAL **1**

CHASSAGNE/CHAMBERTIN - SAULIEU/SAVIGNY - CLUNY1400 D-G
CLUNY GRAND CHEF 1400 D-G - CHAGNY 1400 D-G - SULLY
FONTENAY 1500 - CITEAUX 1500 - CLUNY 1800
CLUNY GRAND CHEF 1800 - CHAGNY 1800 - SULLY 1800 D-G
FONTENAY 1900 D-G - CITEAUX 1900 D-G - SULLY 2200

USER'S MANUAL **47**

TECHNICAL DATA **93**

CHASSAGNE/CHAMBERTIN	97
SAULIEU/SAVIGNY	105
CLUNY1400 D-G	113
CLUNY GRAND CHEF 1400 D-G	121
CHAGNY 1400 D-G	129
SULLY	137
FONTENAY 1500	143
CITEAUX 1500	149
CLUNY 1800	155
CLUNY GRAND CHEF 1800	161
CHAGNY 1800	167
SULLY 1800 D-G	173
FONTENAY 1900 D-G	181
CITEAUX 1900 D-G	189
SULLY 2200	197

OPTIONS	203
----------------	------------

GAS BURNERS	205
CERAMIC HOB	215
INDUCTION	221
PLANCHA	231
CHARGRILL	239
MULTICOOKER	249
ELECTRIC FRIED	267

APPENDIX	275
-----------------	------------

INSTALLATION MANUAL

The installation must be carried out in accordance with recognised best practices, the instructions given in this manual and the regulations in force in the country of installation. The instructions in this INSTALLATION MANUAL are intended for qualified technicians with a good knowledge of this type of appliance and of gas and electrical installations.

This manual must be given to the user on completion of the installation.





Summary

INSTALLATION MANUAL

INSTALLATION - POSITIONING	3
GAS CONNECTION	9
ADJUSTMENT OF THE HOB BURNER	13
ADJUSTMENT OF THE OVEN	17
CHANGE OF GAS	21
GAS CIRCUIT	25
ELECTRICAL POWER CONNECTION	27
WIRING DIAGRAM	29
RESETTING THE SAFETY	39
OPENING AND CLOSING THE GAS HOB TABLE	43

CAUTION:

- The buyer agrees to install the appliance in accordance with recognised best practices and the regulations in force.
- Any technical operation such as installation, repair or adjustment of the appliance must be carried out by a qualified technician.
- Do not lift the appliance by the front rail. Damages caused in this way are not covered by the warranty.
- If the appliance is to be installed against a wall or partition, or close to furniture or decorative railing or skirting, these must be made of fireproof material. Otherwise, they must be lined with a fireproof material. Special attention must be given to all fire prevention regulations. The flooring in the room where the appliance is to be installed must be capable of withstanding temperatures above 65°C.
- Install a suitable extractor hood above the range cooker.
- Before installation, make sure that the local distribution conditions (type of gas and gas pressure) and the setting of the appliance are compatible.
- The setting conditions of this unit are written on the label or name-plate.
- This appliance is not connected to an combustion by-product extraction vent.
- It must be installed and connected in accordance with the applicable installation rules. Particular attention should be given to the applicable ventilation provisions.

DELIVERY AND UNPACKING:

The appliance is delivered on a wooden pallet, packed with cardboard.


- Unpack and check the appliance for damage upon receipt. In case of damage, mark the delivery note accordingly, and within 48 hours notify the carrier in writing by registered mail with acknowledgement of receipt.
- To release the appliance from the pallet, use a 10 mm Allen key to remove the screws under the pallet.
- Remove the wooden pallet and put the appliance on the floor, taking care not to lift it by the front rail.

MOVING AND POSITIONING:


The base of the appliance is made up of a stainless steel frame with rollers on jacks. Using these, the appliance can be raised in order to move it and to adjust its height. The stainless steel front plinth is fixed to the appliance. It can be removed by taking out the pins from the top edge of the plinth.

To be able to move the appliance and to adjust its height :


- Ⓐ Remove the drawers and, if required, open the side doors.




- Ⓑ Open the side door if necessary.




- Ⓒ Pull out the pins from the top edge of the plinth.




- Ⓓ Remove the plinth.



- Ⓔ Using the 7 mm spanner supplied, turn the jacking screws. By doing this, the height of the appliance can be raised or lowered a few millimetres. The appliance can also be rested on the rollers, making it easier to move it to its final position.




- Ⓕ Adjust the jacks using the 20 mm spanner supplied.



PLACE OF INSTALLATION:


- Class 2 devices, sub class 1.
- Check that the gas and electrical supplies, as well as the water supply and drain if required for a combined bain-marie and steam cooker, are provided at the back of or close to the appliance.
- Check that there is adequate space to move the appliance and that the clearance distances shown in the diagram below are available.




(1) CAUTION : Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

- (A) When the appliance is installed next to a worktop surface, the top surface of the appliance must be adjusted level with or above the adjacent surface.
- (B) Above the level of top surface of the appliance there must be a minimum lateral clearance of 75 mm between the edge of the appliance and any adjacent surface. This minimum clearance may be reduced to 50 mm when the surfaces are made of a fireproof material (ceramics, glass, stone, metal).
- (C) There must be a minimum vertical clearance of 800 mm between the top surface of the appliance and any horizontal surface above.
- (D) A minimum lateral clearance of 5 mm between the appliance and the adjacent walls is recommended so that the appliance can be moved and positioned. In order to facilitate other operations such as cleaning, maintenance or repairs, it is recommended that the appliance be kept free, without being permanently fixed to or enclosed within its location.
- (E) It is recommended that the front edge of the appliance is 55 mm further outward than the front edges of the adjacent units.


MOUNTING OF THE BACKSPLASH FOR LACANCHE RANGES




The backsplash must be mounted at least 40mm lower than the range tabletop so it is flush against the wall.



Never place the backsplash on the tabletop.







USE OF SPLASH BACK (Ref. DSD) AND BACK COVERS (Ref. LCH and LCR):

The splash back and covers are particularly recommended as accessories for appliances installed in between other units and/or walls. They bring the appliance 50 mm (DSD) from the wall, making its overall 700 mm.

They also make the working environment more comfortable.



Important note on backsplash material:



The ovens in the Lacanche range have a very high level of energy efficiency, which means that almost no heat escapes from the oven cavities or through the door seals. Steam produced naturally during cooking must be vented. The outlets necessary for the ventilation of the ovens of your Lacanche piano are positioned at the back of the hob.

Since steam can escape from this vent, it is important to install a suitable backsplash material behind your Lacanche piano (A)

Do not use water-sensitive materials such as porous stones, wood, plaster or plasterboard, acrylic, latex, or matte paints, unglazed ceramics, etc.

WARNINGS:

Our gas supply connections on our products comply with the ISO EN 228-1 standard (parallel external thread). For cases in countries requiring fittings in accordance with EN ISO 10226-1 (conical external thread), an adapter fitting is supplied with the device (see **table 13** in the technical annex).

Lacanche's gas range cookers are designed to operate with natural gas (from a distribution network) or with LPG (propane-butane gas in bottles).

The appliance must be connected to the gas supply in accordance with recognised best practices and the regulations in force in the country of installation by a qualified technician (professional plumber, gas technician).

CHECKS BEFORE THE CONNECTION:

In order to ensure the correct and safe supply and operation of the appliance, the following checks must be completed :

APPLIANCE COMPATIBILITY WITH THE GAS SUPPLY :

- Before the connection, check the compliance of the gas supply pressure with the pressure for which the appliance is adjusted. This information is indicated on the nameplate located on the cross frame that is visible after removing the drawer (generally the left drawer).

Should the gas supply be incompatible with the gas required for the appliance, the injectors will have to be changed and a number of adjustments will have to be made. The relevant instructions are included in the section "Change of gas" of this manual.

PIPING:

- The gas supply to the appliance must be provided by means of rigid or flexible piping of sufficient size to allow use of the appliance for extended periods with a flow rate consistent with the power rating. This must be validated by the qualified technician making the gas connection
- The piping must be perfectly clean in order to avoid obstructions in the injectors and the faulty operation of the magnetic heads.

ELECTRICAL POWER SUPPLY:


- The electrical ignition for the burners works if the appliance is connected to the electrical power supply. Check that the electrical connection has been or can be made (refer to Section "Electrical power connection").

AIR SUPPLY:

- The required flow rate of fresh air must be checked. The supply of air must be sufficient to enable a good combustion.

SUPPLY DEVICE / SHUT-OFF VALVE:

- A shut-off valve must be installed nearby and be accessible in order to shut off the supply to the appliance



Natural gas:

Since 1st July 1997, an automatic shut-off valve must be fitted to all new installation or whenever an existing shut-off valve is replaced.

LPG (butane-propane):

Propane gas:

The installation must have a class-1 safety regulator.

Connect the appliance to the outlet of a 4 kg/h regulator. Recommended dual bottles to inlet of regulator for correct operation of the appliance during prolonged periods at full capacity. Supply from 35 kg bottle or from tank is possible and recommended (connection to appliance using approved LPG flexible hose with maximum length of 2 m).



Butane gas:

The connection must be made using a butane safety regulator fitted to the bottle (connection to appliance using approved LPG flexible hose with maximum length of 2 m).

Connect the appliance to the outlet of a 2.6 kg/h regulator. Recommended dual bottles to inlet of regulator for correct operation of the appliance during prolonged periods at full capacity

CONNECTION:

- The appliance is equipped with a Ø15/21 male connector (B), 1/2" gas thread, to the back of the appliance.
- For a correct supply, use an approved flexible connector of suitable characteristics, such as a wire-reinforced flexible connector.
- Once connected, check the supply pressure at the pressure port (B) to the back of the appliance, in one of the ends of the gas inlet manifold.
- Check the connection for leaks.



OPERATIONAL TESTS AND CHECKS:

Once connected, check that the burners operate correctly (hob and oven) and adjust as required.




CHECKING THE OPERATION OF THE HOB BURNERS :

- ① • Check that the appliance is connected to the electrical power supply. The electrical ignition works if the appliance is connected to the electrical power supply.
- Check that the gas shut-off valve is open.


- ② Push down on the control knob and turn it anticlockwise; press simultaneously on the ignition pushbutton.

Once the burner is lit, release the ignition pushbutton.

Keep the control knob down for about ten seconds in order to engage the safety thermocouple.



- ③ Turn the control knob anticlockwise whilst keeping it pushed; set it to the “low flame” setting indicated by the symbol of a small flame «». Release the control knob.




- ④ In the low flame setting, the flame must be low, steady and covering slightly the tip of the thermocouple.

► If the flame goes off in the low flame setting, repeat the procedure.

If after several attempts you are unable to hold the flame in the low flame setting, proceed to adjust the burner (refer to Section “Adjustment of the hob burners”).

► If the flame is too strong in the low flame setting, proceed to adjust the burner (refer to Section “Adjustment of the hob burners”).







CHECKING THE OPERATION OF THE OVEN BURNER:

Once connected, check that the burners operate correctly (hob and oven) and adjust as required.

- Check that the appliance is connected to the electrical power supply.
- Check that the gas shut-off valve is open.

- ① Open the oven door.
- ② Remove the bottom panel from the oven to be able to see the ignition and operation of the burner.
Keep the control knob down for about ten seconds in order to engage the safety thermocouple.
- ③ Push down on the control knob and turn it to the setting 10; press simultaneously on the ignition pushbutton.





- ④ Once the burner is lit, release the ignition pushbutton.
Keep the control knob down for about ten seconds in order to engage the safety thermocouple.

- ⑤ Release the control knob.
- ⑥ Close the oven door and wait for about 15 minutes.
- ⑦ Turn the control knob to the setting 1.

- ⑧ Open the oven door and check immediately that the height of the flame is low (a few millimetres) and covers slightly the tip of the thermocouple

- ⑨ In the low flame setting, the flame must be steady and low.
 - If the flame goes off in the low flame setting, repeat the procedure.
If after several attempts you are unable to hold the flame in the low flame setting, proceed to adjust the burner (refer to Section "Adjustment of the oven burner").
 - If the flame is too strong in the low flame setting, proceed to adjust the burner (refer to Section "Adjustment of the oven burner").



ADJUSTMENT OF THE HOB BURNERS



Lacanche's gas appliances are delivered fully adjusted in compliance with relevant regulations and for use with the particular gas supply (type, pressure) stated in the purchase order and indicated in the appliance's nameplate.

Nevertheless, after connecting the appliance, the correct operation of the burners (hob and oven) must be checked. If required, the height of the flame must be adjusted accordingly.

To do this, the gas delivery rate to the burner must be adjusted by screwing in or out the valve adjustment screw located behind the control knob.

This adjustment is essential when changing the gas supply after having changed injectors (refer to Section "CHANGE OF GAS").




WARNING:

The adjustment of burners must be carried out by a qualified technician.

EN 01-2025


OPERATION:

- 1 Push down on the control knob and turn it anticlockwise; press simultaneously on the ignition pushbutton.
Once the burner is lit, release the ignition pushbutton.



- 2 Still pushing down on the control knob, set it to the small flame "△" setting.

After about ten seconds to allow for the engagement of the thermocouple, release the control knob.




- 3 Turn the control knob anticlockwise whilst keeping it pushed; set it to the "low flame" setting indicated by the symbol of a small flame "△".
Release the control knob.

- 4 In the low flame setting, the flame must be low, steady and covering slightly the tip of the thermocouple.

► If the flame goes off in the low flame setting, repeat the procedure.
If after several attempts you are unable to hold the flame in the low flame setting, proceed to adjust the burner (refer to Section "ADJUSTMENT OF THE HOB BURNERS").

► If in the low flame setting, the flame is too strong, then the gas delivery rate to the burner needs to be reduced.




ADJUSTMENT OF THE HOB BURNERS


ADJUSTMENT OF THE FLOW RATE:

The adjustment of the low flame gas delivery rate is carried out with the burner on and the control knob removed, using a small screwdriver to screw in or out the screw in the gas valve located behind the control knob and the control panel.



- ① With the burner on, set the control knob to the small flame «» setting.




- ② Remove the control knob.



- ③ Screw in or out the gas valve screw to adjust the delivery rate for the low flame.
Screwing out increases the flame.
Screwing in reduces the flame.



- ④ Replace the control knob and turn it to the large flame «» setting.




- ⑤ Turn quickly from the large flame «» setting to the small flame «» setting.

When doing this, the flame must remain burning.

At its minimum size, the flame must be a quarter ($\frac{1}{4}$) in size of the full flame.

When this is not the case :

Repeat the procedure from ① to ⑤.



ADJUSTMENT OF THE HOB BURNERS



EN 01-2025

PRIMARY AIR ADJUSTMENT:

The adjustment of the primary air (air-gas mixture) is done by adjusting the air ring located in the base of the burner, under the table. The mixture is correct when the flame is stable with blue cones.



A soft flame with yellow tips is the result of lack of air.

A flame whose base is separated from the burner cap is the result of excessive air.

CAUTION: The adjustment of the air ring is done with the burner off.


To avoid all risks of burns, ensure that all components likely to be handled manually (pan stands, burner caps...) and other elements in the working area are not hot.

- ① Remove the pan stands and the solid top (for “Tradition” appliances); then remove the caps and bodies of the burners.




- ② Through the hole in the table, remove the locknut from the adjusting spigot of the air ring using a 7 mm spanner.

- ▶ When there is lack of air, turn the adjusting spigot clockwise to increase the opening of the air ring.
- ▶ When there is excess of air, turn the adjusting spigot anticlockwise to reduce the opening of the air ring.



- ③ Replace and tighten lightly the lock nut.


- ④ Once the adjustment completed, replace the burner body and cap and run a new test.



ADJUSTMENT OF THE FLAME SAFETY THERMOCOUPLE:

After the adjustment, when turning on a burner, if it goes off after having kept the control knob pushed down for 20 seconds and then releasing, check that :

- The tip of the thermocouple is well covered by the flame and does not touch the burner;
- The thermocouples and magnetic heads are clean.
- The magnetic head is tightened correctly (moderate torque).



ADJUSTMENT OF THE OVEN BURNER



EN 01-2025

Lacanche's gas appliances are delivered fully adjusted in compliance with relevant regulations and for use with the particular gas supply (type, pressure) stated in the purchase order and indicated in the appliance's nameplate.

Nevertheless, after connecting the appliance, the correct operation of the burners (hob and oven) must be checked. If required, the height of the flame must be adjusted accordingly.

To do this, the gas delivery rate to the burner must be adjusted by screwing in or out the valve adjustment screw located next to the control knob.

This adjustment is essential when changing the gas supply after having changed injectors (refer to Section "CHANGE OF GAS").





WARNING:

The adjustment of burners must be carried out by a qualified technician.


OPERATION:

- ① Open the oven door.
- ② Remove the bottom panel.
- ③ Push down on the control knob and turn it; press simultaneously on the ignition pushbutton.


Once the burner is lit, release the ignition pushbutton.



- ④ Close the oven door.



- ⑤ Leave the oven to warm up for about 10 minutes (thermostat setting 10).





ADJUSTMENT OF THE OVEN BURNER

- ⑥ Turn to low flame (thermostat setting 1).

- ⑦ Open the oven door and check immediately that the height of the flame is low (a few millimetres) and covers slightly the tip of the thermocouple.

In the low flame setting, the height of the flame must be uniform.

- ▶ If in the low flame setting, the flame is too weak and the burner goes off after the release of the control knob, then the gas delivery rate to the burner needs to be increased.
- ▶ If in the low flame setting, the flame is too strong, then the gas delivery rate to the burner needs to be reduced (see below "ADJUSTMENT OF THE FLOW RATE").





ADJUSTMENT OF THE FLOW RATE:

The adjustment of the low flame gas delivery rate is carried out with the burner on and the control knob removed, using a small screwdriver to screw in or out the screw in the gas valve through a hole in the control panel located to the left of the control knob.

- ① Once the burner is on (see instructions ① to ④ above), leave the oven to warm up in setting 10 for 10 minutes.

Turn the control knob to the setting 1.



- ② Open the oven door to check visually the height of the flame.



- ③ Screw in or out the gas valve screw to adjust the delivery rate for the low flame.

Screwing out increases the flame.

Screwing in reduces the flame.



ADJUSTMENT OF THE OVEN BURNER



EN 01-2025

PRIMARY AIR ADJUSTMENT:

The adjustment of the primary air (air-gas mixture) is done by adjusting the air ring. The mixture is correct when the flame is stable with blue cones.


A soft flame with yellow tips is the result of lack of air.

A flame whose base is separated from the burner cap is the result of excessive air.


CAUTION: The adjustment of the air ring is done with the burner off.

To avoid all risks of burns, ensure that all components likely to be handled manually (trays, bottom panel...) and other elements in the working area are not hot.

① Open the oven door.




② Remove the bottom panel.



③ Gain access to the air ring through the two holes located in front of the burner.

④ Make the adjustment.

- Increase the supply of air by pulling the air ring towards the front.
- Reduce the supply of air by pushing the air ring towards the back.



ADJUSTMENT OF THE FLAME SAFETY THERMOCOUPLE:

After the adjustment, when turning on a burner, if it goes off after having kept the control knob pushed down for ten seconds and then releasing, check that:


- The tip of the thermocouple is well covered by the flame and does not touch the burner.

The gap between the thermocouple and the burner is 1 mm.

If the low flame is adjusted lower than the factory setting, it might be necessary to reduce this gap.

Check also:

- The thermocouples and magnetic heads are clean.
- The magnetic head is tightened correctly (moderate torque).



Lacanche's gas appliances are delivered fully adjusted in compliance with relevant regulations and for use with the particular gas supply (type, pressure) stated in the purchase order and indicated in the appliance's nameplate.




The diameter of the injectors are suitable for the power of the burners and the gas supply (refer to **Table 7** in the technical annex).

When changing the type of gas, the injector must be changed (hob and oven burners), and the primary air and the flow rate of the burners must also be adjusted.

CHANGING THE BURNER INJECTORS:

CHANGING THE HOB BURNER INJECTORS:

- ① Open the table (refer to Section "Opening and closure of the gas hob table").
- ② Remove the locknut from the adjusting spigot of the air ring using a 7 mm spanner.
- ③ Lift the air ring by turning the adjusting spigot anticlockwise to gain access to the injector.
- ④ Remove the injector by unscrewing it using a 12 mm spanner.



- ⑤ Replace the seal.
- ⑥ Replace the injector.


Injector diameters depend on the type of gas supply, as shown in **Table 7** in the TECHNICAL ANNEX.

- ⑦ Close the table (refer to Section "Opening and closure of the gas hob table").
- ⑧ Proceed to the adjustment of the burners (refer to Section "Adjustment of the hob burners").
 - ▶ Adjustment of the low flame flow rate.
 - ▶ Adjustment of the primary air.
 - ▶ Adjustment of the thermocouples.
- ⑨ Once adjusted, replace and tighten the locknut.
- ⑩ Reconstitute the sealing of the idle screw, replace the labels indicating the diameter of the injectors, as well as the identification at the connection point of the nature of the gas and its pressure.


CHANGE OF GAS

CHANGING THE OVEN BURNER INJECTOR:


- ① Remove the drawer for access to the connection of the burner under the oven.




- ② Remove the 2 screws.



- ③ Remove the perforated protective box from the burner.




- ④ Using a 7 mm spanner, loosen without removing the nut in the air ring.




- ⑤ Using a 2 mm Allen key, loosen without removing the set screw to release the injector holder.

- ⑥ Remove the injector holder from the burner.


- ⑦ Open the oven door.



- ⑧ Remove the oven bottom panel.



- ⑨ Remove the screw holding the burner with a screwdriver.




CHANGE OF GAS




EN 01-2025

- ⑩ Remove the burner by pulling it towards the front and lifting its back.



- ⑪ Through the opening exposed after the removal of the burner, remove the injector:

- ▶ Using a 16 mm spanner, hold the injector holder.
- ▶ Using a 12 mm spanner, unscrew the injector.



- ⑫ Replace the seal and the injector.

When refitting the injector holder, ensure that it is correctly located at the bottom of the burner.

Check the circuit for leaks.

Adjust the position of the burner to maintain the 2 mm gap between the thermocouple and the burner.

- ⑬ Proceed to the adjustment of the burners (refer to Section “Adjustment of the hob burners”).


- ▶ Adjustment of the low flame flow rate.
- ▶ Adjustment of the primary air.
- ▶ Adjustment of the thermocouples.

- ⑭ Reconstitute the sealing of the idle screw, replace the labels indicating the diameter of the injectors, as well as the identification at the connection point of the nature of the gas and its pressure.


GAS CIRCUIT



For references and descriptions of the various components refer to **table 12** in appendix;



REFERENCE 90000003



The installation must be carried out in accordance with recognised best practices, the instructions given in this manual and the regulations in force in the country of installation.

The means for disconnection must be provided in fixed installations in accordance with all relevant regulations.

BEFORE CONNECTION:






Check that:

-  The mains supply is compatible with the voltage and power of the appliance.
-  The user's fixed installation features an approved main isolating device acting on all phases.

CONNECTION:

- Use a standard flexible cable (245 IEC 57 or 245 IEC 66, or any other cable with the same characteristics).
- The power supply cables between the isolating traction device and the terminals must be of such lengths as to ensure in the event of traction that the live cables become taut before the earth cable.
- If the appliance is permanently connected to a fixed electrical installation, this installation must be fitted with a suitable leakage current protection device.
- If the appliance is connected with a cable fitted with a plug, the socket must be accessible at all times.


- ① Remove the cover(s) from the back of the appliance identified by the label .
- ② Pass the lead through the grommet.
- ③ Connect a standard cable suitable for the voltage to the terminals. (Ensure that the jumper connectors are correctly fitted).



- ④ Set each wire one by one in the power strip and if necessary set the shunt clips.

Tighten each plug separately to the maximum.

- ⑤ Secure the cable with the cable clampe.



It is dangerous to operate the appliance without having it properly earthed.

We cannot be held responsible for accidents due to missing or incorrect earth connection.

WIRING DIAGRAMS




For references and descriptions of the various components refer to **table 11** in appendix;

EN 01-2025

Wiring diagrams Settings	Ceramic hob 4 burners	Ceramic hob 5 burners	Induction hob 3 burners	Induction hob 5 burners	Induction hob 6 burners	Gas oven + burners 3 - 4 - 5 or 6 burners	Electric static oven 76 L	Electric static oven 57 L	Electric multifunction fan 51 L	Electric oven multifunction 68 L	Vertical electric oven multifunction 69 L	Grill oven	Simmer oven	Electric oven multifunction 112 L
Cormatin	A		C			F	G			J				
Rully						F	G			J		L ₁		
Beaune/Bussy					E	F		H			K			
Cluny		B		D		F		H	I			L		
Cluny Grand chef														N
Chagny		B		D		F		H	I					
Volnay/Vougeot		B		D		F	G			J			M	
Chassagne/Chambertin	A		C			F	G			J			M	
Saulieu/Savigny	A		C			F	G			J	K			
Sully	A		C			F	G			J				
Fontenay	A		C			F	G			J			M	
Citeaux	A		C			F	G			J	K		M	


Ceramic hob with 4 burners

A



Ceramic hob with 5 burners

B




WIRING DIAGRAMS



EN 01-2025


Induction hob with 3 burners

C



Induction hob with 5 burners




D



WIRING DIAGRAMS

Induction hob with 6 burners

E




WIRING DIAGRAMS



F

Gas oven + gas burner




Note: Ignition controller terminal lugs not in use are to be grounded.

EN 01-2025


G

Gastro static electric oven




SCE1_055

Static electric oven






Dual function electric convection/static oven



J

[illegible]


INSTALLATION MANUAL



WIRING DIAGRAMS



Electric oven multifunction Cluny Grand Chef



EN 01-2025

RESETTING THE SAFETY THERMOSTAT OF ELECTRIC OVENS



Any servicing or repair work on this appliance must be performed by a qualified engineer.

SAFETY THERMOSTAT OF ELECTRIC OVENS:


In accordance with relevant standards, the safety thermostat is intended for the protection of the appliance against overheating or voltage surges (for instance, lightning).

In the event of overheating, the thermostat is tripped, stopping the operation of the appliance's furnaces.

Because of this, the thermostat can trip unexpectedly when heating the oven for the first time, stopping its operation.

The functions will be automatically restored when the overheating disappears.

Note: ALWAYS INVESTIGATE the original cause of a thermostat trip.



EN 01-2025

Resetting the safety thermostat in the ELECTRIC HOB:

Open the oven / hot cupboard door(s).

Using a flat screwdriver, loosen without removing the two threaded spigots located under the air vent strip at either end.




Pull the table slightly outward.

Lift the table.

Maintain safety by securing the table in the open position with a suitable pro.

The red push button is located behind the air vent strip.



Press the red push button using a screwdriver.




Do not touch any part other than the red button!

INDUCTION HOB:

- ① Turn off the power.
- ② Open the table for access to the regulators. Refer to Section "Opening and closure of the table").
- ③ Disconnect the ribbon cables to the regulator.
- ④ Remove the control knob of the regulator that is to be changed.
- ⑤ Remove the two screws on either side of the control spindle.




- ⑥ Remove and change the regulator.




CHANGING THE INDUCTORS:


- ① Turn off the power.
Open the table for access to the inductors. Refer to Section “Opening and closure of the table”).
- ② Prepare a flat surface covered by clean, smooth and non-abrasive material (blanket, flexible mat, thick fabric) where to put the ceramic glass panel safely and without scratching.
- ③ Lift the table. Refer to Section “Opening and closure of the table”).
- ④ Disconnect the earth cable.
- ⑤ Disconnect the ribbon cables to the regulators.




- ⑥ Disconnect the cables from the terminal connectors located under the table.



- ⑦ Release the table and put it on the previously-prepared surface with the ceramic glass plate face down..




- ⑧ Remove all the screws holding the electronic boxes (use a TORX T10 screwdriver or wrench).




- ⑨ Lift the electronic box whilst holding the glass plate and turn the assembly of glass plate-boxes over.

CAUTION : This is best done by two persons.




- ⑩ Remove the ceramic glass plate.



- ⑪ Remove the screws whilst holding in place the holding bars.

Remove the inductor.

Replace the inductor.



- ⑫ To reassemble, proceed in reverse order ensuring that the inductors are placed correctly.

OPENING AND CLOSURE OF THE GAS HOB TABLE



EN 01-2025




OPENING AND CLOSURE OF THE GAS HOB TABLE

Opening the gas hob table allows access to the components under it.


This procedure is particularly required for:

-  Replacement of burner injectors for a change of gas supply.
-  Adjustment of the position of the safety thermocouple in the burner.
-  Replacement of a control component.

- ① Remove the pan stands and the solid top (for “Tradition” appliances); then remove the caps and bodies of the burners.




- ② Remove the fixing screws located under the burner bodies.




- ③ Two threaded spigots located under the air vent strip at either end hold the stainless steel table fixed to the control panel.

Open the oven / hot cupboard door(s).

Using a flat screwdriver, loosen without removing the two threaded spigots located under the air vent strip at either end.



- ④ Pull the table slightly outward.




OPENING AND CLOSURE OF THE GAS HOB TABLE

⑤ Lift the table.

Maintain safety by securing the table in the open position with a suitable pro.

⑥ To close the table, follow the procedure described above in the reverse order.



OPENING AND CLOSURE OF THE ELECTRIC HOB TABLE



EN 01-2025

OPENING AND CLOSURE OF THE ELECTRIC HOB TABLE


Opening the gas hob table allows access to the components under it.

This procedure is particularly required for replacement of a control component


- ① Two threaded spigots located under the air vent strip at either end hold the stainless steel table fixed to the control panel.

Open the oven / hot cupboard door(s).

Using a flat screwdriver, loosen without removing the two threaded spigots located under the air vent strip at either end.




- ② Pull the table slightly outward.



- ③ Lift the table.

Maintain safety by securing the table in the open position with a suitable prop.



- ④ To close the table, follow the procedure described above in the reverse order.

INSTRUCTION MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

This device is intended for use in domestic and similar applications such as:

- kitchen corners reserved for staff in shops, offices and other professional environments,
- in farms,
- the use by customers of hotels, motels and other residential environments,
- Bed and Breakfast type environments.

Any change of voltage from that for which the appliance is set up must be carried out by a qualified installer.

WARRANTY

The warranty is part of the sale contract. For any warranty work, please contact an authorized reseller. This warranty does not cover damage due to faulty installation, misuse or inadequate maintenance.



Summary

INSTRUCTION MANUAL

WARNINGS	49
GAS HOBS	51
ENAMELLED SOLID TOP	53
CERAMIC HOB	55
INDUCTION HOB 3 AND 5 BURNERS	57
INDUCTION HOB 6 BURNERS	63
RECOMMANDATION BEFORE USING OVENS	69
OVENS	71
ELECTRIC STATIC OVEN	75
CONVECTION ELECTRIC OVEN	77
DUAL FONCTION OVEN	79
GRIL OVEN	83
SIMMER OVEN	85
CLEANING AND MAINTENANCE	87
NOTE CONCERNING THE DISPOSAL OF WASTE ELECTRICAL AND ELECTRICAL EQUIPMENT	91

This appliance has the **CE** marking, which means that it meets all essential requirements of the European directives concerning safety that are applicable to the appliance.

WARNINGS



EN 01-2025

- Before using the appliance, remove all internal and external plastic protections; not doing this risks causing irreversible damage.
- This appliance is not intended for use by disabled persons or children.
- This appliance must not be moved or lifted by the front rail or the doors; doing this risks damaging the enamel finish. It is not advisable to lean on the front rail.
- Never keep flammable products in the oven, in the cupboard, in the drawers, in the plate warmer or on the top surface. Plastic materials and heat-sensitive objects can be damaged.
- Do not hang flammable materials above the appliance.
- During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- This appliance is intended exclusively for cooking food. Do not use the hob or the oven for heating the room.
- When using the hob, do not touch the pan stands and the surrounding areas. The areas surrounding a gas or electric hob are hot and can cause burns. Keep children away from the appliance.
- When using the oven, do not touch the internal surfaces and surrounding areas with unprotected hands.
- Do not cover the hob with aluminium foil.
- Do not obstruct air vents and ducts. Ensure that there is an adequate renewal of the air in the room where the appliance is installed.
- Cut off the gas or the electricity supply to the appliance before starting any servicing or repair work on the appliance. Cut off the supply before replacing the lamp in the oven in order to avoid the risks of electric shock.
- This appliance is not intended to be operated by means of an external timer or a remote control system.
- The cooking process has to be supervised. A short term cooking process has to be supervised continuously.
- Unattended cooking on a hob with fat or oil can be dangerous and may result in a fire.
- The appliance must not be installed behind a decorative door in order to avoid overheating.

WARNINGS

- Children under 8 years old should be kept away from the appliance, unless they are under continuous surveillance.
- This unit can be used by children from 8 years and by people with of physical, sensory or mental capabilities or lack of experience and knowledge provided they have been placed under supervision or they have received instructions for using the machine safely and that understand the dangers. Children should not play with the appliance. The cleaning and maintenance by the user should not be performed by children without surveillance.
- Use only Cooktop protection devices designed by the Cooking appliance manufacturer or specified by the device manufacturer in instructions as appropriate or not appropriate guards can lead to accidents.
- Ceramic tables: If a crack in the surface appears visible, disconnect the device immediately from the power source to prevent a shock electric. Notify your installer.
- Avoid contact jewelery (ring, bracelet, ...) and any accessory metal cooking (forks, lids, knives...) with the cooking surface operation, there is a risk of overheating.

Restrictions of use:

- **CAUTION:** The use of a gas cooking appliance leads to the production of heat, moisture and combustion by-products in the room where it is installed. Ensure that the kitchen is well ventilated, especially when using the appliance: keep the natural ventilation openings open, or install a mechanical ventilation device (mechanical ventilation hood).
- Intensive and prolonged use of the appliance may require additional ventilation, for example by opening a window, or more efficient ventilation, for example by increasing the power of the mechanical ventilation if it exists.

CAUTION: This appliance is for cooking purposes only. It must not be used for other purposes, for example space heating.

Glass hobs (induction or vitroceramic):

CAUTION: In case of broken glass on the hob:

- Immediately turn off all burners and all heating elements and isolate the appliance from all sources of energy.
- Do not touch the surface of the device.
- Do not use the device.
- Do not use kitchen containers that protrude from the work table.
- The minimum diameter of the receptacles that can be placed on each inducer is 130 mm and 280 mm maximum.
- **Caution:** In case of fan fault, the device must be switched off. Contact a qualified person to perform the procedure.

Highly valued by chefs because of their fast heating and ease of use, gas flame burners have always been traditional heat sources for cooking in large kitchens. Other heat sources have appeared in recent years but just as many users still prefer gas. It offers many advantages; gas provides a fast increase in temperature. The height of the flame can be checked easily at a glance in order to increase or reduce its power. Accessories such as wok rings and simmer & griddle plates may be used over gas burners.

Lacanche gas hobs for cook's stoves are fitted with burners of different power. These automatically stabilised flame burners offer a very low slow setting to facilitate simmering or high heat for quick sealing. Depending on their rating, they are suitable for various types of utensils.

Semi fast burner:

is recommended for small sauceboats, small saucepans or blini pans for example.

A trivet can be placed on the pan support to provide greater stability for smaller pans.

Fast and intensive burners:

are ideal for shallow frying pans, saucepans and cooking pots. Their high output provides very fast increases in temperature and very flexible use.

Ultra fast burner:

is a high-power burner. It is especially recommended when using large pans and woks for dishes that have to be sealed quickly (fricassees, fritters, grilled meat).


You will quickly learn how to use the various types of burners to achieve optimum cooking.

Description:

The burners are arranged on a stainless steel hob in various configurations depending on the model (See Figures below). Each burner is fitted with a thermocouple safety cut-out.

This device switches off the gas supply if the flame is accidentally extinguished.

The various types of burners can be identified by their respective diameter.



Désignation		Diameter of the burner cap	Power
Ultra fast	A	Ø 107 mm	5 kW
Intensive	B	Ø 90 mm	4 kW
Fast	C	Ø 72 mm	3 kW
Semi fast	D	Ø 55 mm	1,5 kW

Use:




Simultaneously press in and turn the burner dial anti-clockwise to setting «».

Press the ignition button while maintaining pressure on burner dial for about 20 seconds to ignite burner and initialise safety thermocouple.


When the burner is lit, release the knob.

Turn the knob to the desired power.

Release the knob.




A reduced flowrate position identified by the «» mark produces the preset minimum burner power (low flame).



To turn off, turn the control knob clockwise to the «» position.

The control knob returns to its initial position, the latching mechanism operates and the gas safety cut-out is activated several seconds after the burner goes out.



Useful hint

Always choose a burner that matches the diameter of the utensil used.

CAUTION: During use of the cooking surface, accessible parts may become very hot during use. Warn users of the potential risks.

ENAMELLED SOLID TOP



EN 01-2025

The solid top features a cast iron plate with an enamel finish heated by a powerful gas burner. It provides a working surface with room for several pans at the same time.

Thanks to its cast iron material that absorbs and keeps the heat evenly over its entire surface, the dishes can be simmering slowly or cooking faster depending on the selected temperature.

By removing the central plate, the burner can be used as a conventional open burner.

“TRADITION” gas hobs are equipped with a solid top .


Description:

The solid top is made of cast iron with an enamel finish.

The size of the solid top is 511 x 386 mm.

It is made up of two parts; the main plate rests on the hob table, and in its centre is the smaller removable plate.

Heating is provided by an ultra-fast burner.



Description		Burner cap diameter	Power
Ultra-fast		Ø 107 mm	5 kW

CAUTION: The temperature can reach more than 300°C. Advise potential users of the risks that can be encountered.

ENAMELLED SOLID TOP



Use:

Push down on the control knob and turn it anticlockwise to the maximum setting indicated by the large flame «», symbol; press simultaneously on the ignition pushbutton.

Keep the control knob down for about ten seconds in order to engage the safety thermocouple.

Once the burner is lit, release the ignition pushbutton.



Turn control knob to the required setting.
Release the control knob.



The low flame setting indicated by the «» symbol delivers the pre-set minimum power from the burner.


To turn off, turn the control knob clockwise to the «» setting.

The control knob is now back to its initial position, with the mechanical lock engaged; the gas safety remains active for several seconds after the burner has been turned off.



Open burner:

The solid top can be used as an open burner by removing the central plate. This enables cooking in direct contact with the flame.



IMPORTANT: Do not clean the plate whilst with water; doing this could damage it.

CAUTION: During use of the hob or the oven, all accessible parts can become very hot. Advise potential users of the risks that can be encountered.

Ceramic hobs are a recent development in the technologies applied to cooking. The principle, a relatively simple one, is based on a heating source, generally an electrical element, placed under a ceramic glass plate which is resistant to high temperatures.

The heating element transmits the heat in the form of infrared radiation through the glass, heating the bottom of the cooking vessel above. The area of the plate untouched by the radiation remains cold.

These radiant elements allow very fast temperature rise and adjustment because of their low inertia.

This feature will be appreciated for all those dishes that require rapid changes of heat during cooking.

The flatness of the ceramic glass plate offers good stability, which avoids the risks from knocking over some cooking vessels. The maintenance of ceramic hobs is also very simple.

Description:


The ceramic hob version features a strong ceramic glass plate of 6 mm thickness equipped, depending on the model, with :

- Two single radiant heaters, 210 mm diameter and 2.1 kW power **A**.
- Two double radiant heaters, 140/210 mm diameter and 1.0/2.1 kW power **B**.
- One central oval burner and 2.2 kW power **C**.

The single radiant heater is controlled by means of a 6-position switch.

The double radiant heater comprises a 1.1 kW inside circuit controlled by an energy regulator, and a 1.0 kW outside circuit controlled by an additional switch.

Note: Each radiant heater features a residual heat indicator. The indicator light is switched on a few seconds after turning on the radiant heater, and is switched off when the heat in the radiant zone has come back down below a value (approximately 70°C) that does not represent a risk of personal injury.



Specification		Diameter / Size	Power
Single	A	Ø 210 mm	2.1 kW
Double	B	Ø 140/210 mm	1.0/2.1 kW
Oval	C	170/265 mm	2.2 kW

Use:

Select the control knob for the chosen radiant heater; the adjacent indicator light is switched on.

Single heater:

Depending on quantity, start cooking at setting 6, and reduce to a lower setting depending on the type of cooking.

As reference, recommended settings:

- 1 & 2 = Hold or reheat prepared dishes.
- 3 & 4 = Simmer or steady cooking.
- 5 & 6 = Seal the food.



Double heater:

Set the control knob at setting 10; when the heater starts to radiate, turn to the setting required for the dish being prepared.

For maximum power from the double heater, turn the control knob to MAXI.

For total control of this heater, turn back (settings 1 to 10).

To switch off the additional radiant element, turn back to setting 0.



Advice:

Use cooking vessels with flat and smooth bottom to avoid scratching the glass plate.

Choose a size of vessel suited to the needs. The bottom diameter of the vessel must be the same as or slightly larger than the marking printed on the glass plate.

☒ Do not leave an empty enamelled or aluminium vessel on a heater.

Do not leave packaging material over aluminium directly on the glass plate; this could cause permanent damage to the appliance.

☒ Avoid spilling sugar or syrup; remove them immediately if they occur, otherwise they could cause small bursts with projections of particles.

Do not use any more power than can be absorbed by the food being prepared; too much heat causes loss of water and fat, as well as waste of energy.

Use the lid during cooking whenever directed by the recipe; you will save energy.

Consider turning the control knob to setting «O» just before the end of cooking; cooking will be completed by the heat already accumulated.

INDUCTION HOB 3 AND 5 BURNERS



EN 01-2025

The vitro-ceramic covered induction hotplate is a revolutionary piece of cooking equipment.

An induction ring or zone consists of an induction unit placed underneath a vitro-ceramic hob top. The unit is powered by means of a high-frequency AC current.

Energy is transmitted electromagnetically to the cookware on the hob top.

This magnetic field passes through the cooking surface into the bottom of your pans.

THE INDUCTION HOB IS USED EXACTLY LIKE CAST-IRON OR STANDARD VITRO-CERAMIC HOBS. THE DIFFERENCES ARE AS FOLLOWS:

- During cooking heat is generated inside the pans. The ceramic hob gets hot only as heat is reflected by the pans. It is not directly heated by induction.
- The induction unit only operates if there is contact between the induction zone and the pan in the cooking zone.
- Reaction to adjustments is immediate, enabling the temperature to be changed quickly and accurately.
- Maintenance of induction plate is easy, because in case of accidental overflow, the Food does not burn on the surface of upper cooking than the screen printing of the plate.

☞ Induction hobs require compatible tools, ie ferromagnetic (enameled sheet metal, cast iron, ferritic stainless steel).


Containers made of glass, terracotta, aluminum or stainless steel without a magnetic base can not be used on induction hobs.

Some pans may make noise when placed on an induction cooking zone. These noises do not translate into any fault of the device and have no influence on its operation


DESCRIPTION:

The induction hob version comprises a 4 mm thick vitroceramic plate equipped, according to the model, with the following.

3 burners hob



5 burners hob



Tag	Diameter/Size	Power	Booster
A	Ø 270 mm	2.6 kW	3.7 kW
B	Ø 200 mm	1.85 kW	3.0 kW
C	Ø 180 mm	1.85 kW	3.0 kW
D	Ø 145 mm	1.85 kW	3.0 kW

INDUCTION HOB 3 AND 5 BURNERS

Induction unit are fitted with:

- A control rotary encoder located on the control panel.
- An electronic display of the power of selection on the ceramic hob.
- An indicator of residual heat of the glass ceramic (Displaying the message «HOT»). This indicator blinks a few times after powering the corresponding burner and turns off when the heat of the area of the home in question has fallen below about 60 ° c.
- A tangential fan under the table to allow cooling of the components.

USE:


Place food in pan.

Turn the control knob of the ring required (clockwise).

The power level is set on the display.

La mise en chauffe étant très rapide, sélectionner directement la position souhaitée.

A titre indicatif, les différentes positions correspondent aux utilisations mentionnées dans le tableau ci-dessous :

Positions	Utilisation	
1 & 2	Keeping food warm or preparing sauces.	
3 & 4	Gentle simmer or maintain cooking	
5 & 6	Sustained simmer or cooking pasta or rice once water has boiled.	
7	Frying.	
8	Browning or seizing meat.	
9	Bring to or maintain rolling boil.	
P	Booster = Brings liquid to boil quickly.	
R	Potency level 9 during time to reach the temperature of the level preset then commutes automatically at the level of potency chosen.	
U	Assertion in temperature (42°C).	
U	Assertion in temperature (70°C).	

While in use, if the pan is removed from the cooking zone, the power is cut automatically, the symbol  is displayed. To stop this symbol, you have to cut the burner supply by positioning the knob to 0. Prior to this decision, if the pan is repositioned on the burner, the power automatically restarts.



The display shows the letter .

INDUCTION HOB 3 AND 5 BURNERS



EN 01-2025


BOOSTER FUNCTION:

The «Booster» can speed the rise of power of the induction burner.

It is controlled by positioning the lever on the landmark P. During 10 minutes, the maximum power of the burner is obtained.



The display shows the letter P.



After 10 minutes, the power is reset to level 9.



The display shows the number 9.

Note:

In case of simultaneous operation of dual induction burners, (Front / Rear), the Booster function can only be achieved on only one of the selected burners. The Booster function remains active on the last selected burner.


ACCELERATOR FUNCTION:

The Accelerator function allows to be on level 9 for a few minutes then switch automatically back to the level of the selected power.


To use the accelerator function: from the position 0, turn the knob on the left (slight turn to the left).



The display shows the letter A.



Set the knob to the desired power level.




Selected power level	8	7	6	5	4	3	2
Acceleration duration	3 min. 40	2 min. 50	2 min.	6 min. 50	5 min.	4 min.	2 min. 30


INDUCTION HOB 3 AND 5 BURNERS

ACTIVATING THE CHILD SAFETY FUNCTION:

Single heater : Replace the knobs to zero, turn the knob of the burner anti-clockwise and hold in this position until activation (2 seconds approximately) This feature is symbolized by an **L** display.




Double heaters : Turn the two right induction control knobs anti-clockwise and hold in this position for a couple of seconds to activate of child security function (signalled by the letter **L**). The child safety function is now active for the two right induction rings. If the control knobs for the two right zones are now turned, nothing will happen.




DEACTIVATE CHILD SAFETY:

Single heater : Repeating the process described above to a zone which has been made safe, will re-activate the zone and the letter **L** will go out.



Double heaters : To deactivate the child safety, turn the two handles of both burners in the anti-clockwise and hold it until the deactivation of the child safety function.

The letter **L** will go out.



OVER HEATING CUT OUT:

In case of overheating, the system will trip and render the burner inoperative.

In that case:

- Reset the controller of the burner in question to 0.
- Remove the pan from burner.
- Wait for the burner to cool before re-use.

RECOMMENDATIONS:

- Heating is extremely fast.
- We advise you to keep a careful eye on your dishes until you are familiar with to induction cooking.
- Never leave oil or other greases to heat unattended.
- We recommend for maximum efficiency of the induction hob to match the diameter of the cookware to the diameter of the circle printed on the glass-ceramic surface, particularly when using small ring. When using a cookware of larger diameter than the printed zone, offset the cookware towards the rear of the printed circle.
- We advise against the use of cookware without a fully flat bottom; some pans have engravings, wich may decrease efficiency.
- Disregarding these precautions may decrease the efficiency of your induction hob.
- Your food will not cook efficiently unless your pan is ferromagnetic and in direct contact with the selected induction zone Ferromagnetic means iron/ steel cookware check to see if a magnet sticks to it.
- Avoid scratching the cooking surface with metallic or abrasive objects.
- If you remove a pan from the cooking zone for a moment the display flashes. It is advisable to turn off the power.
- If the pan is repositioned on the zone, power restarts automatically at the same level and the flashing ceases.
-  Never place or leave enamelled, aluminium or any other type of empty pan on a heating zone. Similarly you should not place aluminium-packed products/ tin fail directly on the surface; this can do irreparable damage to your cooker.
-  Do not place unopened tins directly on a hotplate as this could cause them to explode under pressure.
-  Never obstruct ventilation zones (front panel, rear ventilation, etc.). The cooker may overheat and become less efficient. Furthermore you shorten the service life of your hob.
-  Do not store aerosols or flammable products under the cooking surface.
- Use a magnet to check that your pans are ferromagnetic. If they stick to the magnet, you can use them on induction hotplates.
- Do not hang heavy items over the cooking surface. They can damage the vitro-ceramic surface if they fall.
- Never apply more heat than can be absorbed by the food: too much heat causes loss of water, grease and wastes energy.
- Whenever the recipe permits, cover your cookware with a lid in order to save energy.

SAFETY:

- The latest scientific research has found that people fitted with a heart pacemaker are not at risk from using induction cookers. However, if an induction cooker is used improperly a slight risk cannot be ruled out.
- It is for this reason that we advise people with pacemakers to consult their physician before using an induction cooker.
- Avoid all contact between jewellery (rings, chains, etc.) and the cooking surface while it is switched on; it could cause jewellery to heat.

CAUTION:

- **If a visible crack appears in the vitro-ceramic surface of your hob, immediately disconnect the power supply and contact your installer.**

DISPLAY:

E	The sensor for a particular hotplate is not working.	The rest of the surface can nevertheless continue functioning correctly – Contact your retailer
Hot	Residual temperature	Indicates that the zone is hot – The display goes out when the temp has dropped below 60°C
U	Pan undetected	No pan or pans unsuitable for induction cooking
U	Temperature hold : 70 °C	-
U	Temperature hold : 42 °C	-
P	Booster function	This function is only available on hotplates A and B.
L	Child safety function	This function is activated and deactivated by holding the knob in position "A".
⌋	Fault detected in the induction system	This function is activated and deactivated by holding the knob in position "A". Check the control encoder connectors. Check the connection to the encoders and inductors and for any damaged or cut wires.

IF THE INDUCTION COOKER DOES NOT WORK:

- Check your pans.
- First switch off the cooker. Then check ventilation of the generator
- First switch off the cooker. Then check the power supply and electrical connectors.

INDUCTION HOB 6 BURNERS



EN 01-2025

Only concerns the Beaune and Bussy ranges.

The vitro-ceramic covered induction hotplate is a revolutionary piece of cooking equipment.

An induction ring or zone consists of an induction unit placed underneath a vitro-ceramic hob top. The unit is powered by means of a high-frequency AC current.

Energy is transmitted electromagnetically to the cookware on the hob top.

This magnetic field passes through the cooking surface into the bottom of your pans.

THE INDUCTION HOB IS USED EXACTLY LIKE CAST-IRON OR STANDARD VITRO-CERAMIC HOBS. THE DIFFERENCES ARE AS FOLLOWS:

- During cooking heat is generated inside the pans. The ceramic hob gets hot only as heat is reflected by the pans. It is not directly heated by induction.
- The induction unit only operates if there is contact between the induction zone and the pan in the cooking zone.
- Reaction to adjustments is immediate, enabling the temperature to be changed quickly and accurately.
- Maintenance of induction plate is easy, because in case of accidental overflow, the Food does not burn on the surface of upper cooking than the screen printing of the plate.

☞ Induction hobs require compatible tools, ie ferromagnetic (enameled sheet metal, cast iron, ferritic stainless steel).


Containers made of glass, terracotta, aluminum or stainless steel without a magnetic base can not be used on induction hobs.

Some pans may make noise when placed on an induction cooking zone. These noises do not translate into any fault of the device and have no influence on its operation

DESCRIPTION:

The induction hob version comprises a 4 mm thick vitroceramic plate equipped, according to the model, with the following.

6 burners hob



Tag	Diameter/Size	Power	Booster
E	Ø 215 mm	2300 W	3000 W
F	Ø 175 mm	1100 W	1400 W
G	Ø 200 mm	1400 W	2000 W

INDUCTION HOB 6 BURNERS

Induction unit are fitted with:

- A control rotary encoder located on the control panel.
- An electronic display of the power of selection on the ceramic hob.
- An indicator of residual heat of the glass ceramic (Displaying the message «HOT»). This indicator blinks a few times after powering the corresponding burner and turns off when the heat of the area of the home in question has fallen below about 60 ° c.
- A tangential fan under the table to allow cooling of the components.

USE:


Place food in pan.

Turn the control knob of the ring required (clockwise).

The power level is set on the display.

La mise en chauffe étant très rapide, sélectionner directement la position souhaitée.

A titre indicatif, les différentes positions correspondent aux utilisations mentionnées dans le tableau ci-dessous :

Positions	Utilisation	
1 & 2	Keeping food warm or preparing sauces.	
3 & 4	Gentle simmer or maintain cooking	
5 & 6	Sustained simmer or cooking pasta or rice once water has boiled.	
7	Frying.	
8	Browning or seizing meat.	
9	Bring to or maintain rolling boil.	
P	Booster = Brings liquid to boil quickly.	
R	Potency level 9 during time to reach the temperature of the level preset then commutes automatically at the level of potency chosen.	

INDUCTION HOB 6 BURNERS



EN 01-2025


BOOSTER FUNCTION:

The «Booster» can speed the rise of power of the induction burner.

It is controlled by positioning the lever on the landmark P. During 10 minutes, the maximum power of the burner is obtained.



The display shows the letter P.



After 10 minutes, the power is reset to level 9.



The display shows the number 9.

Note:

In case of simultaneous operation of dual induction burners, (Front / Rear), the Booster function can only be achieved on only one of the selected burners. The Booster function remains active on the last selected burner.


ACCELERATOR FUNCTION:

The Accelerator function allows to be on level 9 for a few minutes then switch automatically back to the level of the selected power.


To use the accelerator function: from the position 0, turn the knob on the left (slight turn to the left).



The display shows the letter A.



Set the knob to the desired power level.



Selected power level	8	7	6	5	4	3	2
Acceleration duration	3 min. 40	2 min. 50	2 min.	6 min. 50	5 min.	4 min.	2 min. 30

CHILD SAFETY FUNCTION:



The child safety function can be activated by simultaneously turning the two control knobs of the 2 left fireplaces to the left. Stay in this position for 2 seconds. The display shows «L» when activating the function.

To disable the function, perform the same operations as for activation.

After unlocking the safety function, you must return the knobs to position **0**.

RECOMMENDATIONS:

- Heating is extremely fast.
- We advise you to keep a careful eye on your dishes until you are familiar with to induction cooking.
- Never leave oil or other greases to heat unattended.
- We recommend for maximum efficiency of the induction hob to match the diameter of the cookware to the diameter of the circle printed on the glass-ceramic surface, particularly when using small ring. When using a cookware of larger diameter than the printed zone, offset the cookware towards the rear of the printed circle.
- We advise against the use of cookware without a fully flat bottom; some pans have engravings, wich may decrease efficiency.
- Disregarding these precautions may decrease the efficiency of your induction hob.
- Your food will not cook efficiently unless your pan is ferromagnetic and in direct contact with the selected induction zone Ferromagnetic means iron/ steel cookware check to see if a magnet sticks to it.
- Avoid scratching the cooking surface with metallic or abrasive objects.
- If you remove a pan from the cooking zone for a moment the display flashes. It is advisable to turn off the power.
- If the pan is repositioned on the zone, power restarts automatically at the same level and the flashing ceases.
-  Never place or leave enamelled, aluminium or any other type of empty pan on a heating zone. Similarly you should not place aluminium-packed products/ tin fail directly on the surface; this can do irreparable damage to your cooker.
-  Do not place unopened tins directly on a hotplate as this could cause them to explode under pressure.
-  Never obstruct ventilation zones (front panel, rear ventilation, etc.). The cooker may overheat and become less efficient. Furthermore you shorten the service life of your hob.
-  Do not store aerosols or flammable products under the cooking surface.
- Use a magnet to check that your pans are ferromagnetic. If they stick to the magnet, you can use them on induction hotplates.
- Do not hang heavy items over the cooking surface. They can damage the vitro-ceramic surface if they fall.
- Never apply more heat than can be absorbed by the food: too much heat causes loss of water, grease and wastes energy.
- Whenever the recipe permits, cover your cookware with a lid in order to save energy.

SAFETY:

- The latest scientific research has found that people fitted with a heart pacemaker are not at risk from using induction cookers. However, if an induction cooker is used improperly a slight risk cannot be ruled out.
- It is for this reason that we advise people with pacemakers to consult their physician before using an induction cooker.
- Avoid all contact between jewellery (rings, chains, etc.) and the cooking surface while it is switched on; it could cause jewellery to heat.

CAUTION:

- **If a visible crack appears in the vitro-ceramic surface of your hob, immediately disconnect the power supply and contact your installer.**

DISPLAY:

E	The sensor for a particular hotplate is not working.	The rest of the surface can nevertheless continue functioning correctly – Contact your retailer
Hot	Residual temperature	Indicates that the zone is hot – The display goes out when the temp has dropped below 60°C
U	Pan undetected	No pan or pans unsuitable for induction cooking
P	Booster function	This function is only available on hotplates A and B.
L	Child safety function	This function is activated and deactivated by holding the knob in position "A".
⌋	Fault detected in the induction system	This function is activated and deactivated by holding the knob in position "A". Check the control encoder connectors. Check the connection to the encoders and inductors and for any damaged or cut wires.

IF THE INDUCTION COOKER DOES NOT WORK:

- Check your pans.
- First switch off the cooker. Then check ventilation of the generator
- First switch off the cooker. Then check the power supply and electrical connectors.

If a malfunction is found, the entire table must be removed for replacement.

RECOMMENDATIONS BEFORE USING OVENS



Designed to help you enjoy the best performance from your ovens.

To ensure you use the oven under optimal conditions and to its best advantage please read the following recommendations which will undoubtedly improve your understanding of the principles of oven cooking.

An oven cooks and heats by using a heat source which is generally located inside the oven. This heat source heats the air and then the entire oven. The food therefore cooks thanks to the heat given off by the heating elements but also thanks to heat radiated from the oven walls.

A few preliminary recommendations:

Before using the oven for the first time, heat it while empty to the 220°C position on the thermostat for approximately 2 hours to heat the rockwool oven insulation and burn off the grease used in the manufacturing process. All odours and smoke will disappear when the oven has been used a few times.

Oven dishes:

The material of which cookware is made influences cooking due to its thickness, ability to transmit heat and its colour.

- ✧ Aluminium, earthenware and aluminium with a non-stick coating reduce cooking and underside browning. These materials are recommended for cooking cakes and roasts.
- ✧ Enamelled cast iron, anodised aluminium, tin-plated iron, ovenproof glass, heat-resistant porcelain and aluminium with a non-stick coating and coloured exterior increase underside browning. These materials are recommended in particular for open tarts, quiches and all crispy preparations that must be browned on the underside as well as on the top.

Cooking recommendations:

We advise you:

- ☞ Pre-heat the oven for 10 to 12 minutes depending on the setting selected before placing your dish in the oven.
- ☞ When placing the dish in the oven, make sure that it is not too close to the oven walls in order to prevent the edges of dishes being exposed to excessive radiated heat.
- ☞ Not to place dishes directly on the floor of the oven or to cook meat directly in the dripping pan.
- ☞ Never cook the pieces directly on the oven floor or on the racks.
- ☞ To use dishes that retain considerable heat (earthenware or enamelled cast iron) with high sides, whose use is for meat to be roasted and to turn red meat over half way through cooking to prevent smoke from the grease that is given off when meat is cooked.
- ☞ Place the drip tray at the bottom of the oven in order to collect any spillages when cooking fruit tarts.

Using the grill on electric ovens:

CAUTION: the grill cooks very quickly, always keep an eye on the food you are cooking.

- ☞ Lightly oil the surface of meat and fish before placing them on the sliding grid.
- ☞ Only place and use the drip tray under the oven rack in order to collect cooking juices and prevent spillages in the case of cheese dish.
- ☞ The grill is either on or off. You do not change its temperature. To adjust the speed of cooking or grilling, change the level of the food in the oven raising it closer to or further from the grill as required.
- ☞ Keep oven door closed when using in grill mode, except to check food cooking.

Using these tips, we recommend that you try cooking some simple & different dishes to help you get the feel of your oven.

RECOMMENDATIONS BEFORE USING OVENS

Gas ovens:

 Security on ignition:

When switching on, the oven control knob must not be operated for more than 15 seconds. If at the end of these 15 seconds the burner has not ignited, stop acting on the device, open the door of the oven to ventilate the gas and wait at least 1 minute before attempting to re-ignite the burner.

 Accidental extinction:


In the event of an accidental flame-out of the oven burner, shut-off the burner using the control knob and do not try to light the burner again for at least 1 min.

 Malfunction of the thermostat:


The thermostat needs to be checked and verified in case its malfunction causes an abnormal temperature change of the oven.

To remove the oven rack:

① Pull the rack toward you.




② Lift the rack to disengage the rack support.



Removal of the rack supports:

Untighten the knob screws.

Disengage the racks by lifting them upward.



The gas oven is a high-performance oven. In the opinion of chefs who are unconditional supporters, the gas oven does not dry the dish during cooking. The results are excellent, with more economical energy consumption!

The gas oven is suited to long cooking for instance, for dishes prepared in earthenware (terrines, gratins, ragouts...), but also for meats requiring short cooking and sealing (loin of lamb), or even roasts that do not crust and remain really tender.

Moreover, the gas oven allows to cooking dishes that require the "bottom-up" (1) effect. For dishes requiring a dry atmosphere or very low temperatures (below 150°C) such as meringues and some pasties, we recommend electric ovens.

(1) The "bottom-up" effect is achieved by the heat emanating from the bottom part of the oven, which in the gas oven is where the source of heat is located. This "bottom-up" effect is recommended, for instance, for baking fruit tarts, quiches, etc.

Description:

Built with steel plate that has been stove enamelled at 850°C for corrosion resistance, the gas ovens feature runner slots at three levels with 70 mm pitch distance between them that allow easy sliding for oven trays.

The oven burner is controlled by means of a thermostatic valve. Safety is provided by a thermocouple that ensures the interruption of the gas supply to the thermostatic valve in the event of the flame in the burner dying off unexpectedly.

The large size of the oven burner ensures that the oven bottom panel is evenly heated.

The gas oven is supplied as standard with a grid shelf and a roasting pan.

Important note for Cluny Grand Chef models:

Due to its large size, the gas oven of the Cluny Grand Chef model is equipped with 2 independent heating elements (burners), 2 thermostats and 2 separate ignition systems.

Each heating element must be ignited separately using the corresponding knob (right or left) and following the gas oven ignition method described below.

Therefore, thanks to its design with independent burners, the gas oven of the Cluny Grand Chef model can operate using only one of the two heating elements (right or left) or both (right and left).

Each burner can be adjusted independently, which gives this oven a flexible cooking capacity in its width.

If a uniform temperature is desired throughout the cavity, both thermostats (right and left) should be set to the same temperature.




Use:

Open the oven door.

Push down on the control knob and turn it to the setting **10**; press simultaneously on the ignition pushbutton.

Once the burner is lit, release the ignition pushbutton.

Keep the control knob down for about ten seconds in order to engage the safety thermocouple.



Release the control knob.

Turn control knob to the required setting.

WARNING:



During the operation of the oven, all accessible parts can become very hot. Keep children away at a safe distance. Handle pan and shelves with caution.

The air and heat dissipation vents must not be obstructed or covered.

Do not keep flammable products in the pan storage drawer.

Usage tips:


The flame in our gas ovens never stops, it simply reduces to a minimum when the oven reaches the desired temperature, and increases again when the temperature drops.

This is a system that works great when the oven is loaded.

When empty, the temperature tends to rise slowly as the oven remains on, and after several hours the temperature may rise a few tens of degrees.

You must therefore make sure to open the oven every 1½ hours of cooking to restore the initial temperature and do not hesitate to lower the thermostat after 1 hour of cooking if the oven has not been opened.

THERMOSTATIC FLAME CONTROL



Temperatures given as reference only after 10 minutes of empty oven use.

Setting	Gas oven temperature (°C)
1	100 °C
2	110 °C
3	120 °C
4	140 °C
5	160 °C
6	180 °C
7	200 °C
8	220 °C
9	240 °C
10	270 °C

GAS OVEN



Settings	52 L - 3.5 kW W.414 x H.288 x D.438	70 L - 4 kW W.550 x H.288 x D.438	117 L - 7 kW W.880 x H.305 x D.455
Cormatin		●	
Rully			
Beaune/Bussy	●		
Cluny	●		
Cluny Grand Chef			●
Chagny	●		
Volnay/Vougeot		●	
Chassagne/ Chambertin		●	
Saulieu/Savigny		●	
Cluny 1400	●		
Cluny Grand Chef 1400			●
Chagny 1400	●		
Sully		●	
Fontenay		●	
Citeaux		●	
Cluny 1800	●		
Cluny Grand Chef 1800			●
Chagny 1800	●		
Sully 1800		●	
Sully 2200		●	

EN 01-2025

ELECTRIC STATIC OVEN



EN 01-2025

The electric oven is simple to use and offers very good conditions for cooking the most common dishes.

Equipped with three heating elements, the electric oven can be used as an oven or as grill.

The electric oven is particularly recommended for all types of dishes, and is more especially suited for pastries such as almond tuiles, genoise sponges, etc.

Description:

Built with steel plate that has been stove enamelled at 850°C for corrosion resistance, the ovens feature runner slots at three levels with 70 mm pitch distance between them that allow easy sliding for oven trays.

The electric oven is supplied as standard with a grid shelf and a roasting pan.

The heating for the oven is provided by heating element at the base and a peripheral element at the top, both operating simultaneously.

For the grill there is a central element at the top.

The heating elements are controlled thermostatic switch.


In the electric oven version, the control panel features two indicator lights:

- Indicator light **A** indicates that one of the heating elements is in operation mode.
- Indicator light **B** indicates the state of the heating element in operation mode.

Operation:


The oven must be pre-heated at the thermostat setting required for cooking.

Turn the thermostatic control knob clockwise to the required setting.



Indicator lights **A** and **B**, are switched on. When indicator light **B** is switched off, the selected temperature has been reached and you can then put your dish in the oven.

To stop the oven, turn the thermostatic control knob anticlockwise to the setting "0".




Electric grill:

The electric oven is equipped with a grill which can grill meats as well as a wide range of different dishes.

It is the ideal equipment to finish, for instance, crèmes brûlées or the perfect rib of beef.

Operation:

Turn the thermostatic control knob to the grill symbol . To turn off, turn the control knob anti-clockwise to the 0 position.



ELECTRIC STATIC OVEN

Settings	56 L - 2.2 kW W.414 x H.291 x D.465	76 L - 2.9 kW W.550 x H.291 x D.465
Cormatin		●
Rully		●
Beaune/Bussy	●	
Cluny	●	
Chagny	●	
Volnay/Vougeot		●
Chassagne/Chambertin		●
Saulieu/Savigny		●
Cluny 1400	●	
Chagny 1400	●	
Sully		●
Fontenay		●
Citeaux		●
Cluny 1800	●	
Chagny 1800	●	
Sully 1800		●
Sully 2200		●

CONVECTION ELECTRIC OVEN



EN 01-2025

The electric oven is simple to use and offers very good conditions for cooking the most common dishes.

Equipped with three heating elements, the electric oven can be used as an oven or as grill.

The electric oven is particularly recommended for all types of dishes, and is more especially suited for pastries such as almond tuiles, genoise sponges, etc.

Description:

Built with steel plate that has been stove enamelled at 850°C for corrosion resistance, the ovens feature runner slots at three levels with 70 mm pitch distance between them that allow easy sliding for oven trays.

The electric oven is supplied as standard with a grid shelf and a roasting pan.

The heating for the oven is provided by a heating element at the base and a peripheral element at the top, both operating simultaneously.

For the grill there is a central element at the top.

The heating elements are controlled thermostatic switch..

In the electric oven version, the control panel features two indicator lights:

- Indicator light **A** indicates that one of the heating elements is in operation mode.
- Indicator light **B** indicates the state of the heating element in operation mode.

Operation:

The oven must be pre-heated at the thermostat setting required for cooking.

Turn the thermostatic control knob clockwise to the required setting.

Indicator lights **A** and **B**, are switched on. When indicator light **B** is switched off, the selected temperature has been reached and you can then put your dish in the oven.

To stop the oven, turn the thermostatic control knob anticlockwise to the setting "0".




Electric grill:

The electric oven is equipped with a grill which can grill meats as well as a wide range of different dishes.

It is the ideal equipment to finish, for instance, crèmes brûlées or the perfect rib of beef.

Operation:

Turn the thermostatic control knob to the grill symbol . To turn off, turn the control knob anti-clockwise to the 0 position.





CONVECTION ELECTRIC OVEN

Note: During operation of the grill, the turbine remains on.

Usage tips:

In the case of simultaneous cooking, pastries are preferably placed on the top rack, above the other items to cook.

Moreover, it appears that cooking in a convection oven is carried out at lower temperatures than in a conventional oven. Consider reducing the heating temperature.

Settings	51 L - 2.65 kW W.414 x H.291 x D.417
Cluny	●
Chagny	●
Cluny 1400	●
Chagny 1400	●
Cluny 1800	●
Chagny 1800	●

DUAL FUNCTION ELECTRIC OVEN



EN 01-2025

This oven has two functions: one to set the “Static Electric Oven” mode, and one to set the “Electric Convection Oven” mode.

- Static electric oven function:

Electric ovens are simple to use and are ideal for cooking all usual dishes.

The electric oven has three heating elements and can be used as both an oven and a grill.

The static electric oven is specially recommended for dry pastries such as almond biscuits, Genoese sponges, etc.

The heating elements consist of a element at the base and a peripheral element in the roof which operate simultaneously.

- Function oven with forced convection:

The forced convection oven is a development in cooking techniques. Its principle is straightforward: air circulates over a heating element, is heated when it comes into contact with the element and the heat thus obtained in the oven is used to cook food.

Air circulation is achieved by using one turbine inside the oven which draw in air and expel it onto one or two heating elements, thus producing movement of warm air referred to as “convection”.

Forced convection ovens have many advantages, the main benefit being that identical or different dishes can be cooked evenly at several levels. It is therefore particularly suitable for cooking cakes, pastries, Viennese bread or flaky pastry.

It heats quickly and defrosts frozen food evenly.

Different dishes can be cooked simultaneously without taste transference because odours are destroyed as the air passes over the heating element.

The oven is heated by a circular element.

Description:

Built with steel plate that has been stove enamelled at 850°C for corrosion resistance, the ovens feature runner slots at three levels with 70 mm pitch distance between them that allow easy sliding for oven trays.


The electric oven is supplied as standard with a grid shelf and a roasting pan.

For the grill there is a central element at the top.

The heating elements are controlled thermostatic switch.

In the electric oven version, the control panel features two indicator lights :

- Indicator light **A** indicates that one of the heating elements is in operation mode.
- Indicator light **B** indicates the state of the heating element in operation mode.



DUAL FUNCTION ELECTRIC OVEN



Operation:

To select the operating mode switch must switch **I** is set to  for operation in static mode or on the  position

for operation in forced convection.


The oven must be pre-heated at the thermostat setting chosen for cooking.

Turn the thermostat switch clockwise to the required mark.



The indicator lamps, rep. **A** and **B**, are lit. When indicator lamp **B** is no longer lit, the selected temperature has been reached and you can then place your dish in the oven.

To turn off, turn the control knob anti-clockwise to the 0 position.



Electric grill:


The electric oven is equipped with a grill that can be used to grill meat and fish cook all types of dishes au gratin. The grill is ideal for finishing off crèmes brûlées or to obtain perfect cooking of a rib of beef.

Operation:

Turn the thermostat control knob one click further to the  symbol.

To turn off, turn the control knob clockwise to the 0 position.

In the grill position, only the central element in the roof operates.



DUAL FUNCTION ELECTRIC OVEN



Note: During operation of the grill, the turbine remains on.

Usage tips:

In the case of simultaneous cooking, pastries are preferably placed on the top rack, above the other items to cook.

Moreover, it appears that cooking in a convection oven is carried out at lower temperatures than in a conventional oven. Consider reducing the heating temperature.

EN 01-2025

Settings	67 L - 2.95 kW W.550 x H.291 x D.417	Vertical 69 L - 2.65 kW W.333 x H.458 x D.425	112 L - 7 kW W.880 x H.305 x D.405
Cormatin	●		
Rully	●		
Beaune/Bussy		●	
Volnay/Vougeot	●		
Chassagne/ Chambertin	●		
Cluny Grand Chef			●
Saulieu/Savigny	●	●	
Sully	●		
Cluny Grand Chef 1400			●
Fontenay	●		
Citeaux	●	●	
Cluny Grand Chef 1800			●
Sully 1800	●		
Sully 2200	●		

GRIL OVEN



EN 01-2025

With two heating elements, electric grill oven can be used as a cooking oven and also as broiler. It is particularly intended for finish a crème brûlée or a gratin, grilling sausages, bacon, toasting bread or just cooking a prime rib.

In cooking mode, culinary preparations will be browned by a refractory effect of the oven vault.

Description:

Made of sheet steel antiacid enameled baked at 850 ° the oven is equipped with 3 x 70 mm rack support spaces allowing easy sliding of the racks.

The oven is equipped with an original grille toaster and flat pans.

The heating in the oven position is ensured by a sole resistance used as a grill, the heating is provided by a top heating element.

The heating elements are controlled by a thermostatic switch.

In its electric oven version, the control panel has 2 LEDs:

- The **A** light indicates the power of one of the two heating elements.
- The **B** light indicates the temperature regulation of the heating element.



Use:

Preheating the oven must be on the thermostat mark selected for cooking.

Turn the temperature switch in the clockwise direction to the desired mark.

The lights **A** and **B** turn on. When the light **B** goes out, the selected temperature is reached. You can bake your preparation.

To turn off the oven, turn the knob of the thermostatic switch to the left up to the 0 mark.



GRIL OVEN

Settings	27 L - 1.5 kW W.541 x H.115 x D.422	20 L - 1.5 kW W.405 x H.115 x D.422
Rully	●	
Chagny		●
Chagny 1400		●
Chagny 1800		●

SIMMER OVEN (OPTION)



The simmer oven has many uses such as plate warming, holding food, slow cooking, drying food etc. It offers great flexibility when organising your meals and cooking for large numbers. Its principle is straightforward and involves using a heating element to keep your simmer oven heated at the desired temperature.

Heating is obtained by means of a heating element located underneath the base plate.

Description:

Made of sheet steel with an acid-resistant enamel coating, the simmer oven have 4 shelf levels positions (125 mm spacing) allowing shelves and flarware to slide in easily, that can accommodate catering sized shelves GN1/1.

The simmer oven is supplied equipped with two oven racks. Others available separately.

The heating element is controlled by a thermostatic switch on the control panel.

An indicator lamp next to the control knob indicates thermostat control of the heating element. It is lit or no longer lit depending on the programme temperature (see below).

Use:

The simmer oven should be pre-heated roughly one hour before plates or dishes are placed inside it.

Turn the thermostat switch clockwise to the selected mark. Indicator lamp (A) is lit and goes out when the desired temperature has been reached, at wich point the simmer oven as ready to use.

In order to switch off, turn the thermostat control knob anticlockwise to the 0 position.

Although you can select any position for the simmer oven control knob, four positions are indicated on the control panel of the cooker. These represent approximately as follows.

Useful hint:

Before using the simmer oven for the first time, it is advisable to switch it on without anything in it at the maximum thermostat position for 1/2 hour in order to eliminate the smell of fumes due to the composition of the mineral wool used to insulate the oven and residues from greases applied during manufacture. These odours will disappear after the oven has been used a few times.

- Never place plates directly on the base, crockery may break due to the rapid increase in temperature.
- Your dishes or plates may be extremely hot depending on the temperature selected.

Take the necessary precautions before handling them.

Caution: Always ensure that food is correctly cooked, especially when the slow cooking using lower temperatures. Ensure that any food has reached its regulatory or advisable temperature during cooking to make it safe and suitable for consumption. Always be careful when re-heating food and consult advice as required.

SIMMER OVEN (OPTION)

Settings	79 L - 0.95 kW W.328 x H.452 x D.535
Volnay/Vougeot	●
Chassagne/Chambertin	●
Cluny 1400	●
Chagny 1400	●
Fontenay	●
Citeaux	●
Cluny 1800	●
Chagny 1800	●
Sully 1800	●
Sully 2200	●

Before cleaning, shut off the gas supply and/or switch off the electricity supply.

Do not clean this appliance with chlorinated products.

Read carefully the warnings and directions of use of the products you use for cleaning and maintaining the appliance. Observe all directions of use.



Do not use a steam generator for cleaning the appliance.

Open burners:

Burners are made up of two parts to make cleaning easier. Clean them separately.

→ Burner caps:

The caps are made of solid brass. Clean them using a soft cloth and a special product for cleaning brass (for instance: MIROR®).

If the product is spilled on an enamelled surface, do not rub it at all (this type of product generally contains abrasive particles). Quickly rinse with clean water without rubbing.

If the caps are heavily stained, they should be polished using very fine sandpaper and then rubbed with a product for copper alloys.

→ Burner bodies:

The bodies are made of aluminium and get stained during normal use. Clean them regularly using an abrasive pad (Scotch Brite®).

After removal of the pan stands and the burners, the hob table can be cleaned easily using a sponge. Avoid the use of abrasive or corrosive sponges and cleaning products that are used for the oven or some loose parts.

During cleaning work, take care not to spill any liquids down the openings for the burners.

Solid top plate:

Do not clean the plate whilst with water; doing this could damage it.

Wipe off immediately any spills; cleaning will be made much easier.

Use a sponge with soapy water or soap powder.

Ceramic hob:

The hob must ALWAYS be kept completely dry. Wipe your pans dry before putting them on the hob. Trace of limescale can be removed using white vinegar. Cover the stains with a damp cloth, leave for half an hour, and then rinse and dry carefully.

Stainless steel surfaces are cleaned with a wet sponge, adding a mild detergent to remove tough stains (for instance, CIF®...).

If during use, sugar syrup is spilled on the ceramic hob surface, turn the heating element to setting "1", and remove IMMEDIATELY the burnt deposit using a razor scraper (for instance, CERA Quick®);

WARNING:

If a crack appears on the surface, disconnect immediately the appliance from its power supply to avoid the risks of electric shocks. Contact your installer.

Main body:

You can use special products for stainless steel (for instance ZIP stainless steel®, JOHNSON stainless steel®, PPZ stainless steel®); never use abrasive products.

Stainless steel hob surface:

The plate has been press formed into a shape that makes it easy to clean and improves hygiene (no catch points). Cleaning must be done with non-chlorinated liquid products to avoid scratching the surface.

If the hob is stained, use a clay- and soap-based paste cleaner (non-scratching “pierre d’argile”) available from high street stores.

Stainless steel:

Stainless steel can simply be cleaned with soapy water or with a clay- and soap-based paste cleaner (non-scratching “pierre d’argile”).

Dry with a soft cloth or with absorbent paper.

Do not use chlorinated products.

Brass:

Clean with a soft cloth and a special product for cleaning brass (for instance: MIROR®). If the product is spilled on an enamelled surface, do not rub it at all (this type of product generally contains abrasive particles), but rinse with clean water without rubbing.

Another option is to use a clay- and soap-based paste cleaner (non-scratching “pierre d’argile”) which is applied with a sponge to the surface to be cleaned.

This product is very good for cleaning and bringing back the shine to brass, chromed or stainless steel surfaces.

Enamelled surfaces:


Use a sponge with soapy water or with window cleaner, but never with soap powder. You can also use methylated spirit, but only when the appliance is cold.

Ovens:

Remove the side rack panels with the shelf runners. To do this, loosen the knurled screw **A** and lift the panel slightly to release it.

CAUTION: When replacing the ladders it is imperative to make sure of their proper installation: namely that the ladders are well nested behind the 3 screws **A**.

These side rack panels have to be fitted back correctly to ensure the safe use of shelves and pans.



Cleaning of the internal walls of the oven and the oven door:

Clean with a stainless steel wire scourer and conventional detergent (washing-up liquid, clay- and soap-based paste cleaner or even sodium bicarbonate); apply pressure on the surface with a circular motion of the scourer.

Rinse with a sponge and clean water.


Cleaning of the fan cover (convection and multifunction oven):

Fat particles carried by the air flow during use at low temperature can produce smoke.

Clean at least once a year the area behind the fan cover.

Unscrew the four screws.

After cleaning, refit the fan cover with the screws and washers; take care to tighten the four screws correctly.



Advice:

-  To avoid significant splashes of fat in the oven, it is advisable to use high-sided vessels (cast iron casseroles, earthenware pots) to roast meats (red or white meats, poultry). This technique produces an evenly cooked meat, and by using a lid, the final juices can be preserved.
-  Avoid the use of strong detergents. If you need to use such products, first remove the door seal, and refit it after cleaning.
-  Do not spray a descaler directly on the heating elements of electric ovens.

Note concerning the disposal of waste electrical and electronic equipment

Decree no. 2005-829 of 20 July 2005 transposing European Directives 2002/95/EC and 2002/96/EC on hazardous substances in electrical and electronic equipment and on the disposal waste electrical and electronic equipment.

- Electrical and electronic equipment (EEE) and waste electrical and electronic equipment (WEEE) are regulated at European level by two directives which aim on the one hand to limit the use of certain hazardous substances in EEE, and on the other hand to promote the reuse, recycling and other forms of recovery of WEEE so as to reduce the disposal of waste.



All electrical and electronic equipment put on the market after 13 August 2005 must be marked with this symbol.

This symbol indicates that the equipment may not be disposed of with other waste and that it is the object of separate collection with the purpose of recovery, reuse and recycling.

- Users of electrical and electronic equipment are required not to dispose of WEEE as unsorted municipal waste.
- Appropriate systems of separate collection are available to users.
- To meet these regulations as a manufacturer of electrical equipment, Lacanche has joined and participates in the green scheme operated by ÉCO-SYSTÈMES FRANCE.

It is by observing these regulations that users of electrical and electronic equipment avoid the potentially harmful effects on the environment and human health, whilst contributing also to the preservation of natural resources.



TECHNICAL DATA

CHASSAGNE / CHAMBERTIN

SAULIEU / SAVIGNY

CLUNY 1400 D-G - CHARLIEU / CHABLIS

CLUNY GRAND CHEF 1400 D-G

CHAGNY 1400 D-G - CHAUSSIN / CHEMIN

SULLY - CHALONNAIS

FONTENAY 1500

CITEAUX 1500

CLUNY 1800 - FLAVIGNY

CLUNY GRAND CHEF 1800

CHAGNY 1800 - AVALON

SULLY 1800 D-G - BLIGNY / BELMONT

FONTENAY 1900 D-G

CITEAUX 1900 D-G

SULLY 2200 - VEZELAY

CHASSAGNE – CHAMBERTIN 97

LG 1131 G/E/CT	LG 1141 G/E/CT	LCF 1131 G/E/CT	LVTR 1141 E/CT	LVI 1131 E/CT
LMG 1131 G/E/CT	LMG 1141 G/E/CT	LMCF 1131 G/E/CT	LMVTR 1141 E/CT	LMVI 1131 E/CT

SAULIEU – SAVIGNY 103

LG 1132G/E/CT	LG 1142G/E/CT	LCF 1132G/E/CT	LVTR 1142E/CT	LVI 1132 E/CT
LMG 1132G/E/CT	LMG 1142G/E/CT	LMCF 1132G/E/CT	LMVTR 1142E/CT	LMVI 1132E/CT

CLUNY 1400 D-G - CHARLIEU/CHABLIS 113

LG 1452D-G EG/E/CTG/ECT	LCF 1452D-G EG/E/CTG/ECT	LVTR 1452D-G E/CT	LVI 1452D-G E/CT
LMG 1452D-G EG/E/CTG/ECT	LMCF 1452D-G EG/E/CTG/ECT	LMVTR 1452D-G E/CT	LMVI 1452D-G E/CT

CLUNY GRAND CHEF 1400 D-G 121

LG 1451D-G BG/BCT	LCF 1451D-G BG/BCT	LVTR 1451D-G BCT	LVI 1451D-G BCT
LMG 1451D-G BG/BCT	LMCF 1451D-G BG/BCT	LMVTR 1451D-G BCT	LMVI 1451D-G BCT

CHAGNY 1400 D-G - CHAUSSIN/CHEMIN 129

LG 1453D-G EG/E/CTG/ECT	LCF 1453D-G EG/E/CTG/ECT	LVTR 1453D-G E/CT	LVI 1453D-G E/CT
LMG 1453D-G EG/E/CTG/ECT	LMCF 1453D-G EG/E/CTG/ECT	LMVTR 1453D-G E/CT	LMVI 1453D-G E/CT

SULLY - CHALONNAIS 137

LG 1432 G/GE/E/GCT/ECT	LCF 1432 G/GE/E/GCT/ECT	LVTR 1442 E/CT	LVI 1432 E/CT
LMG 1432 G/GE/E/GCT/ECT	LMCF 1432 G/GE/E/GCT/ECT	LMVTR 1442 E/CT	LMVI 1432 E/CT

FONTENAY 1500 143

LG 1531 G/E/CT	LG 1541 G/E/CT	LCF 1531 G/E/CT	LVTR 1541 E/CT	LVI 1531 E/CT
LMG 1531 G/E/CT	LMG 1541 G/E/CT	LMCF 1531 G/E/CT	LMVTR 1541 E/CT	LMVI 1531 E/CT

CITEAUX 1500 149

LG 1532 G/E/CT	LG 1542 G/E/CT	LCF 1532 G/E/CT	LVTR 1542 E/CT	LVI 1532 E/CT
LMG 1532 G/E/CT	LMG 1542 G/E/CT	LMCF 1532 G/E/CT	LMVTR 1542 E/CT	LMVI 1532 E/CT

CLUNY 1800 - FLAVIGNY 155

LG 1852 G/GE/E/GCT/ECT	LCF 1852 G/GE/E/GCT/ECT	LVTR 1852 E/ECT	LVI 1852 E/ECT
LMG 1852 G/GE/E/GCT/ECT	LMCF 1852 G/GE/E/GCT/ECT	LMVTR 1852 E/ECT	LMVI 1852 E/ECT

CLUNY GRAND CHEF 1800 161

LG 1851 BG/BCT	LCF 1851 BG/BCT	LVTR 1851 BCT	LVI 1851 BCT
LMG 1851 BG/BCT	LMCF 1851 BG/BCT	LMVTR 1851 BCT	LMVI 1851 BCT

CHAGNY 1800 - AVALON 167

LG 1853 EG/E/CTG/ECT	LCF 1853 EG/E/CTG/ECT	LVTR 1853 E/CT	LVI 1853 E/CT
LMG 1853 EG/E/CTG/ECT	LMCF 1853 EG/E/CTG/ECT	LMVTR 1853 E/CT	LMVI 1853 E/CT

SULLY 1800 D-G - BLIGNY/BELMONT 173

LG 1832D-G G/GE/E/GCT/ECT	LCF 1832D-G G/GE/E/GCT/ECT	LVTR 1842D-G E/CT	LVI 1832D-G E/CT
LMG 1832D-G G/GE/E/GCT/ECT	LMCF 1832D-G G/GE/E/GCT/ECT	LMVTR 1842D-G E/CT	LMVI 1832D-G E/CT

FONTENAY 1900 D-G 181

LG 1931D-G G/E/CT	LG 1941D-G G/E/CT	LCF 1931D-G G/E/CT	LVTR 1941D-G E/CT	LVI 1931D-G E/CT
LMG 1931D-G G/E/CT	LMG 1941D-G G/E/CT	LMCF 1931D-G G/E/CT	LMVTR 1941D-G E/CT	LMVI 1931D-G E/CT

CITEAUX 1900 D-G 189

LG 1932D-G G/E/CT	LG 1942D-G G/E/CT	LCF 1932D-G G/E/CT	LVTR 1942D-G E/CT	LVI 1932D-G E/CT
LMG 1932D-G G/E/CT	LMG 1942D-G G/E/CT	LMCF 1932D-G G/E/CT	LMVTR 1942D-G E/CT	LMVI 1932D-G E/CT

SULLY 2200 - VEZELAY 197


LG 2232 G/GE/E/GCT/ECT	LCF 2232 G/GE/E/GCT/ECT	LVTR 2242 E/CT	LVI 2232 E/CT
LMG 2232 G/GE/E/GCT/ECT	LMCF 2232 G/GE/E/GCT/ECT	LMVTR 2242 E/CT	LMVI 2232 E/CT

TECHNICAL SHEET


CHASSAGNE / CHAMBERTIN

LG 1131 G/E/CT — LG 1141 G/E/CT — LCF 1131 G/E/CT — LVTR 1141 E/CT — LVI 1131 E/CT

LMG 1131 G/E/CT — LMG 1141 G/E/CT — LMGF 1131 G/E/CT — LMVTR 1141 E/CT — LMVI 1131 E/CT




Classic



Modern




CHASSAGNE « CLASSIQUE » AND « TRADITION »: GAS HOBS



- Body in stainless steel or enamelled steel.
- Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.




► CHASSAGNE «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► CHASSAGNE «CLASSIQUE»: 4 gas burners


- 4 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► CHASSAGNE «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

CHAMBERTIN « CLASSIQUE » AND « TRADITION » : GAS HOBS




▲ Power supply, electrical oven

▲ Power supply, gas oven


▲ Body in stainless steel or enamelled steel.

▲ Press formed top plate.




▲ CHAMBERTIN «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



▲ CHAMBERTIN «CLASSIQUE»: 3 gas burners

- 4 burners in a range of different sizes and powers (see Burners B, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▲ CHAMBERTIN «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc); Please verify the height of your range cookers before installation.

CHASSAGNE "ÉLECTRIQUE": INDUCTION HOB




- ☐ A Power supply
☐ B Gas connection
☐ C Water supply (option)
☐ D Waste water connection (option)

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc).

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► **INDUCTION HOB**

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, **Table 5** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CHAMBERTIN "ÉLECTRIQUE": INDUCTION HOB




- ☐ A Power supply
☐ B Gas connection
☐ C Water supply (option)
☐ D Waste water connection (option)

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, a model on your order might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► **INDUCTION HOB**

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, **Table 5** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

VOLNAY "ÉLECTRIQUE": CERAMIC HOB



Ⓐ, Ⓑ Power supply

Ⓒ Water supply (option)


Ⓓ Waste water connection (option)

Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, **Table 2** en Appendix).

VOUGEOT "ÉLECTRIQUE": CERAMIC HOB



Ⓐ, Ⓑ Power supply

Ⓒ Water supply (option)


Ⓓ Waste water connection (option)

Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz


► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, **Table 2** en Appendix).

CLOSET DOOR SPACE CHASSAGNE



CLOSET DOOR SPACE CHAMBERTIN



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function 2650 Convection function	Yes 2850 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▲ Enamelled steel.
- ▲ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▲ 5 shelf levels with 70 mm spacing i between.
- ▲ Accessories: 2 grills.

Simmer oven:

- ▲ Enamelled sheet metal.
- ▲ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▲ 5 shelf levels with 70 mm spacing i between.
- ▲ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▲ 2 grills.

Total power: 950 W – 230 V 1N– 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (F, T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):



European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET



SAULIEU / SAVIGNY

LG 1132 G/E/CT — LG 1142 G/E/CT — LCF 1132 G/E/CT — LVTR 1142 E/CT — LVI 1132 E/CT

LMG 1132 G/E/CT — LMG 1142 G/E/CT — LMGF 1132 G/E/CT — LMVTR 1142 E/CT — LMVI 1132 E/CT




Classic



Modern



SAULIEU « CLASSIQUE » AND « TRADITION »: GAS HOBS




(A) Power supply, electrical oven

(B) Power supply, gas oven

(C) Gas connection


► Body in stainless steel or enamelled steel.

► Press formed top plate.




► SAULIEU «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► SAULIEU «CLASSIQUE»: 4 gas burners

- 4 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




► SAULIEU «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

SAVIGNY « CLASSIQUE » AND « TRADITION » : GAS HOBS



Ⓐ Power supply, electrical oven

Ⓑ Power supply, gas oven



Ⓒ, Ⓓ Gas connection

► Body in stainless steel or enamelled steel.

► Press formed top plate.


► SAVIGNY «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► SAVIGNY «CLASSIQUE»: 3 gas burners

- 4 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




► SAVIGNY «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

SAULIEU "ÉLECTRIQUE": INDUCTION HOB



A Power supply


B Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.


Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz



► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

SAVIGNY "ÉLECTRIQUE": INDUCTION HOB



A Power supply


B Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.

Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz




► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

TECHNICAL SHEET SAULIEU/SAVIGNY


SAULIEU "ÉLECTRIQUE": CERAMIC HOB



(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, **Table 2** en Appendix).


SAVIGNY "ÉLECTRIQUE": CERAMIC HOBBY



(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz


► CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, **Table 2** en Appendix).

CLOSET DOOR SPACE SAULIEU



CLOSET DOOR SPACE SAVIGNY



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function	Yes 2850 W	3, 70-mm pitch	Thermostat
				2650 Convection function			
Electric multifunction vertical	Enamelled steel	333 x 458 x 425	65	2800 Static function	Yes 1800 W	3, 70-mm pitch	Thermostat
				2850 Convection function			

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (F, T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.

Electrical Directive (Low Voltage): 2014/35 / EU.


Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET


CLUNY 1400 D - G CHARLIEU / CHABLIS

LG 1452D-G EG/E/CTG/ECT — LCF 1452D-G EG/E/CTG/ECT — LVTR 1452D-G E/CT — LVI 1452D-G E/CT

LMG 1452D-G EG/E/CTG/ECT — LMGF 1452D-G EG/E/CTG/ECT — LMVTR 1452D-G E/CT — LMVI 1452D-G E/CT



Classic




Modern



TECHNICAL SHEET CLUNY 1400
CHARLIEU/CHABLIS

CLUNY 1400 D - CHABLIS « CLASSIQUE » AND « TRADITION » : GAS HOBBS




- ☐ A, ☐ B Power supply, electrical oven
☐ C Power supply, gas oven
☐ D Water supply (option)
☐ E Waste water connection (option)
☐ F, ☐ G Gas connection

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, a model on your order might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.



► **CLUNY 1400 D - CHABLIS "CLASSIQUE": 5 gas burners**


- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, **Table 1, Appendix**).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► CLUNY 1400 D - CHABLIS "TRADITION": 4 gas burners and a solid top


- 5 burners in a range of different sizes and powers (see Burners T, B, C and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

CLUNY 1400 G - CHARLIEU « CLASSIQUE » AND « TRADITION » : GAS HOBS




▲ CLUNY 1400 G - CHARLIEU «CLASSIQUE»: 5 gas burners

- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



▲ CLUNY 1400 G - CHARLIEU «TRADITION»: 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

TECHNICAL SHEET CLUNY 1400 CHARLIEU/CHABLIS

TECHNICAL SHEET CLUNY 1400 CHARLIEU/CHABLIS

CLUNY 1400 D - CHABLIS "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ, Ⓑ Power supply, electrical oven
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

▲ INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CLUNY 1400 D - CHABLIS "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ, Ⓑ Power supply, electrical oven
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.



Power: 10600 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz


▲ CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, **Table 2** en Appendix).

TECHNICAL SHEET CLUNY 1400 CHARLIEU/CHABLIS

TECHNICAL SHEET CLUNY 1400 CHARLIEU/CHABLIS

CLUNY 1400 G - CHARLIEU "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ, Ⓑ Power supply, electrical oven
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CLUNY 1400 G - CHARLIEU "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ, Ⓑ Power supply, electrical oven
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




► CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, **Table 2** en Appendix).


TECHNICAL SHEET CLUNY 1400 CHARLIEU/CHABLIS

TECHNICAL SHEET CLUNY 1400 CHARLIEU/CHABLIS

CLOSET DOOR SPACE CLUNY 1400 / CHARLIEU



CLOSET DOOR SPACE CLUNY 1400 / CHABLIS



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	414 x 288 x 438	52	3500	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	414 x 291 x 465	56	2300	Yes 1800 W	3, 70-mm pitch	Thermostat
Electric multifunction fan	Enamelled steel	414 x 291 x 417	51	2400	Yes 1800 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
	Natural Gas - kW/h	Propane Gas - kW/h
GAS/Burner		
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (F, T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.

Electrical Directive (Low Voltage): 2014/35 / EU.


Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET


CLUNY GRAND CHEF 1400 D-G

LG 1451D-G BG/BCT — LCF 1451D-G BG/BCT — LVTR 1451D-G BCT — LVI 1451D-G BCT

LMG 1451D-G BG/BCT — LMGF 1451D-G BG/BCT — LMVTR 1451D-G BCT — LMVI 1451D-G BCT




Classic



Modern



CLUNY GRAND CHEF 1400 D « CLASSIQUE » AND « TRADITION » : GAS HOBS




- ▲ Power supply, electrical oven
- ▲ Power supply, gas oven

- ▲ Water supply (option)
- ▲ Waste water connection (option)
- ▲ Gas connection

- ▲ Body in stainless steel or enamelled steel.
- ▲ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.



▲ CLUNY GRAND CHEF 1400 D «CLASSIQUE»: 5 gas burners


- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



▲ CLUNY GRAND CHEF 1400 D «TRADITION»: 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

CLUNY GRAND CHEF 1400 G «CLASSIQUE» AND «TRADITION» : GAS HOBS




- Ⓐ Power supply, electrical oven
- Ⓑ Power supply, gas oven

- Ⓒ Water supply (option)
- Ⓓ Waste water connection (option)
- Ⓔ Gas connection

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc); Please verify the height of your range cookers before installation.



▶ CLUNY GRAND CHEF 1400 G «CLASSIQUE»: 5 gas burners

- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▶ CLUNY GRAND CHEF 1400 G «TRADITION»: 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET CLUNY GRAND CHEF 1400

TECHNICAL SHEET CLUNY GRAND CHEF 1400

CLUNY GRAND CHEF 1400 D "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ Power supply, electrical oven
- Ⓑ Water supply (option)
- Ⓒ Waste water connection (option)
- Ⓓ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

▲ INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CLUNY GRAND CHEF 1400 D "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ Power supply, electrical oven
- Ⓑ Water supply (option)
- Ⓒ Waste water connection (option)
- Ⓓ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.




Power: 10600 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

▲ CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, **Table 2** en Appendix).

TECHNICAL SHEET CLUNY GRAND CHEF 1400


CLUNY GRAND CHEF 1400 G "ÉLECTRIQUE": INDUCTION HOB



(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

TECHNICAL SHEET CLUNY GRAND CHEF 1400


CLUNY GRAND CHEF 1400 G "ÉLECTRIQUE": CERAMIC HOB



(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




► CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, **Table 2** en Appendix).


TECHNICAL SHEET CLUNY GRAND CHEF 1400

TECHNICAL SHEET CLUNY GRAND CHEF 1400

CLOSET DOOR SPACE CLUNY GRAND CHEF 1400 G



CLOSET DOOR SPACE CLUNY GRAND CHEF 1400 D



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	880 x 305 x 455	117	7600	No	3, 70-mm pitch	Thermocouple
Electric multifunction	Enamelled steel	880 x 305 x 405	112	4800	Yes 3600 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (F, T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):



European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET



CHAGNY 1400 D - G CHEMIN/CHAUSSIN

LG 1453D-G EG/E/CTG/ECT — LCF 1453D-G EG/E/CTG/ECT — LVTR 1453D-G E/CT — LVI 1453D-G E/CT

LMG 1453D-G EG/E/CTG/ECT — LMGF 1453D-G EG/E/CTG/ECT — LMVTR 1453D-G E/CT — LMVI 1453D-G E/CT



Classic




Modern



**TECHNICAL SHEET CHAGNY 1400
CHEMIN/CHAUSSIN**

CHAGNY 1400 D - CHEMIN « CLASSIQUE » AND « TRADITION »: GAS HOBS




- ☐ A Power supply, electrical oven
☐ B Gas connection for cookers without gas ovens
☐ C Gas connection for cookers with a gas oven
☐ D Gas connection for cookers with gas cooking top option on the right hand side
☐ E Water supply (option)
☐ F Waste water connection (option)

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, a model on your order might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.



► **CHAGNY 1400 D - CHEMIN "CLASSIQUE": 5 gas burners**


- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► CHAGNY 1400 D - CHEMIN "TRADITION": 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B, C and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

CHAGNY 1400 G - CHAUSSIN « CLASSIQUE » AND « TRADITION »: GAS HOBS




- Ⓐ Power supply
- Ⓑ Gas connection for cookers without gas ovens
- Ⓒ Gas connection for cookers with a gas ovens
- Ⓓ Water supply (option)
- Ⓔ Waste water connection (option)

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc); Please verify the height of your range cookers before installation.



▶ CHAGNY 1400 G - CHAUSSIN «CLASSIQUE»: 5 gas burners

- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▶ CHAGNY 1400 G - CHAUSSIN «TRADITION»: 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B, C and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET CHAGNY 1400 CHEMIN/CHAUSSIN

TECHNICAL SHEET CHAGNY 1400 CHEMIN/CHAUSSIN

CHAGNY 1400 D - CHEMIN "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ Power supply, electrical oven
- Ⓑ Waste water connection (option)
- Ⓒ Water supply (option)
- Ⓓ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

▲ INDUCTION HOB

- 9 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, **Table 3** en Appendix).
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CHAGNY 1400 D - CHEMIN "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ Power supply, electrical oven
- Ⓑ Waste water connection (option)
- Ⓒ Water supply (option)
- Ⓓ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.



Power: 10600 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz


▲ CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, **Table 2** en Appendix).

TECHNICAL SHEET CHAGNY 1400 CHEMIN/CHAUSSIN

TECHNICAL SHEET CHAGNY 1400 CHEMIN/CHAUSSIN

CHAGNY 1400 G - CHAUSSIN "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ Power supply, electrical oven
- Ⓑ Waste water connection (option)
- Ⓒ Water supply (option)
- Ⓓ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CHAGNY 1400 G - CHAUSSIN "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ Power supply, electrical oven
- Ⓑ Waste water connection (option)
- Ⓒ Water supply (option)
- Ⓓ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.


► Body in stainless steel or enamelled steel.




► CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, **Table 2** en Appendix).

CLOSET DOOR SPACE CHEMIN



CLOSET DOOR SPACE CHAUSSIN



Ovens:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	414 x 288 x 438	52	3500	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	414 x 291 x 465	56	2300	Yes 1800 W	3, 70-mm pitch	Thermostat
Electric convection	Enamelled steel	414 x 291 x 417	51	2400	Yes 1800 W	3, 70-mm pitch	Thermostat
Electric grill	Enamelled steel	405 x 115 x 422	20	1500	Yes 2400 W	1	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
	Natural Gas - kW/h	Propane Gas - kW/h
GAS/Burner		
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▲ Enamelled steel.
- ▲ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▲ 5 shelf levels with 70 mm spacing i between.
- ▲ Accessories: 2 grills.

Simmer oven:

- ▲ Enamelled sheet metal.
- ▲ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▲ 5 shelf levels with 70 mm spacing i between.
- ▲ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▲ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (F, T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.


Electrical Directive (Low Voltage): 2014/35 / EU.

Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.


TECHNICAL SHEET

SULLY CHALONNAIS

LG 1432 G/GE/E/GCT/ECT — LCF 1432 G/GE/E/GCT/ECT — LVTR 1442 E/CT — LVI 1432 E/CT
 LMG 1432 G/GE/E/GCT/ECT — LMGF 1432 G/GE/E/GCT/ECT — LMVTR 1442 E/CT — LMVI 1432 E/CT




Classic



Modern




SULLY/CHALONNAIS « CLASSIQUE » AND « TRADITION » : GAS HOBS



- Body in stainless steel or enamelled steel.
- Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.



► SULLY/CHALONNAIS «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, B and D, **Table 1**, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




► SULLY/CHALONNAIS «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, B and D, **Table 1**, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET SULLY/CHALONNAIS

SULLY/CHALONNAIS "ÉLECTRIQUE": INDUCTION HOB




A, B Electrical supply

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► **INDUCTION HOB**

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, **Table 3** en Appendix).
 - 9 power settings.
 - Booster mode in each zone.
 - Fast cooking mode.
 - 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
 - Child-proof safety.
 - Pan detection.
 - Electronic display unit under ceramic glass plate.
 - "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

SULLY/CHALONNAIS "ÉLECTRIQUE": CERAMIC HOB




A, B Electrical supply

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, a model on your order might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.



Power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, **Table 2** en Appendix).



TECHNICAL SHEET SULLY/CHALONNAIS

Over:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function 2850 Convection function	Yes 2850 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
	Natural Gas - kW/h	Propane Gas - kW/h
GAS/Burner		
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, D: **Table 5**, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.

Electrical Directive (Low Voltage): 2014/35 / EU.


Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET


FONTENAY

LG 1531 G/E/CT — LG 1541 G/E/CT — LCF 1531 G/E/CT — LVTR 1541 E/CT — LVI 1531 E/CT

LMG 1531 G/E/CT — LMG 1541 G/E/CT — LMCF 1531 G/E/CT — LMVTR 1541 E/CT — LMVI 1531 E/CT



Classic




Modern



TECHNICAL SHEET FONTENAY

FONTENAY « CLASSIQUE » AND « TRADITION » : GAS HOBS




- ☐ A Power supply, electrical oven
☐ B Power supply, gas oven
☐ C ☐ D Water supply
☐ E, ☐ F Water waste connection
☐ G, ☐ H Gas connection

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Laacache range cookers official height is 930 mm. Following your request, each model on your order might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.




► FONTENAY "CLASSIQUE": 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, **Table 1**, Appendix). Individually controlled by a safety valve (thermocouple).
Electrical ignition with pushbutton.



► FONTENAY "CLASSIQUE": 4 gas burners


- 3 burners in a range of different sizes and powers (see Burners B, C and D, **Table 1**, Appendix).
 Individually controlled by a safety valve (thermocouple).
 Electrical ignition with pushbutton.



► FONTENAY "TRADITION": 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, **Table 1**, Appendix).
Central hob with a 385 x 510 mm solid top.
Individually controlled by a safety valve (thermocouple).
Electrical ignition with pushbutton.

FONTENAY "ÉLECTRIQUE": INDUCTION HOB




- (A) Electrical supply
- (B) Waste water connection (option)
- (D) Water supply (option)
- (E) Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 3 induction zones in a range of different sizes
- and powers under a 4 mm ceramic glass plate (heaters A, B and D, **Table 3** en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

FONTENAY "ÉLECTRIQUE": CERAMIC HOB




- (A) Electrical supply
- (B) Waste water connection (option)
- (D) Water supply (option)
- (E) Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, **Table 2** en Appendix).

CLOSET DOOR SPACE FONTENAY



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function 2650 Convection function	Yes 2850 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):


European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET


CITEAUX

LG 1532 G/E/CT — LG 1542 G/E/CT — LCF 1532 G/E/CT — LVTR 1542 E/CT — LVI 1532 E/CT

LMG 1532 G/E/CT — LMG 1542 G/E/CT — LMCF 1532 G/E/CT — LMVTR 1542 E/CT — LMVI 1532 E/CT




Classic



Modern



CITEAUX « CLASSIQUE » AND « TRADITION » : GAS HOBS




- ▲ A Power supply, electrical oven
- ▲ B Power supply, gas oven
- ▲ C Water waste connection (option)
- ▲ D Water supply
- ▲ E, F Gas connection

- ▲ Body in stainless steel or enamelled steel.
- ▲ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.




▲ CITEAUX «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



▲ CITEAUX «CLASSIQUE»: 4 gas burners


- 3 burners in a range of different sizes and powers (see Burners B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



▲ CITEAUX «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

CITEAUX "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ Electrical supply
- Ⓑ Waste water connection (option)
- Ⓒ Water supply (option)
- Ⓓ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 3 en Annex 0).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CITEAUX "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ, Ⓑ Electrical supply
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

CLOSET DOOR SPACE CITEAUX



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function	Yes 2850 W	3, 70-mm pitch	Thermostat
				2650 Convection function			
Electric multifunction vertical	Enamelled steel	333 x 458 x 425	65	2300 Static function	Yes 1800 W	3, 73-mm pitch	Thermostat
				2650 Convection function			

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- Enamelled steel.
- Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- 5 shelf levels with 70 mm spacing i between.
- Accessories: 2 grills.

Simmer oven:

- Enamelled sheet metal.
- Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- 5 shelf levels with 70 mm spacing i between.
- 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, C, D: Table 5, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.


TECHNICAL SHEET

CLUNY 1800


FLAVIGNY

LG 1852 G/GE/E/GCT/ECT — LCF 1852 G/GE/E/GCT/ECT — LVTR 1852 E/ECT — LVI 1852 E/ECT

LMG 1852 G/GE/E/GCT/ECT — LMCF 1852 G/GE/E/GCT/ECT — LMVTR 1852 E/ECT — LMVI 1852 E/ECT




Classic



Modern



CLUNY 1800 - FLAVIGNY « CLASSIQUE » AND « TRADITION » : GAS HOBS




- Ⓐ, Ⓑ Power supply, electrical oven
- Ⓒ Power supply, gas oven
- Ⓓ, Ⓔ Water supply
- Ⓕ, Ⓖ Water waste connection (option)
- Ⓗ, Ⓘ Gas connection

- ▲ Body in stainless steel or enamelled steel.
- ▲ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc); Please verify the height of your range cookers before installation.



▲ CLUNY 1800 - FLAVIGNY "CLASSIQUE": 5 gas burners

- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▲ CLUNY 1800 - FLAVIGNY "TRADITION": 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET CLUNY 1800 FLAVIGNY

TECHNICAL SHEET CLUNY 1800 FLAVIGNY

CLUNY 1800 - FLAVIGNY "ÉLECTRIQUE": INDUCTION HOB




- (A) Electrical supply
- (B) Waste water connection (option)
- (C) Water supply (option)
- (D) Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CLUNY 1800 - FLAVIGNY "ÉLECTRIQUE": CERAMIC HOB




- (A) Electrical supply
- (B) Waste water connection (option)
- (C) Water supply (option)
- (D) Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Power: 10600 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, Table 2 en Appendix).

CLOSET DOOR SPACE CLUNY 1800 / FLAVIGNY



Ovens:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	400 x 307 x 461	57	3500	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	400 x 307 x 461	57	2300	Yes 1800 W	3, 70-mm pitch	Thermostat
Electric multifunction fan	Enamelled steel	400 x 307 x 415	51	2400	Yes 1800 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▲ Enamelled steel.
- ▲ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▲ 5 shelf levels with 70 mm spacing i between.
- ▲ Accessories: 2 grills.

Simmer oven:

- ▲ Enamelled sheet metal.
- ▲ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▲ 5 shelf levels with 70 mm spacing i between.
- ▲ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▲ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.

Electrical Directive (Low Voltage): 2014/35 / EU.

Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.


TECHNICAL SHEET

CLUNY GRAND CHEF 1800


FLAVIGNY

LG 1851 BG/BCT — LCF 1851 BG/BCT — LVTR 1851 BCT — LVI 1851 BCT

LMG 1851 BG/BCT — LMCF 1851 BG/BCT — LMVTR 1851 BCT — LMVI 1851 BCT



Classic




Modern



TECHNICAL SHEET CLUNY
GRAND CHEF 1800

CLUNY GRAND CHEF 1800 « CLASSIQUE » AND « TRADITION » : GAS HOBBS




- ☐ A Power supply, electrical oven
☐ B Power supply, gas oven
☐ C, ☐ E Water supply
☐ D, ☐ F Water waste connection (option)
☐ G, ☐ H Gas connection

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.



► **CLUNY GRAND CHEF 1800 "CLASSIQUE"**: 5 gas burners

- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




► **CLUNY GRAND CHEF 1800 "TRADITION":** 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET CLUNY GRAND CHEF 1800

TECHNICAL SHEET CLUNY GRAND CHEF 1800

CLUNY GRAND CHEF 1800 "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ Electrical supply
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓕ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CLUNY GRAND CHEF 1800 "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ Electrical supply
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓕ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Power: 10600 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, Table 2 en Appendix).

CLOSET DOOR SPACE CLUNY GRAND CHEF 1800



Ovens:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	880 x 305 x 455	117	7600	No	3, 70-mm pitch	Thermocouple
Electric multifunction	Enamelled steel	880 x 305 x 405	112	4800	Yes 3600 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
	Natural Gas - kW/h	Propane Gas - kW/h
GAS/Burner		
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, C, D: Table 5, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.


TECHNICAL SHEET

CHAGNY 1800


AVALON

LG 1853 EG/E/CTG/ECT — LCF 1853 EG/E/CTG/ECT — LVTR 1853 E/CT — LVI 1853 E/CT

LMG 1853 EG/E/CTG/ECT — LMGF 1853 EG/E/CTG/ECT — LMVTR 1853 E/CT — LMVI 1853 E/CT




Classic



Modern



CHAGNY 1800 - AVALON « CLASSIQUE » AND « TRADITION » : GAS HOBS




- Ⓐ Power supply
- Ⓑ Gas connection for cookers without gas ovens
- Ⓒ Gas connection for cookers with a gas oven

- Ⓓ Gas connection for cookers with gas cooking top option on the right hand side
- Ⓔ, Ⓕ Water supply (option)
- Ⓖ, Ⓗ Water waste connection (option)

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.



▶ CHAGNY 1800 - AVALON "CLASSIQUE": 5 gas burners

- 5 burners in a range of different sizes and powers (see Burners A, B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▶ CHAGNY 1800 - AVALON "TRADITION": 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET CHAGNY 1800 AVALON

CHAGNY 1800 - AVALON "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ Electrical supply
- Ⓑ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.




Total power: 11100 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

▲ INDUCTION HOB

- 5 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B, C and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

TECHNICAL SHEET CHAGNY 1800 AVALON

CHAGNY 1800 - AVALON "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ Electrical supply
- Ⓑ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.




Power: 10600 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

▲ CERAMIC HOB

- 5 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B and C, Table 2 en Appendix).

CLOSET DOOR SPACE CHAGNY 1800 / AVALON



Ovens:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	414 x 288 x 438	52	3500	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	414 x 291 x 465	56	2300	Yes 1800 W	3, 70-mm pitch	Thermostat
Electric multifunction fan	Enamelled steel	414 x 291 x 417	51	2400	Yes 1800 W	3, 70-mm pitch	Thermostat
Electric grill	Enamelled steel	405 x 115 x 422	20	1500	Yes 2400 W	1	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.


TECHNICAL SHEET

SULLY 1800 D-G


BLIGNY / BELMONT

LG 1832D-G G/GE/E/GCT/ECT — LCF 1832D-G G/ GE/E/GCT/ECT — LVTR 1842D-G E/CT — LVI 1832D-G E/CT

LMG 1832D-G G/GE/E/GCT/ECT — LMGF 1832D-G G/GE/E/GCT/ECT — LMVTR 1842D-G E/CT — LMVI 1832D-G E/CT




Classic



Modern



SULLY 1800 D - BELMONT « CLASSIQUE » AND « TRADITION » : GAS HOBS



- ⬆ A, B Power supply, electrical oven
- ⬆ C Power supply, gas oven


- ⬆ E Water supply (option)

- ⬆ F Waste water connection (option)

- ⬆ G, H Gas connection


▶ Body in stainless steel or enamelled steel.

▶ Press formed top plate.



▶ SULLY 1800 D - BELMONT «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, B and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▶ SULLY 1800 D - BELMONT «TRADITION»: 4 gas burners and a solid top

- 5 burners in a range of different sizes and powers (see Burners T, B and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

SULLY 1800 G - BLIGNY « CLASSIQUE » AND « TRADITION » : GAS HOBS




- Ⓐ Power supply, electrical oven
- Ⓑ Power supply, gas oven

- Ⓔ Water supply (option)
- Ⓕ Waste water connection (option)
- Ⓖ Gas connection

- Body in stainless steel or enamelled steel.
- Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.



► SULLY 1800 G - BLIGNY «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, B and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




► SULLY 1800 G - BLIGNY «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, B and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET SULLY 1800 BLIGNY/BELMONT

SULLY 1800 D - BELMONT "ÉLECTRIQUE": INDUCTION HOB




- ☐ A ☐ B Power supply, electrical oven
☐ C Waste water connection (option)
☐ D Water supply (option)
☐ E Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, a model on your order might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

- Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

SULLY 1800 D - BELMONT "ÉLECTRIQUE": CERAMIC HOB




- ☐ A ☐ B ☐ C ☐ D ☐ E

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

- Body in stainless steel or enamelled steel.



Power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz


► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

TECHNICAL SHEET SULLY 1800 BLIGNY/BELMONT

TECHNICAL SHEET SULLY 1800 BLIGNY/BELMONT

SULLY 1800 G - BLIGNY "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ, Ⓑ Electric supply
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.


► Body in stainless steel or enamelled steel.



► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

SULLY 1800 G - BLIGNY "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ, Ⓑ Power supply, electrical oven
- Ⓒ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓔ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.


► Body in stainless steel or enamelled steel.




► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

CLOSET DOOR SPACE SULLY 1800 / BELMONT



CLOSET DOOR SPACE SULLY 1800 / BLIGNY



Ovens:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function 2650 Convection function	Yes 2850 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, D: **Table 5**, Appendix).

Compliance with European regulations (EC):



European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET



FONTENAY 1900

LG 1931D-G G/E/CT — LG 1941D-G G/E/CT — LCF 1931D-G G/E/CT — LVTR 1941D-G E/CT — LVI 1931D-G E/CT

LMG 1931D-G G/E/CT — LMG 1941D-G G/E/CT — LMGF 1931D-G G/E/CT — LMVTR 1941D-G E/CT — LMVI 1931D-G E/CT




Classic



Modern




FONTENAY 1900 D « CLASSIQUE » AND « TRADITION » : GAS HOBS




▲ FONTENAY 1900 D «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▲ FONTENAY 1900 D «CLASSIQUE»: 4 gas burners

- 4 burners in a range of different sizes and powers (see Burners B,C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



▲ FONTENAY 1900 D «TRADITION»: 2 gas burners and a solid top


- 3 burners in a range of different sizes and powers (see Burners T, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

FONTENAY 1900 G « CLASSIQUE » AND « TRADITION » : GAS HOBS




- Ⓐ Power supply, electrical oven
- Ⓑ Power supply, gas oven
- Ⓒ, Ⓓ, Ⓔ Waste water connection (option)

- Ⓕ, Ⓖ, Ⓗ Water supply (option)
- Ⓘ, ⓵ Gas connection

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.


(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.




▶ FONTENAY 1900 G «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



▶ FONTENAY 1900 G «CLASSIQUE»: 4 gas burners

- 4 burners in a range of different sizes and powers (see Burners B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




▶ FONTENAY 1900 G «TRADITION»: 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET FONTENAY 1900


FONTENAY 1900 D "ÉLECTRIQUE": INDUCTION HOB



(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

►INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.


FONTENAY 1900 D "ÉLECTRIQUE": CERAMIC HOB



(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

TECHNICAL SHEET FONTENAY 1900

FONTENAY 1900 G "ÉLECTRIQUE": INDUCTION HOB




- ▲ **(A)** Electric supply
- ▲ **(B)** Waste water connection (option)
- ▲ **(E)** Water supply (option)
- ▲ **(H)** Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

▲ Body in stainless steel or enamelled steel.




▲ INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

TECHNICAL SHEET FONTENAY 1900

FONTENAY 1900 "ÉLECTRIQUE": CERAMIC HOB




- ▲ **(A)** Electric supply
- ▲ **(C)** Waste water connection (option)
- ▲ **(F)** Water supply (option)
- ▲ **(J)** Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.


▲ Body in stainless steel or enamelled steel.




▲ CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

CLOSET DOOR SPACE FONTENAY 1900 G



CLOSET DOOR SPACE FONTENAY 1900 D



Ovens:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function 2650 Convection function	Yes 2850 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power
GAS/Burner	Natural Gas - kW/h
Ultra-fast (A)	5.0 kW
Intensive (D)	4.0 kW
Fast (C)	3.0 kW
Semi-fast (B)	1.5 kW
Gas Oven 500	3.2 kW
Gas Oven 700	4 kW
	Propane Gas - kW/h
	5.0 kW
	4.0 kW
	3.0 kW
	1.5 kW
	3.7 kW
	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, C, D: **Table 5**, Appendix).

Compliance with European regulations (EC):


European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET


CITEAUX 1900

LG 1932D-G G/E/CT — LG 1942D-G G/E/CT — LCF 1932D-G G/E/CT — LVTR 1942D-G E/CT — LVI 1932D-G E/CT

LMG 1932D-G G/E/CT — LMG 1942D-G G/E/CT — LMGF 1932D-G G/E/CT — LMVTR 1942D-G E/CT — LMVI 1932D-G E/CT




Classic



Modern



CITEAUX 1900 D « CLASSIQUE » AND « TRADITION » : GAS HOBS




- (A) Power supply, electrical oven
- (B) Power supply, gas oven
- (C) (D) (E) Waste water connection (option)

- (F) (G) (H) Water supply (option)
- (I) (J) (K) Gas connection


- Body in stainless steel or enamelled steel.
- Press formed top plate.

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.
Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc); Please verify the height of your range cookers before installation.




► CITEAUX 1900 D «CLASSIQUE»: 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► CITEAUX 1900 D «CLASSIQUE»: 4 gas burners


- 4 burners in a range of different sizes and powers (see Burners B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► CITEAUX 1900 D «TRADITION»: 2 gas burners and a solid top


- 3 burners in a range of different sizes and powers (see Burners T, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET CITEAUX 1900




►CITEAUX 1900 G "CLASSIQUE": 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




►CITEAUX 1900 G "CLASSIQUE": 4 gas burners

- 4 burners in a range of different sizes and powers (see Burners B, C and D, Table 1, Appendix).
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



► CITEAUX 1900 G "TRADITION": 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, C and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.



- Ⓐ Power supply, electrical oven
Ⓑ Power supply, gas oven
Ⓒ Ⓔ Water supply (option)


- D, F** Waste water connection (option)
- G, H** Gas connection

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.

1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Laacache range cookers official height is 930 mm. Following your request, each model on your order might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

CITEAUX 1900 D "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ Electric supply
- Ⓑ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓕ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

CITEAUX 1900 D "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ Electric supply
- Ⓑ Waste water connection (option)
- Ⓓ Water supply (option)
- Ⓕ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

TECHNICAL SHEET CITEAUX 1900

CITEAUX 1900 G "ÉLECTRIQUE": INDUCTION HOB



Ⓐ Electric supply

Ⓑ Waste water connection (option)


Ⓓ Water supply (option)

Ⓕ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.



Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz


► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 3 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

TECHNICAL SHEET

TECHNICAL SHEET CITEAUX 1900

CITEAUX 1900 G "ÉLECTRIQUE": CERAMIC HOB



Ⓐ Electric supply

Ⓑ Waste water connection (option)


Ⓓ Water supply (option)

Ⓕ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB


- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

TECHNICAL SHEET

CLOSET DOOR SPACE CITEAUX 1900 G



CLOSET DOOR SPACE CITEAUX 1900 D



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function 2650 Convection function	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric fan	Enamelled steel	333 x 458 x 425	65	2300 Static function 2650 Convection function	Yes 1800 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.

Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, C, D: Table 5, Appendix).

Compliance with European regulations (EC):


European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

TECHNICAL SHEET


SULLY 2200

VEZELAY

LG 2232 G/GE/E/GCT/ECT — LCF 2232 G/GE/E/GCT/ECT — LVTR 2242 E/CT — LVI 2232 E/CT
 LMG 2232 G/GE/E/GCT/ECT — LMCF 2232 G/GE/E/GCT/ECT — LMVTR 2242 E/CT — LMVI 2232 E/CT




Classic



Modern



SULLY 2200 - VEZELAY « CLASSIQUE » AND « TRADITION » : GAS HOBS




- (A) Power supply, electrical oven
 (B) Power supply, gas oven
 (C) Water supply (option)
 (D) Waste water connection (option)
 (E) Gas connection
 (F)

- ▶ Body in stainless steel or enamelled steel.
- ▶ Press formed top plate.

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.


Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

**TECHNICAL SHEET SULLY 2200
VEZELAY**



► SULLY 2200 - VEZELAY "CLASSIQUE": 3 gas burners

- 3 burners in a range of different sizes and powers (see Burners A, B and D, Table 1, Appendix).
 - Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.




► SULLY 2200 - VEZELAY "TRADITION": 2 gas burners and a solid top

- 3 burners in a range of different sizes and powers (see Burners T, B and D, Table 1, Appendix).
- Central hob with a 385 x 510 mm solid top.
- Individually controlled by a safety valve (thermocouple).
- Electrical ignition with pushbutton.

TECHNICAL SHEET SULLY 2200 VEZELAY

TECHNICAL SHEET SULLY 2200 VEZELAY

SULLY 2200 - VEZELAY "ÉLECTRIQUE": INDUCTION HOB




- Ⓐ, Ⓑ Electrical supply
- Ⓒ, Ⓓ Waste water connection (option)
- Ⓔ, Ⓕ Water supply (option)
- Ⓖ, Ⓗ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Total power: 7400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► INDUCTION HOB

- 3 induction zones in a range of different sizes and powers under a 4 mm ceramic glass plate (heaters A, B and D, Table 2 en Appendix).
- 9 power settings.
- Booster mode in each zone.
- Fast cooking mode.
- 2 temperature holding modes: 42°C and 70°C.
- Control knobs to front of appliance.
- Energy regulator.
- Child-proof safety.
- Pan detection.
- Electronic display unit under ceramic glass plate.
- "Hot" warning displayed when the temperature of the ceramic glass plate is over 60°C.

SULLY 2200 - VEZELAY "ÉLECTRIQUE": CERAMIC HOB




- Ⓐ, Ⓑ Electrical supply
- Ⓒ, Ⓓ Waste water connection (option)
- Ⓔ, Ⓕ Water supply (option)
- Ⓖ, Ⓗ Gas connection

(1) CAUTION: The appliance height can be adjusted between 930 and 944 mm.

Lacanche range cookers official height is 930 mm. Following your request, model on your order you place might have a different height (900 mm, etc). Please verify the height of your range cookers before installation.

► Body in stainless steel or enamelled steel.




Power: 8400 W
230 V 1N~ 50 Hz/
400 V 3N~ 50 Hz

► CERAMIC HOB

- 4 radiant elements in a range of different sizes and powers under a 6 mm ceramic glass plate (heaters A, B, Table 2 en Appendix).

CLOSET DOOR SPACE SULLY 2200 / VEZELAY



Oven:

Oven type	Inside	Dimensions (mm)	Volume (l)	Power (Watt)	Electric grill	Tray levels	Safety device
Gas*	Enamelled steel	550 x 288 x 438	70	4000	No	3, 70-mm pitch	Thermocouple
Electric static	Enamelled steel	550 x 291 x 465	75	2800	Yes 2850 W	3, 70-mm pitch	Thermostat
Electric multifunction	Enamelled steel	550 x 291 x 417	67	2800 Static function 2850 Convection function	Yes 2850 W	3, 70-mm pitch	Thermostat

*Controlled by thermostatic valve.

PRESSION	Power	
GAS/Burner	Natural Gas - kW/h	Propane Gas - kW/h
Ultra-fast (A)	5.0 kW	5.0 kW
Intensive (D)	4.0 kW	4.0 kW
Fast (C)	3.0 kW	3.0 kW
Semi-fast (B)	1.5 kW	1.5 kW
Gas Oven 500	3.2 kW	3.7 kW
Gas Oven 700	4 kW	4 kW

Cupboard:

- ▶ Enamelled steel.
- ▶ Dimensions W x H x D: 328 mm x 502 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ Accessories: 2 grills.

Simmer oven:

- ▶ Enamelled sheet metal.
- ▶ Dimensions W x H x D: 328 mm x 452 mm x 535 mm.
- ▶ 5 shelf levels with 70 mm spacing i between.
- ▶ 950 W resistance heating controlled by thermal cut-off from 30 to 110 ° C.
- ▶ 2 grills.




Total power: 950 W – 230 V 1N~ 50 Hz

Pressures and supply rates:

Appliance characteristics as per nameplate and marking in the drawer (T, A, B, D: Table 5, Appendix).

Compliance with European regulations (EC):

European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.



OPTIONS

GAS BURNERS 205

CERAMIC HOB 215

INDUCTION 221





PLANCHA..... 231

CHARGRILL..... 239

MULTICOOKER 249

ELECTRIC FRIED 267





Hob top option

GAS BRANDERS

LAG 010 UR

LAG 020 R

LAG 024 R





Contents


TECHNICAL DATA	206
INSTALLATION MANUAL	207
GAS CONNECTION	208
ADJUSTMENT OF THE HOB BURNER	209
ELECTRICAL POWER CONNECTION	211
WIRING DIAGRAM	211
INSTRUCTION MANUAL	212
GAS HOB	213
CLEANING AND MAINTENANCE	213



TECHNICAL DATA


LAG010 UR: Cooking surface option with 1 burner located on left or right of central hob (depending on model).

- ▲ 1 burner : diameter 107/137 mm (See A : table 1 appendix).
- ▲ Controlled by a thermocouple safety valve .
- ▲ Mounted in a dished recess (stainless steel Z7CN 18.09).
- ▲ Electric push button ignition.



LAG 024 R & LAG 020 R: Cooking surface option with 2 burners located on left or right of central hob (depending on model).

- ▲ 2 x 4 kW burners for LAG 024 R (See B : table 1 appendix).
- ▲ 2 x 3 kW burners for LAG 020 R (See C : table 1 appendix).
- ▲ Controlled by a thermocouple safety valve .
- ▲ Mounted in a dished recess (stainless steel Z7CN 18.09).
- ▲ Electric push button ignition.



Pressures and hourly consumption:

Appliance gas supplying can be switched, please refer to rating plate and marking at the rear of the appliance (B, C : table 1, appendix 0).

Directives:

European Regulation (Gas Appliances): (EU) 2016/426.
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.



Hob top option

«LAG 010 UR»

«LAG 020 R»

«LAG 024 R»

INSTALLER'S MANUAL

The installation must be done according to the rules of the art in accordance with the instructions contained in this manual and the regulations in force in the country of installation. The instructions contained in this INSTALLATION MANUAL are intended for authorized persons, qualified professionals with a good knowledge of equipment and gas and electrical installations.

This manual will be given to the user after installation.





GAS CONNECTION

Natural gas:

Since 1st July 1997, an automatic shut-off valve must be fitted to all new installation or whenever an existing shut-off valve is replaced.

LPG (butane-propane):

Propane gas:

The installation must have a class-1 safety regulator.

Connect the appliance to the outlet of a 4 kg/h regulator. Recommended dual bottles to inlet of regulator for correct operation of the appliance during prolonged periods at full capacity. Supply from 35 kg bottle or from tank is possible and recommended (connection to appliance using approved LPG flexible hose with maximum length of 2 m).


Butane gas:

The connection must be made using a butane safety regulator fitted to the bottle (connection to appliance using approved LPG flexible hose with maximum length of 2 m).


Connect the appliance to the outlet of a 2.6 kg/h regulator. Recommended dual bottles to inlet of regulator for correct operation of the appliance during prolonged periods at full capacity.

CONNECTION:

- The appliance is equipped with a Ø15/21 male connector **(A)**, 1/2" gas, thread, to the back of the appliance.
- For a correct supply, use an approved flexible connector of suitable characteristics, such as a wire-reinforced flexible connector.



- Once connected, check the supply pressure at the pressure port **(B)**, to the back of the appliance, in one of the ends of the gas inlet manifold.
- Check the connection for leaks.



OPERATIONAL TESTS AND CHECKS:

Once connected, check that the burners operate correctly (hob and oven) and adjust as required.

CHECKING THE OPERATION OF THE HOB BURNERS:

- Check that the appliance is connected to the electrical power supply. The electrical ignition works if the appliance is connected to the electrical power supply.
- Check that the gas shut-off valve is open.

ADJUSTMENT OF THE HOB BURNER

Lacanche's gas appliances are delivered fully adjusted in compliance with relevant regulations and for use with the particular gas supply (type, pressure) stated in the purchase order and indicated in the appliance's nameplate.

Nevertheless, after connecting the appliance, the correct operation of the burners (hob and oven) must be checked. If required, the height of the flame must be adjusted accordingly.

To do this, the gas delivery rate to the burner must be adjusted by screwing in or out the valve adjustment screw located behind the control knob.

This adjustment is essential when changing the gas supply after having changed injectors (refer to Section "Change of gas").




WARNING:

The adjustment of burners must be carried out by a qualified technician.

OPERATION:


- 1 Push down on the control knob and turn it anticlockwise; press simultaneously on the ignition pushbutton.

Once the burner is lit, release the ignition pushbutton.



- 2 Still pushing down on the control knob, set it to the small flame «» setting.


After about ten seconds to allow for the engagement of the thermocouple, release the control knob.



- 3 In the low flame setting, the flame must be low, steady and covering slightly the tip of the thermocouple.

► If the flame goes off in the low flame setting, repeat the procedure. If after several attempts you are unable to hold the flame in the low flame setting, proceed to adjust the burner (refer to Section "Adjustment of the hob burners").

► If in the low flame setting, the flame is too strong, then the gas delivery rate to the burner needs to be reduced.






ADJUSTMENT OF THE HOB BURNER

ADJUSTMENT OF THE FLOW RATE:

The adjustment of the low flame gas delivery rate is carried out with the burner on and the control knob removed, using a small screwdriver to screw in or out the screw in the gas valve located behind the control.

- 1 With the burner on, set the control knob to the small flame «» setting.
- 2 Remove the control knob.



- 3 Screw in or out the gas valve screw to adjust the delivery rate for the low flame. Screwing out increases the flame. Screwing in reduces the flame.

- 4 Replace the control knob and turn it to the large flame «» setting.



- 5 Turn quickly from the large flame «» setting to the small flame «» setting.

When doing this, the flame must remain burning.

At its minimum size, the flame must be a quarter ($\frac{1}{4}$) in size of the full flame.

When this is not the case:

Repeat the procedure from 1 to 5.



ADJUSTMENT OF THE HOB BURNER

PRIMARY AIR ADJUSTMENT:

The adjustment of the primary air (air-gas mixture) is done by adjusting the air ring located in the base of the burner, under the table. The mixture is correct when the flame is stable with blue cones.






A soft flame with yellow tips is the result of lack of air.

A flame whose base is separated from the burner cap is the result of excessive air.

CAUTION: The adjustment of the air ring is done with the burner off.

To avoid all risks of burns, ensure that all components likely to be handled manually (pan stands, burner caps...) and other elements in the working area are not hot.

- ① Remove the pan stands and the solid top (for "Tradition" appliances); then remove the caps and bodies of the burners.



- ② Through the hole in the table, remove the locknut from the adjusting spigot of the air ring using a 7 mm spanner 7.

► When there is lack of air, turn the adjusting spigot clockwise to increase the opening of the air ring.

► When there is excess of air, turn the adjusting spigot anticlockwise to reduce the opening of the air ring.

- ③ Replace and tighten lightly the lock nut.

- ④ Once the adjustment completed, replace the burner body and cap and run a new test.

ADJUSTMENT OF THE FLAME SAFETY THERMOCOUPLE:

After the adjustment, when turning on a burner, if it goes off after having kept the control knob pushed down for 20 seconds and then releasing, check that :

- The tip of the thermocouple is well covered by the flame and does not touch the burner;
- The thermocouples and magnetic heads are clean.
- The magnetic head is tightened correctly (moderate torque).

ELECTRICAL POWER CONNECTION

The installation must be carried out in accordance with recognised best practices, the instructions given in this manual and the regulations in force in the country of installation.

The means for disconnection must be provided in fixed installations in accordance with all relevant regulations.

BEFORE CONNECTION:

Check that:

- ☞ The mains supply is compatible with the voltage and power of the appliance.
- ☞ The user's fixed installation features an approved main isolating device acting on all phases.





CONNECTION:

- Use a standard flexible cable (245 IEC 57 or 245 IEC 66, or any other cable with the same characteristics).
- The power supply cables between the isolating traction device and the terminals must be of such lengths as to ensure in the event of traction that the live cables become taut before the earth cable.
- If the appliance is permanently connected to a fixed electrical installation, this installation must be fitted with a suitable leakage current protection device.
- If the appliance is connected with a cable fitted with a plug, the socket must be accessible at all times.

- ① Remove the cover(s) from the back of the appliance identified by the label .

- ② Pass the lead through the grommet.

- ③ Connect a standard cable suitable for the voltage to the terminals.
(Ensure that the jumper connectors are correctly fitted).



- ④ Set each wire one by one in the power strip and if necessary set the shunt clips.
Tighten each plug separately to the maximum.


- ⑤ Secure the cable with the cable clamps.

! It is dangerous to operate the appliance without having it properly earthed.

We cannot be held responsible for accidents due to missing or incorrect earth connection.

WIRING DIAGRAM

For references and descriptions of the various components refer to table 9 in appendix.



Note: Ignition controller terminal lugs not in use are to be grounded.

Hob top option

«LAG 010 UR»

«LAG 020 R»

«LAG 024 R»

USER'S MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

Any changeover to a gas other than that for which the cooker is set up must be carried out by a qualified installer.

Any change of voltage from that for which the appliance is set up must be carried out by a qualified installer.

WARRANTY

The warranty is part of the sale contract. For any warranty work, please contact an authorized reseller. This warranty does not cover damage due to faulty installation, misuse or inadequate maintenance.



Use:



Simultaneously press in and turn the burner dial anti-clockwise to setting «».

Press the ignition button while maintaining pressure on burner dial for about 20 seconds to ignite burner and initialise safety thermocouple.



When the burner is lit, release the knob.

Turn the knob to the desired power.

Release the knob.



A reduced flowrate position identified by the «» mark produces the preset minimum burner power (low flame).



To turn off, turn the control knob clockwise to the «» position.

The control knob returns to its initial position, the latching mechanism operates and the gas safety cut-out is activated several seconds after the burner goes out.

Useful hint:

Always choose a burner that matches the diameter of the utensil used.

CAUTION: During use of the cooking surface, accessible parts may become very hot during use. Warn users of the potential risks.

CLEANING AND MAINTENANCE

Before any cleaning work, close the gas supply and/or isolate from the mains electricities supply

WARNING Do not use a steam cleaner to clean the range.

Gas hobs:

The burners are made in two parts in order to facilitate cleaning. Clean them separately.

→ Burner cap:

Burner caps are made of solid brass. Use a special brass-cleaning product (e.g. MIROR® or BRASSO®) and a soft cloth.

If the product runs onto the enamel do not rub (these products generally contain abrasives). Rinse immediately with clean water without rubbing.

If the caps are very dirty polish them with very fine sand paper and then rub them with a copper cleaner.




→ Burner body:

The aluminium bodies of the burners become stained with use. They should be cleaned regularly with a scouring pad (Scotch Brite®).

After removing the pan supports and burners, the cooking surface can be cleaned easily and thoroughly by simply using a sponge.

Do not use scouring pads or abrasive products such as oven cleaners and stain removers.

When cleaning, be careful not to splash liquid into the openings of the burners.



Hob top option

CERAMIC HOB

LAE 020 VTR





Summary

TECHNICAL DATA	216
INSTALLER'S MANUAL	217
ELECTRICAL POWER CONNECTION	218
WIRING DIAGRAM	218
USER'S MANUAL	219
CERAMIC HOB	220
CLEANING AND MAINTENANCE	220




TECHNICAL DATA

Radiant rings:

Option with 2 radiant rings located on left or right of central hob (depending on model):

- ▶ Stainless steel Z7CN18.09 hob.
- ▶ 2 radiant rings of different power individually controlled by a 6-position selector switch or variable power control.



Item No.	Diameter (mm)	Power (kW)	Control
A	210	2,1	Variable power control
B	140 / 210	1,0 / 2,1	Switch

Item No.	P	U	I
LAE 020 VTR	4,2 kW	230 V1N~ 50 Hz + T / E 400 V3N~ 50 Hz + T / E	18,30 A 9,15 A

Compliance with European regulations (EC):

Electrical Directive (Low Voltage): 2014/35 / EU.

Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.



Hob top option

"LAE 020 VTR»

INSTALLER'S MANUAL

The installation must be done according to the rules of the art in accordance with the instructions contained in this manual and the regulations in force in the country of installation. The instructions contained in this INSTALLATION MANUAL are intended for authorized persons, qualified professionals with a good knowledge of equipment and gas and electrical installations.

This manual will be given to the user after installation.



ELECTRICAL POWER CONNECTION

The installation must be carried out in accordance with recognised best practices, the instructions given in this manual and the regulations in force in the country of installation.

The means for disconnection must be provided in fixed installations in accordance with all relevant regulations.


BEFORE CONNECTION:

Check that:

- ☞ The mains supply is compatible with the voltage and power of the appliance.
- ☞ The user's fixed installation features an approved main isolating device acting on all phases.

CONNECTION:


- Use a standard flexible cable (245 IEC 57 or 245 IEC 66, or any other cable with the same characteristics).
- The power supply cables between the isolating traction device and the terminals must be of such lengths as to ensure in the event of traction that the live cables become taut before the earth cable.
- If the appliance is permanently connected to a fixed electrical installation, this installation must be fitted with a suitable leakage current protection device.
- If the appliance is connected with a cable fitted with a plug, the socket must be accessible at all times.
- Remove the cover(s) **A** from the back of the appliance identified by the label **⚡**.
- Connect a standard cable suitable for the voltage to the terminals. (Ensure that the jumper connectors are correctly fitted) **B**.
- Secure the cable with the cable clamp **C**.
- Pass the lead through the grommet **D**.



We cannot be held responsible for accidents due to missing or incorrect earth connection.

WIRING DIAGRAM

For references and descriptions of the various components refer to table 9 in appendix.





Hob top option

"LAE 020 VTR»

USER'S MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

This device is intended for use in domestic and similar applications such as:

- kitchen corners reserved for staff in shops, offices and other professional environments,
- in farms,
- the use by customers of hotels, motels and other residential environments,
- Bed and Breakfast type environments,

Any change of voltage from that for which the appliance is set up must be carried out by a qualified installer.

WARRANTY

The warranty is part of the sale contract. For any warranty work, please contact an authorized reseller. This warranty does not cover damage due to faulty installation, misuse or inadequate maintenance.



Use:

Select the control knob for the chosen radiant heater, the adjacent indicator light is switched on.

Single heater:

Depending on quantity, start cooking at setting 6, and reduce to a lower setting depending on the type of cooking.

As reference, recommended settings:

- 1 & 2 = Hold or reheat prepared dishes.
- 3 & 4 = Simmer or steady cooking.
- 5 & 6 = Seal the food.

Double heater:

Set the control knob at setting 10; when the heater starts to radiate, turn to the setting required for the dish being prepared.

For maximum power from the double heater, turn the control knob to MAXI.

For total control of this heater, turn back (settings 1 to 10).

To switch off the additional radiant element, turn back to setting 0.

Advice:



Use cooking vessels with flat and smooth bottom to avoid scratching the glass plate.

Choose a size of vessel suited to the needs. The bottom diameter of the vessel must be the same as or slightly larger than the marking printed on the glass plate.

 Do not leave and empty enamelled or aluminium vessel on a heater.

 Do not leave packaging material over aluminium directly on the glass plate; this could cause permanent damage to the appliance.

 Avoid spilling sugar or syrup; remove them immediately if they occur, otherwise they could cause small burst with projections of particles.



CLEANING AND MAINTENANCE

Before cleaning, shut off the gas supply and/or switch off the electricity supply.

Do not clean this appliance with chlorinated products.

Read carefully the warnings and directions of use of the products you use for cleaning and maintaining the appliance. Observe all directions of use.

Radiant Electric ring:

Hotplates must ALWAYS be kept dry. Wipe your pans before placing them on the hotplates.

Limescale can be removed by using white wine vinegar. Cover the marks with a cloth soaked in wine vinegar and leave for 1/2 h before carefully rinsing and drying.

Marks made by metal or superficial deposits which remain after the standard cleaning described above can be removed by using a liquid product for cleaning stainless steel pans (e.g. cream stainless steel ZIP®, stainless steel PPZ®, etc.).

The stainless steel frame can be cleaned by using a damp sponge with a mild detergent for stubborn marks (e.g. CIF Ammoniacal®, etc.).

If any sugar-based syrup falls on the glass ceramic hob during use, leave the element switched to position 1, and, using a razor blade scraper (such as CERA Quick) IMMEDIATELY remove the remaining burnt-on layer.





CAUTION

If there is any visible sign of a surface crack, immediately isolate appliance from the electrical supply to prevent risk of electric shock. Contact your installer.

Body panels:

You can use special-purpose products for stainless steel (e.g. SUMAINOX®, JOHNSON STAINLESS STEEL®, PPZ STAINLESS STEEL®). Never use abrasive products.

CAUTION : Use NO chlorinated cleansers to clean this unit.



Hob top option

INDUCTION

LAE 020 I





Contents


TECHNICAL DATA	222
INSTALLER'S MANUAL	223
ELECTRICAL CONNECTION	224
ELECTRICAL CIRCUIT DIAGRAM	224
USER'S MANUAL	225
USE	226
CLEANING AND MAINTENANCE	229



TECHNICAL DATA

Induction rings: Option with 2 induction rings located on left or right of central hob (depending on model)

- ▶ 2 Induction zones of different sizes and power under a 4 mm glass-ceramic surface (Hob A , B table 2 in appendix)
- ▶ 9 power selections.
- ▶ “Booster” function on each induction zone.
- ▶ Programmable temperature setting with function accelerator.
- ▶ Warming functions (at approximately 42°C and 70°C in the bottom recipient)
- ▶ Classic Lacanche knob hob controls.
- ▶ Digital power display.
- ▶ Child safety function.
- ▶ Safety warming temperature setting with function accelerator (above 60 °C).



Item N°	Diameter (mm)	Power (kW)	Booster (kW)
A	180	1,85	3,0
B	210	1,85	3,0

Part number	P	U	I
LAE 020 I	3,7 kW	230 V1N~ 50 Hz + T 400 V3N~ 50 Hz + T	16 A 5,3 A

Compliance with European regulations (EC):

Electrical Directive (Low Voltage): 2014/35 / EU.

Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

Hob top option

«LAE O2O I»

INSTALLER’S MANUAL

The installation must be done according to the rules of the art in accordance with the instructions contained in this manual and the regulations in force in the country of installation. The instructions contained in this INSTALLATION MANUAL are intended for authorized persons, qualified professionals with a good knowledge of equipment and gas and electrical installations.

This manual will be given to the user after installation.



ELECTRICAL CONNECTION

The installation must be carried out in accordance with recognised best practices, the instructions given in this manual and the regulations in force in the country of installation.

The means for disconnection must be provided in fixed installations in accordance with all relevant regulations.


BEFORE CONNECTION:

Check that:

- ☞ The mains supply is compatible with the voltage and power of the appliance.
- ☞ The user's fixed installation features an approved main isolating device acting on all phases.

CONNECTION:


- Use a standard flexible cable (245 IEC 57 or 245 IEC 66, or any other cable with the same characteristics).
- The power supply cables between the isolating traction device and the terminals must be of such lengths as to ensure in the event of traction that the live cables become taut before the earth cable.
- If the appliance is permanently connected to a fixed electrical installation, this installation must be fitted with a suitable leakage current protection device.
- If the appliance is connected with a cable fitted with a plug, the socket must be accessible at all times.
- Remove the cover(s) **A** from the back of the appliance identified by the label **A**.
- Connect a standard cable suitable for the voltage to the terminals. (Ensure that the jumper connectors are correctly fitted) **B**.
- Secure the cable with the cable clamp **C**.
- Pass the lead through the grommet **D**.



We cannot be held responsible for accidents due to missing or incorrect earth connection.

ELECTRICAL CIRCUIT DIAGRAM

For references and descriptions of the various components refer to table 9 in appendix 0.



Hob top option

«LAE 020 I»

USER’S MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

This device is intended for use in domestic and similar applications such as:

- kitchen corners reserved for staff in shops, offices and other professional environments,
- in farms,
- the use by customers of hotels, motels and other residential environments,
- Bed and Breakfast type environments,

Any change of voltage from that for which the appliance is set up must be carried out by a qualified installer.

WARRANTY

The warranty is part of the sale contract. For any warranty work, please contact an authorized reseller. This warranty does not cover damage due to faulty installation, misuse or inadequate maintenance.



INDUCTION

The vitro-ceramic covered induction hotplate is a revolutionary piece of cooking equipment. An induction ring or zone consists of an induction unit placed underneath a vitro-ceramic hob top. The unit is powered by means of a high-frequency AC current. Energy is transmitted electromagnetically to the cookware on the hob top. This magnetic field passes through the cooking surface into the bottom of your pans. The induction hob is used exactly like cast-iron or standard vitro-ceramic hobs. The differences are as follows:

- During cooking heat is generated inside the pans. The ceramic hob gets hot only as heat is reflected by the pans. It is not directly heated by induction.
- The induction unit only operates if there is contact between the induction zone and the pan in the cooking zone
- Reaction to adjustments is immediate, enabling the temperature to be changed quickly and accurately.

The electronic controls mean that the heat can be changed very accurately. The great efficiency of the system means that it is cheap to run and improves comfort for the user as it heats the pan, not the surrounding kitchen.

Some pans may make noise when placed on an induction cooking zone. These noises do not translate into any fault of the device and have no influence on its operation.

Cleaning induction hotplates is very easy since when pans boil over, the food they contain does not burn on the cooking surface.

Description:

The induction hob version comprises a 4 mm thick vitroceramic plate equipped, according to the model, with the following :


- one 1,85 kW zone Ø 145 mm and a 3,0 kW booster function (T).
- one 1,85 kW zone Ø 200 mm (B) and a 3,0 kW booster function.

Induction unit are fitted with:

- a rotating encoder control that gives 9 power selections
- an electronic display of the power being used.
- 2 warming positions (at approximately 42°C and 70°C in the recipient).
- Accelerator to pre-selected heat setting and then automatically switches to the preset power level.
- Booster function.
- Child safety function.
- Overheating cut out.

Note : Each ring is fitted with a waste heat indicator lamp. These lamps light up a short time after the corresponding unit has been switched on and go out when the heat in the zone of the ring has dropped to a value that no longer constitutes a risk to users (approximately 60°C) : Is the Message «Hot».

A ventilator is located underneath the table, to refresh air for an optimum power of all units.



INDUCTION

USE:

Place food in pan.


Turn the control knob of the ring required (clockwise).

The power level is set on the display.

LA's heating is very rapid, select the target heat required immediately (i.e. no need to increase heat in stages).

The various positions are best suited to the following examples of cooking operations:

Positions	Use
1 & 2	Keeping food warm or preparing sauces.
3 & 4	Gentle simmer or maintain cooking
5 & 6	Sustained simmer or cooking pasta or rice once water has boiled.
7	Frying.
8	Browning or seizing meat.
9	Bring to or maintain rolling boil.
P	Booster = Brings liquid to boil quickly.
R	Potency level 9 during time to reach the temperature of the level preset then commutes automatically at the level of potency chosen.
u	Assertion in temperature (42°C).
U	Assertion in temperature (70°C).



While in use, if the pan is removed from the cooking zone, the power is cut automatically, the symbol **u** is displayed. To stop this symbol, you have to cut the burner supply by positioning the knob to 0. Prior to this decision, if the pan is repositioned on the burner, the power automatically restarts.



The display shows the letter **u**.

INDUCTION

BOOSTER FUNCTION:

The «Booster» can speed the rise of power of the induction burner. It is controlled by positioning the lever on the landmark P. During 10 minutes, the maximum power of the burner is obtained.



The display shows the letter P.

After 10 minutes, the power is reset to level 9.



The display shows the number 9.

Note:

In case of simultaneous operation of dual induction burners, (Front / Rear), the Booster function can only be achieved on only one of the selected burners. The Booster function remains active on the last selected burner.

ACCELERATOR FUNCTION:

The Accelerator function allows to be on level 9 for a few minutes then switch automatically back to the level of the selected power.




To use the accelerator function: from the position 0, turn the knob on the left (slight turn to the left).



The display shows the letter A.

Set the knob to the desired power level.

Selected power level	8	7	6	5	4	3	2
Acceleration duration	3 min. 40	2 min. 50	2 min.	6 min. 50	5 min.	4 min.	2 min. 30



INDUCTION

ACTIVATING THE CHILD SAFETY FUNCTION:

Single heater :
Replace the knobs to zero, turn the knob of the burner anti-clockwise and hold in this position until activation (2 seconds approximately) This feature is symbolized by an L display.



Double heater : Turn the two right induction control knobs anti-clockwise and hold in this position for a couple of seconds to activate of child security function (signalled by the letter L). The child safety function is now active for the two right induction rings. If the control knobs for the two right zones are now turned, nothing will happen.



DESACTIVATE CHILD SAFETY:

Single heater : Repeating the process described above to a zone wich has been made safe, will re-activate the zone and the letter L will go out.

Double heaters :

To desactivate the child safety, turn the two handles of both burners in the anti-clockwise and hold it until the deactivation of the child safety function.





The letter L will go out.

OVER HEATING CUT OUT:

In case of overheating, the system will trip and render the burner innoperative.

In that case:

- Reset the controller of the burner in question to 0.
- Remove the pan from burner.
- Wait for the burner to cool before re-use.



INDUCTION

RECOMMENDATIONS:

- Heating is extremely fast.
- We advise you to keep a careful eye on your dishes until you are familiar with to induction cooking.
- Never leave oil or other greases to heat unattended.
- We recommend for maximum efficiency of the induction hob to match the diameter of the cookware to the diameter of the circle printed on the glass-ceramic surface, particularly when using small ring. When using a cookware of larger diameter than the printed zone, offset the cookware towards the rear of the printed circle.
- We advise against the use of cookware without a fully flat bottom; some pans have engravings, which may decrease efficiency.
- Disregarding these precautions may decrease the efficiency of your induction hob.
- Your food will not cook efficiently unless your pan is ferromagnetic and in direct contact with the selected induction zone. Ferromagnetic means iron/ steel cookware check to see if a magnet sticks to it.
- Avoid scratching the cooking surface with metallic or abrasive objects.
- If you remove a pan from the cooking zone for a moment the display flashes. It is advisable to turn off the power.
- If the pan is repositioned on the zone, power restarts automatically at the same level and the flashing ceases.

 Never place or leave enamelled, aluminium or any other type of empty pan on a heating zone. Similarly you should not place aluminium-packed products/ tin foil directly on the surface; this can do irreparable damage to your cooker.

 Do not place unopened tins directly on a hotplate as this could cause them to explode under pressure.

 Never obstruct ventilation zones (front panel, rear ventilation, etc.). The cooker may overheat and become less efficient. Furthermore you shorten the service life of your hob.

 Do not store aerosols or flammable products under the cooking surface.

- Use a magnet to check that your pans are ferromagnetic. If they stick to the magnet, you can use them on induction hotplates.
- Do not hang heavy items over the cooking surface. They can damage the vitro-ceramic surface if they fall.
- Never apply more heat than can be absorbed by the food: too much heat causes loss of water, grease and wastes energy.
- Whenever the recipe permits, cover your cookware with a lid in order to save energy.

SAFETY:

- The latest scientific research has found that people fitted with a heart pacemaker are not at risk from using induction cookers. However, if an induction cooker is used improperly a slight risk cannot be ruled out.

INDUCTION

- It is for this reason that we advise people with pacemakers to consult their physician before using an induction cooker.
- Avoid all contact between jewellery (rings, chains, etc.) and the cooking surface while it is switched on; it could cause jewellery to heat.
- **CAUTION:**
- **If a visible crack appears in the vitro-ceramic surface of your hob, immediately disconnect the power supply and contact your installer.**

DISPLAY:

E	The sensor for a particular hotplate is not working.	The rest of the surface can nevertheless continue functioning correctly - Contact your retailer
Hot	Residual temperature	Indicates that the zone is hot - The display goes out when the temp has dropped below 60°C
	Pan undetected	No pan or pans unsuitable for induction cooking
U	Temperature hold: 70 °C	-
U	Temperature hold: 42 °C	-
P	Booster function	This function is only available on hotplates A and B.
L	Child safety function	This function is activated and deactivated by holding the knob in position "A".
L	Fault detected in the induction system	This function is activated and deactivated by holding the knob in position "A". Check the control encoder connectors. Check the connection to the encoders and inductors and for any damaged or cut wires.

IF THE INDUCTION COOKER DOES NOT WORK:

- Check your pans.
- First switch off the cooker. Then check ventilation of the generator
- First switch off the cooker. Then check the power supply and electrical connectors.



CLEANING AND MAINTENANCE

Before cleaning, shut off the electricity supply.

Do not clean this appliance with chlorinated products.

Read carefully the warnings and directions of use of the products you use for cleaning and maintaining the appliance.

Observe all directions of use.

Ceramic hob:

The hob must **ALWAYS** be kept completely dry. Wipe your pans dry before putting them on the hob. Trace of limescale can be removed using white vinegar. Cover the stains with a damp cloth, leave for half an hour, and then rinse and dry carefully.

Stainless steel surfaces are cleaned with a wet sponge, adding a mild detergent to remove tough stains (for instance, CIF®...).

If during use, sugar syrup is spilled on the ceramic hob surface, turn the heating element to setting "1", and remove **IMMEDIATELY** the burnt deposit using a razor scraper (for instance, CERA Quick®);






WARNING:

If a crack appears on the surface, disconnect immediately the appliance from its power supply to avoid the risks of electric shocks. Contact your installer.

Main body:

You can use special products for stainless steel (for instance ZIP stainless steel®, JOHNSON stainless steel®, PPZ stainless steel®); never use abrasive products.

CAUTION: Do not use a steam generator for cleaning the appliance.



Hob top option

PLANCHA

LAE 010 TPK





Contents


TECHNICAL DATA	232
INSTALLER'S MANUAL	233
ELECTRICAL CIRCUIT DIAGRAM	234
SERVICING	234
USER'S MANUAL	235
USE	236
CLEANING AND MAINTENANCE	237



TECHNICAL DATA

Plancha : Optional plate, smooth grill plate to the left or right of the central cooking surface

- ▲ Plancha mild-steel .
- ▲ Dimensions 515 mm x 360 mm.
- ▲ 35-micron satin-finish chrome coating.
- ▲ The heat is generated by a 2200 W resistor, controlled by the thermostat.
- ▲ Limit-control plate protection.



Item No.	P	U	I
LAE 010 TPK	2,2 kW	230 V1N~ 50 Hz + T / E 400 V3N~ 50 Hz + T / E	9,10 A 5,50 A

Compliance with European regulations (EC):
Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

Hob top option

«LAE 010 TPK»

INSTALLER’S MANUAL


The installation must be done according to the rules of the art in accordance with the instructions contained in this manual and the regulations in force in the country of installation. The instructions contained in this INSTALLATION MANUAL are intended for authorized persons, qualified professionals with a good knowledge of equipment and gas and electrical installations.

This manual will be given to the user after installation.



ELECTRICAL CIRCUIT DIAGRAM




For references and descriptions of the various components refer to table 9 in appendix.



ELECTRICAL CIRCUIT DIAGRAM

Resetting the safety thermostat in the ELECTRIC HOB:

- Open the oven / hot cupboard door(s).
- Using a flat screwdriver, loosen without removing the two threaded spigots located under the air vent strip at either end.
- Pull the table slightly outward.
- Lift the table.
- Maintain safety by securing the table in the open position with a suitable pro.
- The red push button is located behind the air vent strip.
- Press the red push button using a screwdriver.



Do not touch any part other than the red button!

Hob top option

«LAE 010 TPK»

USER’S MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

This device is intended for use in domestic and similar applications such as:

- kitchen corners reserved for staff in shops, offices and other professional environments,
- in farms,
- the use by customers of hotels, motels and other residential environments,
- Bed and Breakfast type environments,

Any changeover to a voltage other than that for which the cooker is set up must be carried out by a qualified engineer.

WARRANTY

The warranty is stated on the sales contract. Please contact your approved Dealer if any work has to be carried out under warranty.

This warranty excludes damage resulting from incorrect installation, improper use or inadequate servicing.





USE

Before using for the first time

- Remove the plastic protection.
- Initial usage will cause some smoke and is no cause for alarm.

Use:

- Toggle switch.
Position 0 = off.
Position 1 = on.
- Turn dial clockwise to preferred temperature.
- Turn dial anti clockwise to reduce temperature.
- To shut down, turn dial anti clockwise, then toggle switch.



Recommendations:

- Oil griddle prior to use with a good quality vegetable oil, a few seconds before cooking begins.
- Plancha is perfect for :
 - pieces of meat (steaks, chops, sirloin steaks, medallions, meatballs, Chinese-style meat, etc.)
 - fish (fillets, lobsters and prawns, sardines, salmon and other fish steaks, etc.). We recommend you flour cod, hake, etc. type filets and use the cover (special option) to finish the cooking. For fish seared on one side (filet with one side skin), cook them on the skin side without turning them over.
 - even vegetables (thinly sliced vegetables such as leeks, mushrooms, peppers, courgettes, etc.)
- For successive cooking operations use the scraper to remove any residue from the heating area.
- To avoid scratches we advise against cutting food directly on the pan.

USE

Information on the cooking time:

		Thermostat	Cooking time
Fish and shellfish	Fresh floured hake filets	230	3 minutes
	Cod filets	230	5 minutes
	Trout filet seared on one side, cooking finished under the cover	230	1.5 minutes
	Whole trout	230	11.5 minutes
Meat	Fresh prawns	230	8 minutes
	Fresh calf liver	230	3 minutes
	Pork chops, cooking finished under the cover	Maxi	6.5 minutes
	Minced beef	Maxi	3.5 minutes
Vegetables	Whole steak	Maxi	3.5 minutes
	Finely chopped vegetables, cooking under the cover: Carrots, onions, peppers	150	20 minutes
	Diced potato	150	20 minutes

(values stated for information only)

Turn on the plancha 10 minutes before cooking to get to temperature.



CLEANING AND MAINTENANCE

Before any cleaning work, isolate from the mains supply

Do not use a steam cleaner to clean the appliance.

Wait until the fire tray has at least partially cooled.

The surface of the heating element may have residual heat after use. It is necessary to ensure the cooling of the resistance before any manipulation.

Plate:

Let cool and use wooden spatula to clean plate, then rinse with water or use coarse salt and a rag. Grease and wipe.





You can also use a non-metallic abrasive sponge (eg Scotch ® britt) white vinegar and alcohol to bleach the plate.

CAUTION : Do not use metal utensils or abrasive cleaning products on the hard chromium steel hot-plate. The plancha surfac will form a patina with user time

Body panels:

You can use special-purpose products for stainless steel (e.g. SUMAINOX ®, JOHNSON STAINLESS STEEL ®, PPZ STAINLESS STEEL ®). Never use abrasive products.

CAUTION : Use NO chlorinated cleansers to clean this unit.



Hob top option

GAS CHARGRIL

ELECTRIC CHARGRILL

LAG 010 CKG

LAE 010 CKG





Contents

TECHNICAL DATA LAG 010 CKG	240
INSTALLER'S MANUAL LAG 010 CKG	241
ADJUSTMENT OF THE HOB BURNER	242
CHANGE OF GAS	242
GAS CIRCUIT	243
ELECTRICAL CIRCUIT DIAGRAM	243
INSTALLER'S MANUAL LAE 010 CKG	244
INSTALLER'S MANUAL LAE 010 CKG	244
ELECTRICAL CONNECTION	245
ELECTRICAL CIRCUIT DIAGRAM	245
USER'S MANUAL	246
GAS CHARGRILL LAG 010 CKG	247
ELECTRIC CHARGRILL LAE 010 CKG	247
CLEANING AND MAINTENANCE	248

TECHNICAL DATA LAG 010 CKG

Charcoal: Hop top, gas lava rock chargrill left or right of central hob (depending on model).

- ▶ A 4-kW gas burner, controlled by a thermocouple safety valve.
- ▶ A 260 x 460 mm grill resting on pillars is located above the fire tray.
- ▶ Electric push button ignition.



Electrical power supply:

230 V 1N~ 50 Hz + T / 400 V 3N~ 50 Hz + T (non switchable). Connect to base unit if other options are electrical.

Pressures and hourly consumption:

The gas lava rock chargrill can operate from a supply of either mains gas or LPG but it must be configured for either, please refer to power plate and marking at the rear of the range (**CKG** : table 3, appendix).

Directives:

European Regulation (Gas Appliances): (EU) 2016/426.

Electrical Directive (Low Voltage): 2014/35 / EU.

Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

Hob top option

«LAG 010 CKG»

INSTALLER’S MANUAL

The installation must be done according to the rules of the art in accordance with the instructions contained in this manual and the regulations in force in the country of installation. The instructions contained in this INSTALLATION MANUAL are intended for authorized persons, qualified professionals with a good knowledge of equipment and gas and electrical installations.

This manual will be given to the user after installation.



ADJUSTMENT OF THE HOB BURNER

Lacanche's gas appliances are delivered fully adjusted in compliance with relevant regulations and for use with the particular gas supply (type, pressure) stated in the purchase order and indicated in the appliance's nameplate.

Nevertheless, after connecting the appliance, the correct operation of the burners (hob and oven) must be checked. If required, the height of the flame must be adjusted accordingly.

To do this, the gas delivery rate to the burner must be adjusted by screwing in or out the valve adjustment screw located behind the control knob.

This adjustment is essential when changing the gas supply after having changed injectors (refer to Section "Change of gas").



WARNING:

The adjustment of burners must be carried out by a qualified technician.

OPERATION:


- ① Push down on the control knob and turn it anticlockwise; press simultaneously on the ignition pushbutton.

Once the burner is lit, release the ignition pushbutton.



- ② Still pushing down on the control knob, set it to the small flame «L» setting.


After about ten seconds to allow for the engagement of the thermocouple, release the control knob.



- ③ In the low flame setting, the flame must be low, steady and covering slightly the tip of the thermocouple.

► If the flame goes off in the low flame setting, repeat the procedure. If after several attempts you are unable to hold the flame in the low flame setting, proceed to adjust the burner (refer to Section "Adjustment of the hob burners").

► If in the low flame setting, the flame is too strong, then the gas delivery rate to the burner needs to be reduced.



CHANGE OF GAS


Lacanche's gas appliances are delivered fully adjusted in compliance with relevant regulations and for use with the particular gas supply (type, pressure) stated in the purchase order and indicated in the appliance's nameplate.

The diameter of the injectors are suitable for the power of the burners and the gas supply (refer to Table 6 in the annex).

When changing the type of gas, the injector must be changed (hob and oven burners), and the primary air and the flow rate of the burners must also be adjusted.

CHANGING THE BURNER INJECTORS:

- ① Open the table (refer to Section "Opening and closure of the gas hob table").
- ② Using a 2 mm Allen key, loosen without removing the set screw to release the injector holder.
- ③ Remove the injector holder from the burner.
- ④ Using a 7 mm key, remove the screw that holds the burner.
- ⑤ Remove the burner by pulling it towards the front and lifting its back.
- ⑥ Through the opening exposed after the removal of the burner, remove the injector:
 - Using a 16 mm spanner, hold the injector holder.
 - Using a 12 mm spanner, unscrew the injector.



- ⑦ Replace the seal and the injector.

When refitting the injector holder, ensure that it is correctly located at the bottom of the burner.

Check the circuit for leaks.

Adjust the position of the burner to maintain the 2 mm gap between the thermocouple and the burner.


- ⑧ Proceed to the adjustment of the burners (refer to Section "Adjustment of the hob burners").

► Adjustment of the low flame flow rate.

► Adjustment of the primary air.


► Adjustment of the thermocouples.

GAS CIRCUIT



ELECTRICAL CIRCUIT DIAGRAM

For references and descriptions of the various components refer to table 9 in appendix.





Note: Ignition controller terminal lugs not in use are to be grounded.



TECHNICAL DATA LAE 010 CKG

Charcoal: Hob top, electric chargrill left or right of central hob (depending on model).

- ▶ Power: 2.5 kW.
- ▶ A 260 x 460 mm grill resting on pillars is located above the fire tray.



Hob top option

«LAE 010 CKG»

INSTALLER'S MANUAL

The installation must be done according to the rules of the art in accordance with the instructions contained in this manual and the regulations in force in the country of installation. The instructions contained in this INSTALLATION MANUAL are intended for authorized persons, qualified professionals with a good knowledge of equipment and gas and electrical installations.

This manual will be given to the user after installation.

Electrical power supply:

230 V 1N~ 50 Hz + T (non switchable). Connect to base unit if other options are electrical.

Directives:

Electrical Directive (Low Voltage): 2014/35 / EU.
Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.



ELECTRICAL CONNECTION

The installation must be carried out in accordance with recognised best practices, the instructions given in this manual and the regulations in force in the country of installation.

BEFORE CONNECTION:

Check that:

- ✓ The mains supply is compatible with the voltage and power of the appliance.
- ✓ The user's fixed installation features an approved main isolating device acting on all phases.

Electrical power supply:


230 V 1N~ 50 Hz + T (non switchable). Connect to base unit if other options are electrical.



It is dangerous to operate the appliance without having it properly earthed.

ELECTRICAL CIRCUIT DIAGRAM

For references and descriptions of the various components refer to table 9 in appendix.



Hob top options

«LAG 010 CKG»

«LAE 010 CKG»

USER’S MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

This device is intended for use in domestic and similar applications such as:

- kitchen corners reserved for staff in shops, offices and other professional environments,
- in farms,
- the use by customers of hotels, motels and other residential environments,
- Bed and Breakfast type environments,

Any changeover to a gas other than that for which the cooker is set up must be carried out by a qualified installer.

Any changeover to a voltage other than that for which the cooker is set up must be carried out by a qualified engineer.

WARRANTY

The warranty is stated on the sales contract. Please contact your approved Dealer if any work has to be carried out under warranty.

This warranty excludes damage resulting from incorrect installation, improper use or inadequate servicing.



Before use, it is imperative to remove all the internal and external plastic packaging & coating, failure to do so will cause irreversible damage to the steel body.
Initial usage will cause some smoke and is no cause for alarm.

CAUTION: During use of the cooking surface, accessible parts may become very hot during use. Warn users of the potential risks.

Use:



Simultaneously press in and turn the burner dial anti-clockwise to setting «»

Press the ignition button while maintaining pressure on burner dial for about 20 seconds to ignite burner and initialise safety thermocouple.

When the burner is lit, release the knob.

Turn the knob to the desired power.




Release the knob.



A reduced flowrate position identified by the «» mark produces the preset minimum burner power (low flame).

To turn off, turn the control knob clockwise to the «O» position.

The control knob returns to its initial position, the latching mechanism operates and the gas safety cut-out is activated several seconds after the burner goes out.



Useful hint:

CAUTION:

- Use no oils or fats when cooking over lava rock as these may burn and smoke.
- Untrimmed fat may burn and smoke; simply move the food away from the flame.
- The grill can be fixed in a higher or lower position for fast or slow cooking.


Use:

- Press the switch.
- Turn the knob clockwise to the desired position.
- Put the knob in the proper position for cooking your food according to the quantity and nature.
- To switch off, turn the control knob to the "O" position.

Grilled meat tips:

- Do not score or «spear» the cut or it will lose its juices.
- Use tongs not a fork to turn and clean the grill with a brush between each cooking to avoid the meat sticking to the griddle.

CAUTION: Use oven gloves when taking hold of the grill brass handles to prevent burns.



Recommended temperatures:

Very hot:

Use for thin pieces or for bleu and red pieces.

Hot:

For medium sized piece or medium-thick cuts cooked medium.

Medium:

Thick pieces (e.g., ribs of beef) should not be seared too quickly to avoid a well-browned outside and a raw inside.

Grilles lengthwise and crosswise:

Cuts can be grilled length- and crosswise once or twice; twice will more evenly distributed the juices and produce a better result.



CLEANING AND MAINTENANCE

Before any cleaning work, close the gas supply and/or isolate from the mains electricities supply

Do not use a steam cleaner to clean the range.

Wait until the fire tray has at least partially cooled.

Cooking grill:





After use, scrub the grill on which the food has grilled with a metal brush, while still hot.

Ashes grease trap fall into the ash-drawer, which may be pulled out completely for emptying.

Body panels:

You can use special-purpose products for stainless steel (e.g. SUMAINOX[®], JOHNSON STAINLESS STEEL[®], PPZ STAINLESS STEEL[®]). Never use abrasive products.

CAUTION: Use NO chlorinated cleansers to clean this unit.



Multicooker Module

MULTI-COOKER

LAE 010 CVA





Table of Contents

TECHNICAL DATA, MEASUREMENTS AND DIMENSIONS	251
INSTALLATION MANUAL	253
ELECTRICAL CONNECTION	254
WIRING DIAGRAM	254
WATER SUPPLY CONNECTION	255
USER'S MANUAL	256
USE	257
CLEANING AND MAINTENANCE	265

Multicooker Module

«LAE 010 CVA»

TECHNICAL DATA MEASUREMENTS AND DIMENSIONS



EN 01-2025


TECHNICAL DATA, MEASUREMENTS AND DIMENSIONS

Description:


The Lacanche multi-cooker is a module offered as an option on the hobs and ranges above 1000 mm. This module is mounted on the right or left of the units.

Main characteristics:

- ▲ Pan 336 x 308 x 200 mm (GN 2/3) AISI316L (Z2 CND 17-12).
- ▲ Nominal capacity 12 litres.
- ▲ Heating element unit 3500 W.
- ▲ Control thermostat 30°C-110°C.
- ▲ Manual reset water-deficiency safety thermostat.
- ▲ Illuminated switch on front.
- ▲ Heating element of stainless steel swivel «special» multi-cooker steam.



TECHNICAL DATA, MEASUREMENTS AND DIMENSIONS



Ref	P	U	I
LAE 010 CVA	3,5 kW	230 V1N~ 50 Hz + T / E	15,20 A

Directives:

Electrical Directive (Low Voltage): 2014/35 / EU.

Electromagnetic Compatibility Directive: EMC: 2014/30 / EU.

Multicooker Module

«LAE 010 CVA»

INSTALLER’S MANUAL

The installation must be executed according to the instructions of this notice and the local regulations of the city/region/country where the unit is installed. The instructions contained in this manual are destined to professional installers with a good knowledge of equipment and installations gas, water and electrical.

This manual will be handed over to the user after installation of the unit.



ELECTRICAL CONNECTION

The cooker must be installed in a workmanlike manner in accordance with the instructions in this manual and locally applicable regulations.

BEFORE CONNECTION:

Verify:

- That the electrical supply of the system is compatible with the voltage and power of the range.
- The user's fixed installation must include an all-pole circuit-breaker of approved type.







CONNECTION:

- Cable insulation must be type 245 IEC 57 or 245 IEC 66
- The length of the conductors of the power cable between the strain relief device and the terminals must be such that the conductors become taut before the earth conductor in case of traction on the cable.
- If this unit is permanently connected to a fixed electrical cable, the cable should be equipped with a fault leak protector.
- If this unit is connected to a wall outlet, the outlet should be permanently accessible.

① Remove cover (or covers), to the back of the unit identified by .


② Use a standard flexible cable to connect to terminal block.

③ Secure the cable by means of cable clamp.



 It is hazardous to put the appliance into service without connecting it to suitable ground.

WIRING DIAGRAM




SCE4_016

EV1: 5,5/min

WATER SUPPLY CONNECTION

WATER SUPPLY HOOK-UP:


The multi-cooker must be connected to a potable water supply.
The minimal pressure of the water supply must of 1 hPa and the maximum must be 5 hPa.
-Before connecting the final connection, the pipes, hoses and connectors must be cleaned to remove any debris and impurities.



Water connection diameter : 20/27 mm.
Maximum flow : 5,5 l/mn.
Pressure : 1 à 5 hPa.

WATER SUPPLY CONNECTION



DRAINING OF USED WATER:



IMPORTANT:

The P trap must be made of metal.
An "Air Gap" disconnect is required between the flexible water drain and the P trap leading to the local waste water network.
The disconnect must feature either an "air-gap" disconnect or an "air-vent" disconnect. See drawings below:

- 1: Drain pipe
 - 2: Overflow level
 - E: Diameter
 - G: Diameter
 - S1, S2...: Air vents sections
 - Z: Smallest dimension for air vent
- Calculation:
- $b \geq G$
 - $b \geq 20 \text{ mm}$
 - $G > E$: G must be large enough to allow full drainage of E
 - $S_1 + S_2 + \dots \geq \frac{b \times 2G}{3}$
 - $Z \geq 4 \text{ mm}$





Multicooker Module

«LAE 010 CVA»

USER'S MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

This device is intended for use in domestic and similar applications such as:

- kitchen corners reserved for staff in shops, offices and other professional environments,
- in farms,
- the use by customers of hotels, motels and other residential environments,
- Bed and Breakfast type environments,

Any changeover to a gas other than that for which the cooker is set up must be carried out by a qualified installer.

Any change of voltage from that for which the appliance is set up must be carried out by a qualified installer.

WARRANTY:

The warranty is stated on the sales contract. Please contact your approved Dealer if any work has to be carried out under warranty. This warranty excludes damage resulting from incorrect installation, improper use or inadequate servicing.





USE

WARNINGS:

There is a risk of injury in the case of any use other than those described in this manual. When in use, the device and its accessible parts become hot. Care should be taken not to touch the heating elements, even after stopping operation, as they have residual heat. Wait for complete cooling before handling them.

In normal use, this appliance emits steam, precautions should be taken during use, especially when the lid is removed when the water boils.

The unit is not intended to operate using an external timer or a separate remote control system.

INTRODUCTION:


The Lacanche multi-cooker is a multi-use cooking tool that allows cooking of all kinds of food through three different cooking functions.

- The **“STEAMER”** cooking function allows cooking of vegetables, fish, meat, or any preparations needing soft, regular and homogenous cooking, with a high level of moisture.
- The **“DOUBLE-BATH”** function allows the maintaining in temperature of prepared food, the soft cooking at controlled temperature and the making of preserves.
- The **“BOILING”** function allows the cooking through immersion, the reheating of vacuum packed food, the reheating of pasta and rice, and convection cooking in temperature controlled water.


The thermostatically controlled temperature offers the user a complete array of possible use. Numerous recipes are available on our website: <http://www.lacanche.com>.

PRECAUTIONS:

- This appliance is not for use by children. If unfamiliar with this appliance, use should be overseen by a competent person who has read all the relevant information. Before use, it is mandatory to remove all the internal and external plastic packing, failure to do so will cause irreversible damage to the steel walls of the cooker.
- Wash the tank of the multi-cooker with non-aggressive soapy water.
- Make sure that the water-supply is opened.
- Shut the drain valve situated below the tank inside the cabinet.



Opened valve



Closed valve

IMPORTANT During any use, the unit must never be left unattended.

WARNING! NEVER USE ANY OTHER LIQUID THAN WATER IN THE MULTICOOKER


USER'S MANUAL



USE

USING THE MULTICOOKER:

The tank of the multi-cooker fills-up with water through the water-filling valve situated on the back wall of the tank.



Depending on the selected cooking function, the multi-cooker can be filled-up in two different ways:

- **Automatically** for the **“STEAMER”** function
- **Manually** for the **“DOUBLE BATH”** and **“BOILING”** functions

CALIBRATING THE WATER LEVEL PROBE ACCORDING TO THE LEVEL OF HARDNESS OF

THE WATER:

ATTENTION! THIS WATER PROBE CALIBRATION MUST BE DONE BEFORE THE FIRST USE OF THE MULTICOOKER

The multicooker is equipped with a adjustment dial allowing the adjusting of the water level of the automatic refill according to the level of hardness of the water supply.

As the level of hardness of the water varies greatly depending on the region and country, it is very important to calibrate the water level probe before using the multicooker.

The water probe detects the minimum water level necessary for the proper use of the multicooker.

The factory calibration is set to respond to an average water hardness.

The calibration procedure is explained in the next chapter.


USER'S MANUAL

EN 01-2025


USE

Calibrating of the probe:


To calibrate the probe, first verify that once the automatic refill stops, the minimum level reaches the first mark (STEAM level).



- If the water level is higher or lower than this mark, you need to proceed with an adjustment of the calibration module dial.
- The calibration adjustment dial is situated on the back wall of the lower cabinet, on the upper left corner (on the range model)




- The adjustment is made by turning the large dial on the lower part of the module.



USE


- **ATTENTION!** Never touch the voltage dial situated on the top end of the module.




Calibration procedure:

If the water level is higher or lower than the first mark, proceed with an adjustment of the calibration module dial.


1. Make sure the manual refill switch is off (low position)



2. Turn the temperature knob clockwise to desired temperature. The white LED turns-on.



- After a 15-second delay, the yellow LED turns-on. The multi-cooker fills-up to the first mark, through the water-filling valve situated on the back wall of the tank. Wait until the automatic refill stops.



- Verify the water level.

If the water level is lower than the first mark:



- Turn the dial to the left 1/8 turn.
- Empty the tank completely and proceed with a new automatic refill cycle to check if the water level is correct.
- Repeat the procedure until the proper level is reached.

If the water level is higher than the first mark:




- Turn the dial to the right 1/8 turn.
- Empty the tank completely and proceed with a new automatic refill cycle to check if the water level is correct.
- Repeat the procedure until the proper level is reached.

Once calibrated, the automatic refill probe is adjusted to level of hardness of the water supply.
The automatic water level should remain constant.
If a change in the hardness of water occurs, the water level may change (In the case of the addition of a water softener, for instance).
It is possible to adjust the water level again by following the procedure described above.

FUNCTIONS:


Make sure that the manual water supply switch is on the lower position.

Toggle the master switch to the 1 position.




1) "STEAMER" function: steam cooking

- Make sure that the manual water supply switch is on the lower position.




USE

- Turn the temperature knob clockwise to desired temperature. The white LED turns-on.




- After a 15-second delay, the yellow LED turns-on. The multi-cooker fills-up to the first mark, through the water-filling valve situated on the back wall of the tank. ("STEAMER" level.)

«STEAMER» level mark




- To compensate for any evaporation during the cooking process, the automatic refill system will re-adjust the water level automatically by refilling the tank to the first mark. The yellow LED will turn-on each time the water refill activates.



USE

- Place the perforated pan in the tank of the multi-cooker. Place the food to be cooked in the pan and cover it with the lid (supplied) if necessary. Cook accordingly to the recipe.




- To stop the function, place the thermostat on the 0 position.
- Drain the tank after usage

2) Mode « BAIN-MARIE » : cuisson et maintien en température



- Toggle the manual water supply switch upward. The yellow LED turns on. The multi-cooker fills-up through the water-filling valve situated on the back wall of the tank.
- Toggle the switch downward to stop the flow of water when the desired level is reached. The yellow LED turns off.

Manual refill switch




- Fill the tank to the middle mark on the right side of the tank ("DOUBLE BATH" water level).

«DOUBLE BATH» level mark





USE


- Turn the temperature knob clockwise to desired temperature. The white LED turns on.



- The White LED situated at the center of the control panel will turn-off once the desired temperature is reached. The multi-cooker is ready to use.
- To maintain food at temperature, place one or several Gastronorm pans (2/3, 1/3, etc.) containing food and preparation in the multi-cooker and cover it with the corresponding lid.



- It is also possible to place jars, terrines, dishes, pots and pans directly on the Heating element shield/rack, or in the perforated Gastronorm 2/3 pan supplied with the multi-cooker to maintain in temperature, and cook at low temperature (lower than 195°F). In this case, the containers will be partially immersed according to their size, to insure sufficient heat exchange. To obtain best result, it is usually recommended to cover the items with a tight fitting lid.




- To stop the “**DOUBLE BATH**” function, place the thermostat on the 0 position.
- Drain the tank after usage.

USE

3) “**BOILING**” function: *cooking, reheating, preserves*



- Toggle the manual water supply switch upward. The yellow LED turns on. The multi-cooker fills-up through the water-filling valve situated on the back wall of the tank.
- Toggle the switch downward to stop the flow of water when the desired level is reached. The yellow LED turns off.

Manual refill switch




- Fill the tank to the middle mark on the right side of the tank. “**BOILING**” water level
- Toggle the switch downward to stop the filling process, once the desired level is obtained. Be sure not to fill the tank above the maximum mark (12 liters).

«BOILING» level mark




USE

- Turn the temperature knob clockwise to desired temperature. The white LED turns on.



- The heating time depends on the water level and the final temperature desired.
- The White LED situated at the center of the control panel will turn-off once the desired temperature is reached. The multi-cooker is ready to use.
- Place food in sealed containers (preserves, cans, etc.) or food in sealed pouches (vacuum packed, frozen pack), or food in baskets (pasta, rice, vegetables, etc.), directly in the hot (slow cooking, maintaining temperature), simmering (preserving, canning) or boiling water (cooking and/or reheating) depending on the result you wish to attain.



- To stop the **"BOILING"** function, place the thermostat on the 0 position.
- Drain the tank after usage.

USE

SUMMARY OF ESSENTIAL POINTS RELATING TO AUTOMATIC REFILL:

- As soon as the temperature handle is turned to the left (clockwise) the tank of the multi-cooker will start filling-up automatically, up to the first mark ("**STEAMER**" level)
- As a safety, the automatic water refill is set at the factory to reach the first mark at the bottom of the tank, situated right above the heating element.
- The automatic refill system maintains the level of water at the first mark ("**STEAMER**" level) automatically and indefinitely, so the heating element remains submerged at all time.
- Since the automatic water refill system functions only to the first mark level ("**STEAMER**" level), any water level above this mark ("**DOUBLE BATH**" and "**BOILING**" level) must be reached using the manual refill switch.
- It is possible to use the manual refill switch at any point before or during any cooking function to adjust the water level to your specific needs. This adjustment doesn't affect the minimum water level ("**STEAMER**" level) which is managed by the automatic water refill system. If the water level reaches the minimum level, the automatic water refill will take over.


SAFETY SWITCH

SAFETY AND SECURITY SWITCH:

To prevent any overheating, a security/safety switch will shut off the unit if the automatic water refill fails or if the water supply is cut-off, or if the water level in the tank drops below the level of the heating element. This safety/security switch will cut-off all electrical supply to the unit and it needs to be reset by hand.

MANUAL RESET OF THE SAFETY/SECURITY SWITCH:

The manual reset is done by pushing the red button **A** situated below the tank in the cupboard.



UTILISATION DES FONCTIONS DU POLYCUISEUR

Below are a few examples of recipes made possible by the different functions along with the temperatures to use. A large number of recipes are available on our website: <http://www.lacanche.fr>.

1. STEAM FUNCTION	
TEMPERATURES	RECIPES
110°C	↓ - Sterilization (Baby bottles, jars, utensils)
105°C	↓ - Vegetable cooking
100°C	↓ - Poultry cooking (included pre-roasting)
95°C	↓ - Finishing and holding (rice, bulgur, couscous, quinoa, etc.)
90°C	↓ - Finition (riz, bulgur, couscous, quinoa, etc.)
85°C	↓ - Whole fish
	↓ - Fish filets
80°C	↓ - Flans, custards
	↓ - Dim Sum
	↓ - Risen doughs (cooking)
75°C	↓ - Cakes, sponge cakes, angel-food cakes (cooking)
	↓ - Dumplings (heating, cooking)
70°C	↓ - Poached eggs
	↓ - Snow eggs, floating island
65°C	↓ - Custards, pudding
60°C	
55°C	↓ - Foie gras (whole)
50°C	
45°C	
40°C	↓ - Yogurt, farmer cheese
35°C	↓ - Yeast dough (proofing)
30°C	



USE



USE

2. DOUBLE BATH

RECIPES

110°C	→ - Jarring, preserves
105°C	
100°C	→ - Température holding (soups, sauces, garnishes etc.)
95°C	→ - Infusing (flavored huiles, teas, butters, sauces, etc.)
90°C	→ - Molded and dished cooking (meat based terrine, etc.)
85°C	
80°C	→ - Egg based molded and dished cooking (Fish and vegetable terrines & mousses)
75°C	→ - Whole egg based dessert molded (Flans, crèmes caramel, custards, etc.)
70°C	→ - Egg yolk based desserts
65°C	
60°C	→ - Defrosting before cooking
55°C	
50°C	→ - Foie gras terrines
45°C	
40°C	→ - Chocolate melting and tempering
35°C	
30°C	

TEMPERATURES

3. BOILING

RECIPES

110°C	→ - Stérilization, preserves
105°C	→ - Pasta and rice cooking
100°C	→ - Pasta and rice re-heating
95°C	→ - Eggs in shells
90°C	→ - Sausage and ham cooking
90°C	→ - Risen doughs before oven cooking (Bagels, Pretzels)
85°C	→ - Ballotines (meat, poultry, fish)
80°C	→ - Galantine before roasting (meat, poultry, fish)
75°C	→ - Towel wrapped cooking (whole ham)
70°C	→ - Vacuum packed cooking (prepared dishes)
65°C	
60°C	→ - De-frosting of sealed food before re-heating
55°C	→ - Vacuum packed foie gras
50°C	
45°C	
40°C	
35°C	
30°C	

TEMPERATURES

CLEANING AND MAINTENANCE

- **Before any maintenance and: or cleaning, make sure the electric supply is turned off**
- **Wait until complete cooling of the tank before any intervention**
- **The surface of the heating element may have residual heat after use. It is necessary to ensure the cooling of the resistance before any manipulation.**

CLEANING:


- The low operating temperature of the multi-cooker makes it prone to bacteria development. It is only through a very tight hygiene and systematic cleaning that complete food and sanitary safety can be ensured.
- After each and every use, clean the tank thoroughly with soapy water followed by a triple rinse with clear water.

CAUTION: Draining of the tank:


- Wait until partial cooling of the tank. Open the drain valve.

Cleaning the tank:

- Remove the heating element protection. It can be washed in the dishwasher.
- To facilitate the washing of the tank, the heating element pivots.



- Wipe the tank dry after rinsing
- Leave the drain valve open between use




CLEANING AND MAINTENANCE

IMPORTANT:

- Make sure that the water level probe located on the lower part of the inner facing of the tank is cleaned after each use.
- DO NOT use any abrasive and/or acid cleaning products or pads to clean the water level probe.

Water level probe



Cabinet:

Clean the inside with a non-abrasive cleaning product.

The use of aggressive cleaning solution is not recommended, but if needed, unclip the gaskets and remove them while cleaning.

Rinse and dry thoroughly.





Enamel parts:

Use soapy water, never use abrasive powders.

Body panels:

You can use special-purpose products for stainless steel (e.g. SUMAINOX®, JOHNSON STAINLESS STEEL®, PPZ STAINLESS STEEL®). Never use abrasive products.

CAUTION : Use NO chlorinated cleansers to clean this unit.



Hob top option

ELECTRIC FRYER

LAE 413 FR





Contents


TECHNICAL DATA	268
INSTALLER'S MANUAL	269
INSTALLING / POSITIONING	270
ELECTRICAL CIRCUIT DIAGRAM	270
USER'S MANUAL	271
USE	272
CLEANING AND MAINTENANCE	273



TECHNICAL DATA

Fryer: 6-litre deep-fat fryer option located on left or right of central hob (depending on model).

- ▶ Stainless steel Z7CN18.09 vessel with a nominal capacity 6 litres.
- ▶ Unpluggable 3300 kW heating element unit.
- ▶ Control thermostat (0 °C-200 °C), safety thermostat, illuminated switch on front, manual timer (0-15 mn).



Part number	P	U	I
LAE 413 FR	3.3 kW	230 V1N~ 50 Hz + T / E	14.3 A

Overeenstemming met de Europese reglementering (EG):

Richtlijn voor elektrische apparaten (Laagspanning): 2014/35/UE.

Richtlijn Elektromagnetische Compatibiliteit: EMC: 2014/30/UE.

Hob top option

«LAE 413 FR»

INSTALLER’S MANUAL

The installation must be executed according to the instructions of this notice and the local regulations of the city/region/country where the unit is installed. The instructions contained in this manual are destined to professional installers with a good knowledge of equipment and installations gas, water and electrical.

This manual will be handed over to the user after installation of the unit.



See «Installing/ Positioning» in Cooker Installer's manual.

All work on or repair of an appliance must be carried out by a qualified engineer.

Limiting thermostat:

In accordance with the construction regulations, the limiting thermostat is intended to protect the range from overheating.

In the event of overheating the limiting thermostat is triggered and cuts out the range's electric functions.

The advanced technology used in the limiter means that it is very sensitive to impacts and vibration that may occur during transport and handling.

The limiter may therefore be unexpectedly triggered when the oven is first heated and stop the oven from working.


To reset limiting thermostat:

- 1- Lift cover.
- 2- Push button.

ALWAYS IDENTIFY THE REASON why the thermostat tripped.

ELECTRICAL CIRCUIT DIAGRAM

For references and descriptions of the various components refer to table 11 in appendix.



Hob top option

«LAE 413 FR»

USER'S MANUAL

IMPORTANT

This appliance must be installed in accordance with all relevant standards and regulations in force in a room with adequate ventilation.

This device is intended for use in domestic and similar applications such as:

- kitchen corners reserved for staff in shops, offices and other professional environments,
- in farms,
- the use by customers of hotels, motels and other residential environments,
- Bed and Breakfast type environments,

Any changeover to a gas other than that for which the cooker is set up must be carried out by a qualified installer.

Any change of voltage from that for which the appliance is set up must be carried out by a qualified installer.

WARRANTY:

The warranty is stated on the sales contract. Please contact your approved Dealer if any work has to be carried out under warranty. This warranty excludes damage resulting from incorrect installation, improper use or inadequate servicing.



WARNINGS :

There is a risk of injury in the case of any use other than those described in this manual. When in use, the device and its accessible parts become hot. Care should be taken not to touch the heating elements, even after stopping operation, as they have residual heat. Wait for complete cooling before handling them.


In normal use, this appliance emits steam, precautions should be taken during use, especially when the lid is removed when the water boils.

Before using for the first time, remove the plastic protection, carefully clean the vessel with water plus a non-aggressive washing agent.

CAUTION: Because the lid of the fryer is a safety component, it must be raised but not removed when the fryer is in use. The cover can be lowered in the event of fire.

Use:

- Fill the vessel :
- Remove the basket.
- Fill with good-quality frying oil up to a level between the two marks.





The oil level must be between the 2 marks.


When using solid vegetable oil (blocks), melt the blocks in a utensil over low heat and not on the heating elements and then pour the liquefied fat into the vessel.

→ Use:

- Switches on Indicator lamp **T** is lit.
- Turn the control knob to the desired position.



- Indicator lamp **B** is lit and goes out when the set temperature is reached.
- Put in the food to be fried.
- Remove the basket at the end of cooking.



CAUTION

Keep an eye on the deep fat fryer when it is in use. Keep children away from the fryer when it is operating. No hob in operation should be near the fryer when the oil is hot.

→ Recommendations:

- Change the oil regularly, the flashpoint of used oil is lower.
- There is also a risk of spitting and overflowing if the baskets are overloaded or the food to be fried has not been allowed to drain.
- In order to preserve the full flavour of your oil, AVOID heating your oil for prolonged periods with nothing in it and NEVER salt fried food when it is above the oil.

Production capacity:

LAE 413 FR					
FROZEN FRENCH FRIES*			FRESH FRENCH FRIES*		
Cooking time in minutes	Hourly production in kg	Number of portions	Cooking time in minutes	Hourly production in kg	Number of portions
5	5.0	30	4.5	5.9	36
Basket load : 600 gr					

* Partially fried then continuously browned, values stated for information only.



CLEANING AND MAINTENANCE

Before any cleaning work, isolate from the mains supply.

The surface of the heating element may have residual heat after use.
It is necessary to ensure the cooling of the electric fryer (resistance +oil) before any manipulation.

Do not use a steam cleaner to clean the appliance.

Wait until the fire tray has at least partially cooled.

Draining:

After any servicing it is advisable to drain only when it's cold by slightly opening valve until oil starts to flow having previously carefully positioned a container underneath the valve.

Daily cleaning:

Use a cloth to immediately remove any spills.

Clean the steel body with soapy water before rinsing and wiping it. Do not use abrasive products.

Regular cleaning:

- ▶ Drain the oil into container.
- ▶ Take out the basket and the heating element unit.
- ▶ Remove the filter, remove any food debris.
- ▶ Close valve, fill the vessel with a special detergent or washing agent for deep fat fryers (2 cm above the MAX. mark).
- ▶ Boil for approx. 15 minutes with thermostat at 100-110°C.
- ▶ Drain, rinse and dry thoroughly.

Baskets and filter may be cleaned in the dishwasher.

CAUTION: Use NO chlorinated cleansers to clean this unit.

Body panels:

You can use special-purpose products for stainless steel (e.g. SUMAINOX ®, JOHNSON STAINLESS STEEL ®, PPZ STAINLESS STEEL ®). Never use abrasive products.

**ANNEXE TECHNIQUE
APPENDIX
TECHNISCHER ANHANG
ANEXO TÉCNICO
ALLEGATO TECNICO
TECHNISCHE BIJLAGE
VEDLEGG
ZAŁĄCZNIK
ANEXO TÉCNICO
ПРИЛОЖЕНИЕ**





ANNEXE TECHNIQUE

- (FR) L'INSTALLATION DOIT ETRE REALISEE CONFORMEMENT AUX REGLEMENTATIONS ET NORMES EN VIGUEUR .
(GB) THE APPLIANCE MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE REGULATIONS AND STANDARDS.
(NL) DE APPARATEN MOETEN VOLGENS DE GELDENDE DE WEITEN EN VOORSCHRIFTEN WORDEN GEINSTALLEERD.
(DE) DIE INSTALLATION MUSS NACH DEN GELTEN DEN VORSCHRIFTEN UND NORMEN VORGENOMMEN WERDEN.
(IT) L'INSTALLAZIONE DEVE ESSERE REALIZZATA CONFORMEMENTE AI RE GOLAMENTI ED ALLE NORME INVIGORE.
(ES) LA INSTALACIÓN DEBE REALIZARSE DE CONFORMIDAD CON LAS NORMATIVAS Y REGLAS EN VIGOR.
(PT) A INSTALAÇÃO DEVE SER REALIZADA CONFORME OS REGULAMENTOS E AS NORMAS EM VIGOR.

Conformité du débit d'air neuf / Correct fresh air flowrate / Juiste doorvoerhoeveelheid verse lucht / Die Übereinstimmung des Frischluftdurchsatzes / La conformità del flusso di aria nuova / La conformidad del caudal de aire nuevo / A conformidade do débito de ar novo

10 m³/h / kW

Table et carrosserie / Cooking surface and body panels / Kochfeld und Gehäuse / Piano e rivestimento esterno / Spisýta och chassi / Encimera y carrocería / Placa e estrutura:

Tableau / Table / Tabella / Tabella / Tabla / Cuadro / Quadro 1			
Repère / Item	Désignation / Designation / Omschrijving /	Beskrivning/ Designación/ Designação / Designazione	Puissance
T	Tradition	Tradition	5 kW
A	Ultra-rapide / Ultra fast/ Ultra snel/ Ultra-rapido	Extrasnabb/ Ultrarápido/ Ultra-rápido	5 kW
B	Intensif / Intensive / Intensiv/ Intensivo	Intensiv/ Intensivo/ Intensivo	4 kW
C	Rapide / Fast / Schnell / Rápido	Snabb/ Rápido/ Rápido	3 kW
D	Semi-rapide / Semi fast / Semi snel/ Semi rapido	Halvsnabb/ Semirápido/ Semi-rápido	1,5 kW



ANNEXE TECHNIQUE

Foyers radiants (option) / Ceramic hobs (option) / Glaskeramik-Kochfeld (option) / Fornelli radianti (opzione) / Glaskeramikhäll (tillval) / Zonas de cocció radiantes (opción) / Placas irradiantes (opção)

Repère / Item	Tableau / Table / Tabelle / Tabella / Tablă / Cuadro 2	Ø	P
A	Foyer simple circuit / Single hotplate / Einkreis-Kochzone/ Fornello circuito semplice / Platta med enkel strömkrets / Zona de cocció simple circuito / Placas circuito simples	210 mm	2100 W
B	Foyer double circuit, / Dual hotplate / Dubblecircuitovens/ Zweikreis-Kochzone/ Fornello circuito doppio / Platta med dubbel strömkrets i / Zona de cocció doble circuito / Placas duplo circuito	140/210 mm	1000/2100 W
C	Foyer ovale / oval hob / Ovale kookzone/ Fornello ovale/ Oval zon / Zona de cocció ovalada / Zona de cocció ovalada	170 x 265 mm	800/1400/2200 W

Foyers induction (option)

Repère / Item	Tableau / Table / Tabelle / Tabella / Tablă / Cuadro 3		
	Ø	P	Booster
A	270 mm	2600 W	3700 W
B	200 mm	1850 W	3000 W
C	180 mm	1850 W	3000 W
D	145 mm	1850 W	3000 W
E	215 mm	2300 W	3000 W
F	175 mm	1100 W	1400 W
G	200 mm	1400 W	2000 W

Table électrique (option) / Electric hotplates (option)

Tableau / Table / Tabelle / Tabella / Tablă / Cuadro 4				
Repère / Item	A	B	C	E
Ø	220 mm	220 mm	180 mm	145 mm
P	2600 W	2000 W	2000 W	1500 W



ANNEXE TECHNIQUE

Débit calorifique nominal et consommations horaire / Pressures and hourly consumption/ Drukwaarden en energieverbruik per uur / Druck und Stundenverbrauch / Pressioni e consumo orario/ Tryck och timkonsumtion/ Pressões e consumos horários/ Pressões e consumos horários:

Tableau / Table /Tabelle /Tabella / Tablá / Cuadro / Quadro 5																					
	G20		G 20		G 25		G 25		G 30		G 31		G 30		G 31		G 110		G 120		
	15 mbar		20 mbar		20 mbar		25 mbar		28-30 mbar		37 mbar		50 mbar		50 mbar		8 mbar		8 mbar		
	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	kg/h	kW	kg/h	kW	kg/h	kW	kg/h	kW	m³/h	kW	m³/h	kW	
F / O	55 litres	0,34	3,2	0,34	3,2	0,39	3,2	0,39	3,7	0,29	3,7	0,29	3,7	0,29	3,7	0,29	3,7	0,90	3,5	0,80	3,5
	60 litres	0,39	3,7	0,42	4	0,49	4	0,49	4	0,31	4	0,31	4	0,31	4	0,31	4	1,03	4	0,92	4
Charcoal	4 kW	0,42	4	0,42	4	0,49	4	0,49	4	0,31	4	0,31	4	0,31	4	0,31	4	1,03	4	0,92	4
Charcoal	6 kW	0,63	6	0,63	6	0,74	6	0,68	5,5	0,43	5,5	0,43	5,5	0,43	5,5	0,43	5,5	1,55	6	1,4	6
SK/SR	4.8 kW		0,4	4	4	0,4	4	0,49	3,5	0,23	3,2	0,25	3,2	0,31	4,0	0,31	4,0				
T	5 kW	0,44	4,2	0,53	5	0,61	5	0,61	5	0,39	5	0,39	5	0,39	5	0,39	5	1,29	5	1,15	5
A	5 kW	0,44	4,2	0,5	3,5	0,61	5	0,61	5	0,33	4,2	0,32	4,2	0,33	4,2	0,32	4,2	1,29	5	1,15	5
B	4 kW	0,38	3,6	0,42	4	0,49	4	0,49	4	0,26	3,3	0,25	3,3	0,26	3,3	0,25	3,3	1,03	4	0,91	4
C	3 kW	0,32	3	0,32	3	0,36	3	0,36	3	0,20	2,6	0,20	2,6	0,20	2,6	0,20	2,6	0,77	3	0,69	3
D	1,5 kW	0,18	1,7	0,18	1,7	0,21	1,7	0,21	1,7	0,13	1,75	0,13	1,75	0,13	1,75	0,11	1,5	0,44	1,7	0,39	1,7

Puissances calculées sur pouvoir calorifique inférieur / Power calculated on lower calorific value / Leistung berechnet nach dem unteren Heizwert / Potenza calcolata su potere calorifico inferiore / Effekt beräknad på det undre värmevärdet./ Potencia calculada respecto al poder calorifico inferior./ Potência calculada no poder calorifico inferior.

Débit calorifique nominal et débit réduit

Tableau / Table /Tabelle /Tabella / Tablá / Cuadro / Quadro 6																					
	G20		G 20		G 25		G 25		G 30		G 31		G 30		G 31		G 110		G 120		
	15 mbar		20 mbar		20 mbar		25 mbar		28-30 mbar		37 mbar		50 mbar		50 mbar		8 mbar		8 mbar		
	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	
F / O	55 litres	3,2	0,96	3,2	0,96	3,2	0,96	3,2	0,96	3,7	1,11	3,7	1,11	3,7	1,11	3,7	1,11	3,5	1,05	3,5	1,05
	60 litres	3,7	1,11	4,0	1,2	4,0	1,2	4,0	1,2	4,0	1,2	4,0	1,2	4,0	1,2	4,0	1,2	4,0	1,2	4,0	1,2
Charcoal	4 kW	4	1,2	4	1,2	4	1,2	4	1,2	4	1,2	4	1,2	4	1,2	4	1,2	4	1,2	4	1,2
Charcoal	6 kW	6	2,7	6	2,7	6	2,7	5,5	2,7	5,5	2,7	5,5	2,7	5,5	2,7	5,5	2,7	6	2,7	6	2,7
SK/SR	4.8 kW		4	1,48	4,0	1,48	3,5	1,29	3,2	1,18	3,2	1,18	4,0	1,48	4,0	1,48					



ANNEXE TECHNIQUE

		G20 15 mbar		G 20 20 mbar		G 25 20 mbar		G 25 25 mbar		G 30 28-30 mbar		G 31 37 mbar		G 30 50 mbar		G 31 50 mbar		G 110 8 mbar		G 120 8 mbar	
		m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW	m³/h	kW
A	5 kW	4,2	1,26	5	1,5	5	1,5	5	1,5	4,2	1,26	4,2	1,26	4,2	1,26	4,2	1,26	5	1,5	5	1,5
T	5 kW	4,2	1,26	5	1,5	5	1,5	5	1,5	5	1,5	5	1,5	5	1,5	5	1,5	5	1,5	5	1,5
B	4 kW	3,6	1,08	4,0	1,2	4,0	1,2	4,0	1,2	3,3	0,99	3,3	0,99	3,3	0,99	3,3	0,99	4,0	1,2	4,0	1,2
C	3 kW	3	0,9	3	0,9	3	0,9	3	0,9	2,6	0,78	2,6	0,78	2,6	0,78	2,6	0,78	3	0,9	3	0,9
D	1,5 kW	1,7	0,51	1,7	0,51	1,7	0,51	1,7	0,51	1,75	0,52	1,75	0,52	1,75	0,52	1,5	0,45	1,7	0,45	1,7	0,45



ANNEXE TECHNIQUE

Changement de gaz / Change of gas / Gaswechsel / Cambiamento di gas / Byte av gas / Cambio de gas / Mudança de gás :

Tableau / Table / Tabelle / Tabella / Tablá / Cuadro / Quadro 7		
PAYS / COUNTRY / LAND / PAESE / PAÍS / PAÍSES	PRESSION (Pn) / PRESSURE (Pn) / DRUK (Pn) PRESSIONE(Pn) / TRYCK (Pn) / PRESIÓN (Pn) PRESSÃO (Pn)	CATEGORIE / CATEGORY / CATEGORIE / KATEGORIE / CATEGORIA / KATEGORI / CATEGORÍA / CATEGORIA
AT	20 ; 50	I12H3B/P
BE-FR	20/25 ; 28-30/37	I12E+3+
FR	20 ; 50	I12E+3B/P
DE	8 ; 20 ; 50	III1ab2ELL3B/P
DK	8 ; 20 ; 30	III1a2H3B/P
ES-IE-PT-GB-CH-GR	20 ; 28-30/37	I12H3+
FI	20 ; 30	I12H3B/P
LU	20 ; 28-30/37	I12E+3+
LU	20 ; 50	I12E3B/P
IT	8 ; 20 ; 28-30/37	III1a2H3+
NL	20-25 ; 30	I2EK I3B/P
NO	30	I3B/P
ES-CH	20 ; 50	I12H3P
IS	20	I2H
SE	8 ; 20 ; 30	III1ab2H3B/P



ANNEXE TECHNIQUE

Injecteurs / Orifice / Injector / Inietttore / Injektor / Inyector / Injector:

Tableau / Table / Tabelle / Tabella / Tablá / Cuadro / Quadro 8						
Brûleurs / Burners / Brenners / Bruciatori / Brännare / Quemadores / Queimadores	Pression / Pressure / Druk / Pressione / Tryck / Presión / Pressão	1,5 kW D	3 kW C	4 kW B	5 kW A	5 kW PCF T
GAZ / GAS / GÁS						
G 20	15 mbar	105	140	160	170	170
G 20	20 mbar	100	130	150	170	170
G 25	20 mbar	110	140	160	180	180
G 25	25 mbar	100	130	150	170	170
G 30	28-30 mbar	65	80	90	100	110
G 30	50 mbar	50	70	80	90	100
G 31	37 mbar	65	80	90	100	110
G 31	50 mbar	50	70	80	90	100
G 110	8 mbar	170	250	320	370	370
G 120	8 mbar	170	230	300	320	320
G 20	10 mbar	105	140	165	175	175
G 31	27,5 mbar	65	90	105	110	110



ANNEXE TECHNIQUE

R glage de l'air primaire / Adjustment of primary air / Einstellung der Prim rluft / Regolazione dell'aria primaria / Reglage av lufintag / Regulaci n del aire primario / Ajuste do ar prim rio:

Tableau / Table / Tabelle / Tabella / Tabl� / Cuadro 9							
Br�teurs / Burners / Brenners / Bruciatori / Br�nnare / Quemadores / Queimadores		1,5 kW D	3 kW C	4 kW B	5 kW A	5 kW PCF T	4 kW LAG 010 CKG
GAZ / GAS / G�S	Pression / Pressure / Druk / Pressione / Tryck / Presi�n / Press�o						
G 20	15 mbar	1,2	2	2	3	3	1
G 20	20 mbar	1,2	2	2	3	3	1
G 25	20 mbar	1,2	2	2	3	3	1
G 25	25 mbar	1,2	2	2	3	3	1
G 30	28-30 mbar	1,2	2	2	3	3	4
G 30	50 mbar	1,2	2	2	3	3	4
G 31	37 mbar	1,2	2	2	3	3	4
G 31	50 mbar	1,2	2	2	3	3	4
G 110	8 mbar	1	2	2	3	3	1
G 120	8 mbar	1	2	2	3	3	1
G 20	10 mbar	1,2	2	2	3	3	1
G 31	27,5 mbar	1,2	2	2	3	3	4



Réduction de puissance Allemagne/ Leistungsreduzierung Deutschland

		Injecteurs / Injector				Réglage de l'air primaire / Einstellung der Primärluft			
		Brûleurs /Brenners							
GAZ / GAS	Pression /Druk	0.9 kW D	1.9 kW C	2.6 kW B	3.5 kW A	0.9 kW D	1.9 kW C	2.6 kW B	3.5 kW A
G20	20	1.35	1.15	1.00	0.70	3	2	1.2	1.2
G30	50	0.80	0.70	0.55	0.50	2	2	1.2	1.2
G31	50	0.80	0.70	0.55	0.50	2	2	1.2	1.2



Règlage de l'air primaire / Adjustment of primary air / Einstellung der Primärluft / Regolazione dell'aria primaria / Reglage av luftintag / Regulación del aire primario / Ajuste do ar primário:

Tableau / Table / Tabella / Tablă / Cuadro / Quadro 10					
		Four /Oven / Ofen / Forno / Horno / Ugn 52 litres	Injecteurs / Orifice / Injector / Inietttore / Injektor / Injector / Injector	Four /Oven / Ofen / Forno / Horno / Ugn 70 litres	Injecteurs / Orifice / Injector / Inietttore / Injektor / Injector / Injector
GAS / GÁS	Pression / Pressure / Druk / Pressione / Tryck / Presión / Pressão	Ouverture en mm./ Opening in mm./ Öffnungsweite in mm Apertura in mm./ Öppning i mm./ Abertura em mm			
G 20	15 mbar	1	145	1	155
G 20	20 mbar	1	135	1	150
G 25	20 mbar	1	155	1	160
G 25	25 mbar	1	135	1	150
G30	28-30 mbar	4	95	4	100
G30	50 mbar	4	80	4	90
G31	37 mbar	4	95	4	100
G31	50 mbar	4	80	4	90
G110	8 mbar	1	260	1	280
G120	8 mbar	1	240	1	260



Référence éléments électriques

Tableau / Table / Tabelle / Tabella / Tablà / Cuadro / Quadro 11			
Rep / Item n°	Désignation / Designation / Omschrijving / Designazione / Beskrivning / Designação		Référence / Part number
TL	Thermostat de sécurité / Safety thermostat / Thermostaat met beveiliging / Thermostat mit Sicherheit / Termostato di sicurezza / Termostato de seguridad / Termostad med säkerhet / Termostato de segurança	Thermostato di sicurezza / Termostato de seguridad	38562
TL1	Thermostat de sécurité / Safety thermostat / Thermostaat met beveiliging / Thermostat mit Sicherheit / Termostato di sicurezza / Termostato de seguridad / Termostad med säkerhet / Termostato de segurança	Thermostato di sicurezza / Termostato de seguridad	37879
TL2	Thermostat de sécurité / Safety thermostat / Thermostaat met beveiliging / Thermostat mit Sicherheit / Termostato di sicurezza / Termostato de seguridad / Termostad med säkerhet / Termostato de segurança	Thermostato di sicurezza / Termostato de seguridad	39942
TL3	Thermostat de sécurité / Safety thermostat / Thermostaat met beveiliging / Thermostat mit Sicherheit / Termostato di sicurezza / Termostato de seguridad / Termostad med säkerhet / Termostato de segurança	Thermostato di sicurezza / Termostato de seguridad	224003
TL4	Thermostat de sécurité / Safety thermostat / Thermostaat met beveiliging / Thermostat mit Sicherheit / Termostato di sicurezza / Termostato de seguridad / Termostad med säkerhet / Termostato de segurança	Thermostato di sicurezza / Termostato de seguridad	224015
TH	Thermostat régulation / Control thermostat / Regelthermostaat / Regelthermostat / Termostato di regolazione / Termostato de regulación / Termostato de regulacão	Thermostato de regulación / Termostato de regulacão	224010
TH1	Thermostat régulation / Control thermostat / Regelthermostaat / Regelthermostat / Termostato di regolazione / Termostato de regulación / Termostato de regulacão	Thermostato de regulación / Termostato de regulacão	224007
TH2	Thermostat régulation / Control thermostat / Regelthermostaat / Regelthermostat / Termostato di regolazione / Termostato de regulación / Termostato de regulacão	Thermostato de regulación / Termostato de regulacão	28195
TD	Thermostat à disque		224009
S	Commutateur / Switch / Omschakelaar / Schlater / Commutatore / Conmutador / Strömbrytare / Comutador	Commutador / Strömbrytare / Comutador	52194
SA	Commutateur / Switch / Omschakelaar / Schlater / Commutatore / Conmutador / Strömbrytare / Comutador	Commutador / Strömbrytare / Comutador	40129
SB	Commutateur / Switch / Omschakelaar / Schlater / Commutatore / Conmutador / Strömbrytare / Comutador	Commutador / Strömbrytare / Comutador	53435
S1	Bouton d'allumage / Ignition button / Druknop / Zündtaster / Pulsante / Botón pulsador / Tryckknapp / Botão de pressão	Botão de pressão	222004
S2	Doseur / Variable power control switch / Energieregelaar / Energiedosierier / Regolare d'energia / Dosificador de energia / Variabel strömbrytare / Dosador de energia	Dosificador de energia / Variabel strömbrytare / Dosador de energia	35287
S3	Commutateur / Switch / Omschakelaar / Schlater / Commutatore / Conmutador / Strömbrytare / Comutador	Commutador / Strömbrytare / Comutador	28979
S4	Electrovanne / Solenoid valve / Magneetventiel / Elektroventil / Electrovalvola / Magnetventiel / Electroválvula	Electroválvula / Magnetventiel / Electroválvula	109014
S5	Commutateur / Switch / Omschakelaar / Schlater / Commutatore / Conmutador / Strömbrytare / Comutador	Commutador / Strömbrytare / Comutador	222005
S6	Commutateur / Switch / Omschakelaar / Schlater / Commutatore / Conmutador / Strömbrytare / Comutador	Commutador / Strömbrytare / Comutador	221005
S7	Commutateur / Switch / Omschakelaar / Schlater / Commutatore / Conmutador / Strömbrytare / Comutador	Commutador / Strömbrytare / Comutador	222013
D	Doseur d'énergie / Variable power control switch / Energieregelaar / Energiedosierier / Dosatore d'energia / Energidoserare / Dosificator	Dosatore d'energia / Energidoserare / Dosificator	225001
D1	Doseur d'énergie / Variable power control switch / Energieregelaar / Energiedosierier / Dosatore d'energia / Energidoserare / Dosificator	Dosatore d'energia / Energidoserare / Dosificator	35760
D2	Doseur d'énergie / Variable power control switch / Energieregelaar / Energiedosierier / Dosatore d'energia / Energidoserare / Dosificator	Dosatore d'energia / Energidoserare / Dosificator	225003
A	Allumeur / Module spark / Ontsteking / Anzünder / Accenditore / Encendedor / Tändare / Acendedor	Encendedor / Tändare / Acendedor	226007
B	Bougie de table / Top burner electrode / Kooktafel-ontstekingsplug / Zündkerze am Kochfeld / Candela del piano cottura / Bujía de encendido de encimera / Spishällens tändstift / Vela de mesa	Bujía de encendido de	226006
B1	Bougie de four / Oven electrode / Oven-ontstekingsplug / Zündkerze im Ofen / Candela del forno / Bujía de encendido de horno / Ugnens tändstift / Vela de forno	Bujía de encendido de horno / Ugnens tändstift / Vela de forno	53063
C	Connecteur / Connector / Koppeling / Kontakt / Connetttore / Kontakt / Conector	Kontakt / Connetttore / Kontakt / Conector	251002



ANNEXE TECHNIQUE

Référence éléments électriques (suite)		
Rep / Item n°	Désignation / Designation / Omschrijving / Designazione / Beskrivning / Designação	Référence / Part number
X1	Bornier de raccordement / Terminal block / Aansluitklemblok / Anschlusssklemmblock / Morsettiera / Placa de bornes de conexión / Kopplingsklämman / Caixa de terminais	51785
X	Bornier de raccordement / Terminal block / Aansluitklemblok / Anschlusssklemmblock / Morsettiera / Placa de bornes de conexión / Kopplingsklämman / Caixa de terminais	51922
R	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	36147
RA	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211018
RB	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	32362
RC	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	32917
R1	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	30051
R1A	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	35970
R2	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	27752
R3	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	30624
R4	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	39168
R5	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211006
R6	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	652208
R7	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	32415
R8	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211007
R9	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211014
R10	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211024
R11	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211030
R12	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211026
R13	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211032
R14	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211029
R15	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211028
R16	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211027
R17	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211042
R18	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211046
R19	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211045
R20	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211043
RV1	Foyer / Hotplate / Stralingselement / Kochzone / Fornello / Zona de cocción / Platta / Placa	32987
RV2	Foyer / Hotplate / Stralingselement / Kochzone / Fornello / Zona de cocción / Platta / Placa	35285
RV3	Foyer / Hotplate / Stralingselement / Kochzone / Fornello / Zona de cocción / Platta / Placa	212004
RV4	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	36157
RV5	Résistance / Heating element / Weerstand / Wiederstand / Resistenza / Resistencia / Motstånd / Resistência	211013



ANNEXE TECHNIQUE

Référence éléments électriques (suite)		
Rep / Item n°	Désignation / Designation / Omschrijving / Designazione / Beskrivning / Designación / Designação	Référence / Part number
A1	Allumeur 3 points / Module spark / Anzünder / Accenditore / Ontstekng / Encendedor / Acendedor	226011
A2	Allumeur 2 points / Module spark / Anzünder / Accenditore / Ontstekng / Encendedor / Acendedor	226002
P1	Plaque / Electric plate / Kook plate Ø 145 - 1500 W	17745
P2	Plaque / Electric plate / Kook plate Ø 180 - 2000 W	50952
P3	Plaque / Electric plate Ø 220 - 2600 W	27688
P4	Plaque / Electric plate Ø 180 - 1500 W	50951
H1	Voyant Orange / Orange indicator / Oranje controlelampje / Orangene Kontrollampe / Spia arancione / Piloto naranja / Orange kontrollampan / Indicador laranja	231007
P5	Plaque / Electric plate Ø 220 - 2000 W	50953
F	Fusible / Fuse / Zekering / Sicherung / Fusibile / Säkring / Fusible / Fusível	390001
M	Ventilateur ref r2k 150 ac01-15 + ecrou borgne	39815
M1	Moteur / Motor / Motore	260007
M2	Moteur / Motor	260005
M3	Moteur / Motor / Motore	260012
M1	Minuterie / Timer / Timer 0-120 mn / Programmuhr 0-120 mn / Minuteria 0-120 mn / Timer 0-120 mn / Minutería 0-120 mn / Temporizador 0-120 mn	28965
H2	Voyant Orange / Orange indicator / Oranje controlelampje / Orangene Kontrollampe / Spia arancione / Piloto naranja / Orange kontrollampan / Indicador laranja 220-240 V	40106
H3	Voyant Orange / Orange indicator / Oranje controlelampje / Orangene Kontrollampe / Spia arancione / Piloto naranja / Orange kontrollampan / Indicador laranja 400 V	40107
H4	Voyant cristal/Cristal indicator/ Kristal Kontrollampe	231017
KM1	Contacteur / Contactor / Contactsluit / Schaltschütz / Contattore / Contactor de potencia / Contactor	223002
KM2	Contacteur / Contactor / Contactsluit / Schaltschütz / Contattore / Contactor de potencia / Contactor	223001*
Q1	Connecteur mâle / Male connector / Mnl. Koppeling / Kontakstift / Connettoe maschio / Conector macho / Hankontakt / Conector macho	31654
Q2	Connecteur femelle / Female connector / Vrl. Koppeling / Kontakthülse / Connettoe femmina / Conector hembra / Honkontakt / Conector fêmea	31655
CRD	Témoin de chaleur résiduelle / Residual heat LEDs / Restwarmte-LEDs / Leuchtanzeige für Restwärme / Spia di calore residuo / Testigo de calor residual / Kontrollampa för restvärme /	231003
TT	Turbine tangentielle	26009
L	Lampe	232003
L1	Lampe	232006
Mr	Mini rupteur	222001



Tableau / Table / Tabelle / Tabella / Tablá / Cuadro / Quadro 12

SCHEMA DE GAZAGE / GAS CIRCUIT DIAGRAMME / GASSCHEMA / GASSHALTBILD / SCHEMA DI GASATURA / ESQUEMA DE GASIFICACIÓN / ESQUEMA DO GÁS

Désignation / Designation / Omschrijving / Designazione / Beskrivning/ Designación/ Designação	Référence / Part number / N°
Chapeau de brûleur / Burner cap / Branderdop / Brenneraufsatz / Cappello del bruciatore / Tapa de quemador / Brännarlock / Espalhador 1,5 kW	65.330005
Chapeau de brûleur / Burner cap / Branderdop / Brenneraufsatz / Cappello del bruciatore / Tapa de quemador / Brännarlock / Espalhador 3,0 W	65.330006
Chapeau de brûleur / Burner cap / Branderdop / Brenneraufsatz / Cappello del bruciatore / Tapa de quemador / Brännarlock / Espalhador 4,0 kW	65.330007
Chapeau de brûleur / Burner cap / Branderdop / Brenneraufsatz / Cappello del bruciatore / Tapa de quemador / Brännarlock / Espalhador 5,0 kW	65.330008
Corps de brûleur / Burner bowl / Branderschacht / Sicherheitbrennerkörper / Corpo del bruciatore / Cuerpo de quemador / Brännarkropp / Corpo do queimador 1,5 kW	65.640003
Corps de brûleur / Burner bowl / Branderschacht / Sicherheitbrennerkörper / Corpo del bruciatore / Cuerpo de quemador / Brännarkropp / Corpo do queimador 3,0 kW	65.640004
Corps de brûleur / Burner bowl / Branderschacht / Sicherheitbrennerkörper / Corpo del bruciatore / Cuerpo de quemador / Brännarkropp / Corpo do queimador 4,0 kW	65.640005
Corps de brûleur / Burner bowl / Branderschacht / Sicherheitbrennerkörper / Corpo del bruciatore / Cuerpo de quemador / Brännarkropp / Corpo do queimador 5,0 kW	65.640006
Bouchon de prise de pression	65.32638
Porte injecteur (table)/ Injector holder (Cooking surface) / Injectorhouder (Kooktafel) / Düsenhalter (Kochfeld) / Porta-iniettore (tavolo) / Portainyector (encimera) / Injektorhållare (Klassisk spishåll) / Porta-injector (mesa)	65.30915
Thermocouple (table) / Thermokoppel (Cooking surface) / Thermokoppel (Kooktafel) / Thermokoppel (Kochfeld) / Termocoppia (tavolo) / Termopar (encimera) / Termoelement (Klassisk spishåll) / Termopar (mesa)	65.39895
Ens. Brûleur / Burner assy / Branderstet / Brennersystem / Ins bruciatore / Conjunto quemador / Brännaraggregat / Conjunto quemador	88.248300
Joint / Gasket / Afdichting / Dichtung / Guarnizione / Junta / Packning / Junta	65.119003



SCHEMA DE GAZAGE / GAS CIRCUIT DIAGRAMME / GASSCHEMA / GASSHALTBILD / SCHEMA DI GASATURA / ESQUEMA DE GASIFICACIÓN / ESQUEMA DO GÁS

Désignation / Designation / Omschrijving / Designazione / Beskrivning/ Designação		Référence / Part number / N°
Robinet de table / Gas valve / Sicherheits-Kochfeldventil / Rubinetto tavolo / Säkerhetsventil värmeplattan / Llave de seguridad encimera / Torneira da placa com segurança		65.39140
Bague d'air / Air Shuttler / Lufttring / Luchtring / Anello dell'aria / Anillo de aire / Lufttringen / Anel de ar		65.080005
Tube mélangeur / Mixing tube (1,5-3,0-4,0 & 5,0 kW)		65.064007
Porte injecteur / Injector holder / Düsenhalter / Porta-iniettore / Portainyector / Injektorhållare / Porta-injector		65.033018
Rondelle d'étanchéité / Sealing ring / Dichtungsring. / Dichtungsscheibe / Rondella di tenuta stagna / Arandela de estanqueidad / Tättningsbricka / Anilha de vedação.		65.430007
Robinet de table / Gas valve / Sicherheits-Kochfeldventil / Rubinetto tavolo / Säkerhetsventil värmeplattan / Llave de seguridad encimera / Torneira da placa com segurança		65.51114
Porte injecteur (four) / Injector holder / Injektorholder / Düsenhalter / Porta-iniettore / Portainyector / Injektorhållare / Porta-injector		65.51764
Thermocouple / Thermokoppel / Thermokoppel / Termocoppia / Termopar / Termoelement / Termopar		65.39896
Robinet thermostatique de four / Oven thermostat valve / Thermostaatkraan van oven / Thermostatisches Ventil / Rubinetto termostatico del forno / Llave termostática de horno / Termostatventil / Torneira termostática		65.51110
Porte injecteur four / Injector holder / Injektorholder / Düsenhalter / Porta-iniettore / Portainyector / Injektorhållare / Porta-injector		65.51764



ANNEXE TECHNIQUE

Points de raccordements autorisés / Authorized connection points / Autorisierte Anschlusspunkte/ Puntos de conexión autorizadas / Punti di connessione autorizzati / Toegestane aansluitpunten / Autoriserte tilkoblingspunkter:

Tableau / Table /Tabelle /Tabella / Tablă / Cuadro / Quadro 13										
		AT	BE	CH	DE	DK	GB	GR	NL	NO
Raccord Filetage ext conique	EN10226-1	oui	oui	oui	oui	oui	oui	oui	oui	oui
Raccord filetage ext parrallèle	EN10228-1	oui	oui	oui	oui	oui	oui	oui	oui	oui

